



ATD-5519  
Digital Multimeter  
Operation Manual

**CONTENT**

1. Safety rules.....	2
2. Features.....	3
3. Measurement range.....	5
4. Electrical specification.....	5
5. Operation.....	8
6. Maintenance.....	12


We thank you very much for your purchasing our products . They are most reliable, high-precision instruments, designed by our excellent technology .Before you use your new instrument , please read this *OPERATION MANUAL* completely and familiarize you self thoroughly with all function and connections with proper use and care your digital multimeter will give you years of satisfactory service .

#### Safety rules

- Use the meter only as specified in this manual.
- Never measure voltage while the test leads are at the current test state.
- Do not use the meter if it looks damaged.
- Inspect the leads for damaged insulation or exposed metal, check test lead continuity , replace damaged leads.
- Disconnect the power and discharge all high-voltage capacitors before testing in resistance, continuity, and diode function.
- Be Cautions when working above DC 60V or AC 42V , such voltages may cause a shock hazard.
- When making measurement, keep your fingers behind the guards plant on the probes.
- Select the proper function and range for measurement , to avoid damaging the meter, disconnect the test leads from test points before change function.
- **If the voltage of measuring frequency is too high the meter will into protection state the display can't indicate measurement value.**

- 2 -

#### Features

Measuring method ..... $\Delta \Sigma$  mode.  
Display ..... 4000 counts LCD.  
Range ..... Auto range / Manual range  
Polarity ..... Automatic on indication for positive(+) polarity , minus(-)sign for negative polarity.  
Overrange indication:....."OL" mark indication .  
Low battery indication :....."" mark is displayed when the battery voltage drops below about 2.4V .  
Data hold ..... Data hold function .  
Auto power off :.....The meter is powered off 30 minutes later after the last operation was made . To bring back display please turn rotary switch to more positions or push any button.  
Operational temperature :.....0°C to 40°C,  $\leq 75\%RH$  . Storage temperature : -20°C to 60°C,  $< 80\%RH$  .  
Power supply(3V) :.....R6P or 1.5V AA 2 Pcs.  
Power consumption :.....4.5mW(typical) .  
Size :.....75(W) × 155(H) × 33(D)mm .  
Weight :.....Approx. 260g(Included Battery) .

- 3 -

Table 1. Terminals

Terminals	Description
COM	Common terminal for all measurements
mA	Input for DC 0.1 $\mu$ A to 400mA or AC 0.1 $\mu$ A to 400mA current measurements
10A	Input for 0.001A to 10A current measurements
$\rightarrow$ $\leftarrow$ $\rightarrow$ $\leftarrow$ V/ $\Omega$ /Hz	Input for voltage , continuity , resistance , diode , capacitance , frequency and duty cycle measurements

Table 2. Push button

Button	Function	Operation performed	Note
<b>RANGE</b>	DCV ,ACV, DCA,ACA, $\Omega$	Press <b>RANGE</b> enter the manual range mode. Press <b>RANGE</b> more than 2 sec . return to auto range state.	
<b>SELECT</b>	$\sim$ $\mu$ (mA), $\sim$ A $\Omega$ $\rightarrow$ $\leftarrow$ $\rightarrow$ $\leftarrow$	Press <b>SELECT</b> to select DC or AC and $\Omega$ , $\rightarrow$ $\leftarrow$ or $\rightarrow$ $\leftarrow$ mode	The Yellow key
<b>REL</b> $\Delta$	Any switch position except Hz	Press this button meter enter relative measurement mode , the value is equalled test value subtract reference value.	
<b>HOLD</b>	Any switch position except Hz and DUTY	Press <b>HOLD</b> meter enter data hold mode and press this button again the meter exit hold mode.	
<b>Hz/DUTY</b>	Switch at Hz /V/ $\mu$ A/mA/A position	Press this button change Hz or duty cycle test mode.	The Blue Key
<b>RESET</b>	Clean all value	All range	

- 4 -

### Measurement range

A measurement range determines the highest value the meter can measure .Most meter functions have more than one range . So being in the right measurement range is important . If the range is too low for the input , the meter displays "OL" to indicate overload .If the range too high , the meter will not display the most accurate measurement .Power on the meter it in auto range mode . Press RANGE the meter enters the manual range mode and "AUTO" turn off . Each press of RANGE increments the range . When the highest range is reached , the meter wraps to the lowest range . Turn switch to any position the meter will exit manual range mode . In the auto range mode , the meter selects the best range for the input detected . In the manual range mode , you can select the range .This allows you to override auto range and lock the meter in a specific range .

### Electrical specification

Accuracies are  $\pm$  (% of reading +number in last digit) at  $23\pm 5^{\circ}\text{C}$  , <75%RH.

Table 3. DCV

Range	Resolution	accuracy	Note
400.0mV	0.1mV	$\pm(0.5\% \text{rdg}+5)$	Input resistance: 10M $\Omega$ . Overload protect:400mV Range 250V RMS.The rest 600V DC or AC 600V RMS.
4.000V	1mV		
40.00V	10mV		
400.0V	100mV		
600V	1V	$\pm(0.8\% \text{rdg}+5)$	

- 5 -

Table 4.AC.V

Range	Resolution	accuracy	Note
400.0mV	0.1mV	$\pm(1.5\%rdg+8)$	Frequency response:50Hz - 400Hz Input resistance: 10M $\Omega$ . Overload protect:400mV Range 250V RMS.The rest 600V DC or AC 600V RMS.
4.000V	1mV	$\pm(0.8\%rdg+5)$	
40.00V	10mV		
400.0V	100mV		
600V	1V	$\pm(1.2\%rdg+5)$	

Table 5.DCA

Range	Resolution	accuracy	Note
400.0 $\mu$ A	0.1 $\mu$ A	$\pm(2.0\%rdg+5)$	Overload protect: Fast fuse 0.5A/250V & Fast fuse 10A/250V. 10A for 15sec maximum. Input voltage drop: $\leq 0.4V$ .
4000 $\mu$ A	1 $\mu$ A		
40.00mA	10 $\mu$ A	$\pm(1.5\%rdg+5)$	
400.0mA	100 $\mu$ A		
4.000A	1mA	$\pm(2.0\%rdg+5)$	
10.00A	10mA		

Table6.ACA

Range	Resolution	accuracy	Note
400.0 $\mu$ A	0.1 $\mu$ A	$\pm(2.5\%rdg+3)$	Overload protect: Fast fuse 0.5A/250V & Fast fuse 10A/250V.
4000 $\mu$ A	1 $\mu$ A		

- 6 -

40.00mA	10 $\mu$ A	$\pm(2.0\%rdg+5)$	10A for 15sec maximum. Input voltage drop: $\leq 0.4V$ . Frequency Respond: 50Hz - 400Hz
400.0mA	100 $\mu$ A		
4.000A	1mA	$\pm(2.5\%rdg+5)$	
10.00A	10mA		

Table7.Resistance

Range	Resolution	accuracy	Note
400.0 $\Omega$	100m $\Omega$	$\pm(1.0\%rdg+5)$	Overload protect: 250V RMS
4.000k $\Omega$	1 $\Omega$		
40.00k $\Omega$	10 $\Omega$		
400.0k $\Omega$	100 $\Omega$		
4.000M $\Omega$	1k $\Omega$	$\pm(2.0\%rdg+5)$	
40.00M $\Omega$	10k $\Omega$		

Table 8. Capacitance

Range	Resolution	Accuracy	Note
40.00nF	10pF	$\pm(3.5\%rdg+10)$	Overload protect: 250V RMS
400.0nF	100pF	$\pm(3.0\%rdg+5)$	
4.000 $\mu$ F	1nF		
40.00 $\mu$ F	10nF		
100.0 $\mu$ F	100nF	$\pm(3.5\%rdg+5)$	

- 7 -

Table 9. Diode

Range	Description	Note
	Display read approx. forward voltage of diode	Forward DC current approx. 1.5mA; Reversed DC voltage approx. 1.5V.

Overload protect:250V RMS

Table 10.Frequency and Duty

Range	Resolution	Accuracy	Sensitivity	Note
5.12Hz-10MHz	0.001Hz-10kHz	$\pm(0.1\%rdg+5)$	$\leq 1\text{MHz}: 0.7\text{V RMS};$ $> 1\text{MHz}: 1.5\text{V RMS}$	Overload protect: 250V RMS Duty Cycle:10Hz – 1kHz
DUTY CYCLE: 0.1% to 99.9%		$\pm(2.5\%rdg+5)$	1.5V RMS	

### Operation

#### AC voltage measurement

1. Set the rotary switch to " $\sim V$ " position.
2. Connect the black test lead to "COM" terminal and the red test lead to " $\rightarrow \bullet \bullet \bullet \rightarrow V/\Omega/Hz$ " terminal .
3. Touch the probes to the test points and reading the display ,at same time,you can press Hz/DUTY button obtain the signal frequency and duty of voltage is in measured.

#### DC voltage measurement

1. Set the rotary switch to " $\equiv V$ " position.

- 8 -

2. Connect the black test lead to "COM" terminal and the red test lead to " $\rightarrow \bullet \bullet \bullet \rightarrow V/\Omega/Hz$ " terminal .
3. Touch the probes to the test points and read the display ,at same time,you can press Hz/DUTY button obtain the signal frequency and duty of voltage is in measured.

#### DC / AC Current measurement

##### Warning

To avoid damage to the meter or injury if the fuse blows , never attempt an in-circuit current measurement where the open-circuit potential to earth is greater than 600V. To avoid damage to the meter , check the meter's fuses before proceeding . Use the proper terminals , function , and range for your measurement . Never place the probes in parallel with a circuit or component when the leads are plugged into the current terminals .

1. Turn off power to the circuit . Discharge all high-voltage capacitors .
2. Set the rotary switch to " $\sim \mu A$ " , " $\sim mA$ " or " $\sim A$ " position
3. Press SELECT (yellow) to select DC or AC mode .
4. Connect the black test lead to "COM" terminal and the red test lead to "mA" or "A" terminal .
5. Touch the probes to the test points , turn on to the circuit and read the display ,at same time, you can press Hz/DUTY button obtain the signal frequency and duty of current is in measured..

#### Resistance measurement



##### Caution

- 9 -


#### Capacitance measurement

##### Caution

To avoid damage to the meter or to the equipment under test , disconnect circuit power and discharge all high -voltage capacitance before measuring capacitance . Use the DC voltage function to confirm that the capacitor is discharged .

1. Set the rotary switch to "  " position .
2. Connect the black test lead to "COM" terminal and red test lead to "  V/ $\Omega$ /Hz " terminal .
3. Touch the probes to test point , if the capacitor is a polarity , the red test lead to position leg and black test lead to minus leg .

#### Frequency and duty cycle measurement

1. Set the rotary switch to " Hz " position .
  2. Connect the black test lead to " COM " terminal and the red test lead to "  V/ $\Omega$ /Hz " terminal .
  3. Press Hz/DUTY to select Hz or DUTY test mode .
  4. Touch the probes to signal source and read display .
- Note: When the rotary switch at voltage or current measurement positions, press Hz/DUTY can measure frequency or duty cycle also.


- 11 -

#### Maintenance

##### Warning

To avoid electrical shock or damage the meter . do not get water inside the case . If the meter fails to operate , check battery , test leads , fuse , etc., and replace them if necessary . If the meter still does not work , double check operating procedure as described in this manual .

#### Battery replacement

The meter is powered by R6P or 1.5V AA battery two pieces , Replace battery if the low battery sign "  " is displayed .

- (1) Set the rotary switch to " OFF " position .
- (2) Loosen screws on battery cover , pull up and move the battery cover .
- (3) Replace the defective battery .
- (4) Reverse the procedure of opening battery cover to close the battery cover .

#### Fuse replacement

- (1) Set the rotary switch to " OFF " position .
- (2) Loosen screws on bottom cover , pull up and move the bottom cover .
- (3) Replace the defective fuse and use same size and rating install in the fuse holder ..
- (4) Reverse the procedure of opening cover to close the bottom cover .

- 12 -