



Hydraulic Transmission Jack, Telescopic

Operating Instructions & Parts Manual

Model
BH7000

Capacity
700 lb.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

WARNING

To avoid **crushing and related injuries**:



NEVER work on, under or around a load supported only by a hydraulic jack. **Immediately** transfer the load to an appropriate work station.

 **WARNING:** Cancer and Reproductive Harm.

Read this manual and follow all the Safety Rules and Operating Instructions before using this product.

SAFETY and GENERAL INFORMATION

Save these instructions. For your safety, read, understand, and follow the information provided with and on this jack before using. The owner and operator of this equipment shall have an understanding of this jack and safe operating procedures before attempting to use. The owner and operator shall be aware that use and repair of this product may require special skills and knowledge. Instructions and safety information shall be conveyed in the operator's native language before use of this jack is authorized. If any doubt exists as to the safe and proper use of this jack, remove from service immediately.

Inspect before each use. Do not use if broken, bent, cracked or damaged parts are noted. Any jack that appears damaged in any way, or operates abnormally shall be removed from service immediately. If the jack has been or suspected to have been subjected to a shock load (a load dropped suddenly, unexpectedly upon it), immediately discontinue use until jack has been checked by a factory authorized service center (contact distributor or manufacturer for list of authorized service centers). It is recommended that an annual inspection be done by qualified personnel. Labels and Operator's Manuals are available from manufacturer.

PRODUCT DESCRIPTION

Hydraulic Transmission Jack is designed to be used as an aid in the removal and installation of automotive and light truck transmissions, transfer cases and transaxles. This telescopic style transmission jack is for use under an overhead lift or in a garage pit.



NEVER use for any purpose other than those uses outlined above!

SPECIFICATIONS

Model	Capacity	Min. Height	Max. Height	Saddle Base	Extended Saddle Area	Jack Size	Volume of Hyd. Oil
BH7000	700 lb.	57 1/4"	76 3/8"	9 7/8" x 9 7/8"	18 7/8" x 18 7/8"	36 1/8" x 32 5/8"	695 mL

PREPARATION

Assembly (refer to Figure 1)

Tools required: M16 & M18 wrench.

1. Four major parts should be included in the package:
(a) Hydraulic unit; (b) Upright Post; (c) Saddle Assembly; (d) 2 pieces of base half with hardware.
2. Attach the base halves to the upright post, then secure using threaded pins, washers and M12 nuts.
3. Attach the casters onto the base halves using M12 nuts and washers.
4. Place hydraulic unit on top of the upright post and secure with M10x25 bolts and washers.
5. Attach saddle assembly above the ram of hydraulic unit and secure using pin and spring pin provided.
6. Attach all four bracket supports onto saddle plate with bolts and wing nuts.
7. Attach saddle brackets to bracket support with provided nuts.
8. Finally, attach chains with bolts, washers, and nuts to saddle bracket.

Before Use

1. Verify that the product and application are compatible, if in doubt call BlackhawkTech.
2. Before using this product, read the operator's manual completely and familiarize yourself thoroughly with the product, its components and recognize the hazards associated with its use.
3. With ram plunger fully retracted, remove the oil filler plug. Insert the handle into the handle sleeve, then pump 6 to 8 strokes. This will help release any pressurized air, which may be trapped within the reservoir. Ensure the oil level is just below the oil filler hole. Reinstall the oil filler plug.
4. To familiarize yourself with basic operation, turn the release valve lever:
 - a. Clockwise until firm resistance is felt to further turning. This is the 'CLOSED' release valve position used to raise the ram/saddle.
 - b. Counter-clockwise, but no more than 2 turns from the closed position. This is the 'OPEN' release valve position used to lower the ram/saddle.
5. Ensure that jack rolls freely. Raise and lower the unloaded jack throughout the lifting range before putting into service to ensure the pump operates smoothly. Replace worn or damaged parts and assemblies with Blackhawk authorized replacement parts only.





Figure 1- Transmission Jack Components

WARNING

- **Read, understand, and follow** all printed material provided with and on this product **before use**.
- **Do not** exceed rated capacity.
- Use **only** on hard, level surfaces.
- **Adequately support the vehicle before starting repairs.**
- If loaded jack must be moved, make certain that load is secured by appropriate means, is stable, is in the **lowest possible position**, is moved over a smooth, hard level surface and that the **lifting platform is level**.
- Use of this product is **limited to removal, installation, and transportation of automotive and light truck transmissions, transfer cases and transaxles.**
- Use only adapters / accessories provided by the manufacturer of this transmission jack.
- Use only adapters / accessories whose **rated capacity is greater** than the rated capacity of this jack.
- Ensure the center of gravity is **center loaded** on the saddle.
- Never use this device as a work/repair station. **Transfer the load immediately** to a suitable work station.
- No alteration shall be made to this product.
- **Failure to heed** these markings may **result in personal injury and/or property damage.**

WARNING



To avoid **crushing and related injuries**:

- **Never** work on, under or around a load supported only by hydraulic jack.
- **Be alert** and **sober** when using this product. Do not operate under the influence of drugs or alcohol.

OPERATION

Follow the instruction for removal and installation of transmission, transfer case or transaxle according to the vehicle manufacturer's service manual.

Raise saddle assembly:

1. Close release valve by turning the release valve level clockwise until firm. Pump handle until saddle reaches desired height.
2. Secure the load using the provided chains.



Ensure center gravity of load is centered on the saddle and load is stable before moving jack. An off-center transmission could cause the jack to tip or flip over .

Lower saddle assembly:



*Be sure all tools and personnel are clear before lowering load. **Slowly engage release valve!** **Maintain control** of the rate of speed at which the load lowers at all times!*

Open release valve by turning lever counter-clockwise, but never more than 2 full turns. Control the rate of descent at all times. The more you open the release valve, the faster the load descends.



Never use this jack as a work station!

MAINTENANCE

Important: Use only good grade hydraulic jack oil. Avoid mixing different types of fluid and NEVER use brake fluid, turbine oil, transmission fluid, motor oil or glycerin. Improper fluid can cause premature failure of the jack and the potential for sudden and immediate loss of load. Hein-Werner HW93291 or equivalent is recommended.

Adding oil

1. With saddle fully lowered, set jack in its upright, level position. Remove oil filler plug.
2. Fill until oil is level with the oil filler hole, reinstall oil filler plug.

Changing oil

For best performance and longest life, replace the complete fluid supply at least once per year.

1. With saddle fully lowered, remove oil filler plug.
2. Lay the jack on its side and drain the fluid into a suitable container.

Note. Dispose of hydraulic fluid in accordance with local regulations.

3. Set jack in its level position. Fill until oil is level with the oil filler hole, reinstall oil filler plug.

Lubrication

A periodic coating of light lubricating oil to pivot points, axles and hinges will help to prevent rust and assure that casters and pump assemblies move freely.

Cleaning

Periodically check the pump piston and ram for signs of rust or corrosion. Clean as needed and wipe with an oily cloth.

Note: Never use sandpaper or abrasive material on these surfaces!

Storage

When not in use, store the jack with saddle fully lowered.

TROUBLESHOOTING

Symptom	Possible Causes	Corrective Action
Jack will not lift load	<ul style="list-style-type: none">• Release valve not tightly closed• Load is too heavy	<ul style="list-style-type: none">• Ensure release valve tightly closed• Consider higher capacity jack
Jack will lift, but not maintain pressure	<ul style="list-style-type: none">• Release valve not tightly closed• Hydraulic unit malfunction	<ul style="list-style-type: none">• Ensure release valve tightly closed• Discontinue use, Contact Blackhawk Tech. Service
Jack will not lower after unloading	<ul style="list-style-type: none">• Reservoir overfilled• Linkage binding	<ul style="list-style-type: none">• Ensure load is removed, then drain fluid to proper level• Clean and lubricate moving parts
Poor lift performance	<ul style="list-style-type: none">• Fluid level low• Air trapped in system	<ul style="list-style-type: none">• Ensure proper fluid level• With ram fully retracted, remove oil filler plug to let pressurized air escape, then reinstall oil filler plug
Jack will not lift to full extension	<ul style="list-style-type: none">• Fluid level low	<ul style="list-style-type: none">• Ensure proper fluid level

REPLACEMENT PARTS *(page 6 & 7)*

Not all components of the jack are replacement items, but are illustrated as a convenient reference of location and position in the assembly sequence. When ordering parts, give Model number, serial number and parts description.

Replacement Parts Illustration for Models BH7000:




Figure 2 - Replacement Parts Illustration for Models BH7000

Replacement Parts List for Models BH7000:

Item	Part Number	Description	Qty
1	T250-01000-000	Base Half/Leg	2
2	T250-00005-000	Steel Rod	2
3*	<i>see item#35 or hardware kit</i>	Nut M12	8
4*	<i>see item#35 or hardware kit</i>	Lock Washer	8
5	<i>see item# 34</i>	3" Caster	4
6*	<i>see item#36 or hardware kit</i>	Lock Washer	2
7*	<i>see item#36 or hardware kit</i>	Bolt M10x25	2
8	T250-02000-000	Post Assy.	1
9	BL80-20000-000	Handle Assy.	1
10	BL8A-10000-000	Hydraulic Unit	1
11	T250-00001-000	Pin	1
12	T474-00007-000	Retaining Pin	1
13	T250-08000-000	Tilt Adjustment Knob	2
14	T250-00002-000	Pin	2
15*	5304-00025-000	Washer	8
16	T250-00003-000	Pin	2
17*	5402-02018-000	Spring pin	1
18*	5307-00010-000	Washer	4
19*	5205-00010-000	Nut M10	2
20	T250-06000-000	Support Plate	1
21	T250-00004-000	Pin	2
22*	5304-00018-000	Washer	4
23	T250-07000-000	Adjustable Plate	1
24	T250-03000-000	Saddle Plate	1
25*	5202-00010-000	Nut M10	4
26	T250-00006-000	Extension Bracket	4
27	T250-04000-000	Chain Bracket	4
28*	5103-12040-000	Bolt	4
29*	<i>see item#37 or hardware kit</i>	Nut M12	4
30	<i>see item#37 or hardware kit</i>	Chain Assy.	2
31*	<i>see item#38 or hardware kit</i>	Bolt	4
32*	<i>see item#38 or hardware kit</i>	Nut M6	4
33	T250-00007-000	Tube	2
34	T250-90037-001	Caster Assy.	1
35	T250-90037-002	Kit (includes #3 & 4)	-
36	T250-90037-003	Bolt Kit (includes #6 & 7)	-
37	T250-90037-004	Bolt Kit (includes #28 & 29)	-
38	T250-90037-005	Bolt Kit (includes #31 & 32)	-
(*)	T250-90009-K01	Hardware Kit	-
-	BL800S-034	Seal Kit for Hydraulic Unit	-
(*) Items included in Hardware Kit			

Check out the collection of automotive tools we offer.