






Chicago Pneumatic

Torque Wrenches



Model :	Square drive	Torque Range	Lenght	Precision
				%
CP8905	1/4'	5 – 25 Nm 50 – 250 in-lb	245 mm	± 4%
CP8910	3/8'	20 - 100 Nm 15 – 75 ft-lb	410 mm	± 4%
CP8915	1/2'	40 – 200 Nm 30 – 150 ft-lb	520 mm	± 4%
CP8917	1/2'	60 – 340 Nm 50 – 250 ft-lb	610 mm	± 4%
CP8920	3/4'	150 – 750 Nm 100 – 550 ft-lb	1060 mm	± 4%
CP8925	1'	200 – 1000Nm 150 – 750 ft-lb	1255 mm	± 4%

1. Unlock



2. Adjust



3. Align



4. Lock



Caution

1. When it is not used, be sure to set torque to the lowest value.
2. Do not keep applying pressure after reaching the present torque; otherwise, the work piece may get damaged.
3. Before setting the torque value, check to see if the torque wrench is at lock or unlock status
4. Do not use an extension on the handle. This would impair the set value being correctly signalled
5. Never set the torque above or below the limit of the scale!
6. Handle your torque wrench as carefully as you treat a measurement instrument!