



# Workforce®

## Workforce® Manually Operated Grease Guns

Part No.: L1025, L1310, L1320,  
L1325, L1350, L1355



### Loading Your Grease Gun

Cartridge Loading	Suction Loading	Filler Pump Loading
Pull follower rod from barrel and lock into place.	Pull follower rod from barrel and lock into place.	<b>WARNING:</b> Do not load gun with air operated grease pump. Damage to unit will occur and warranty will be voided.
Unscrew barrel from head.	Unscrew barrel from head.	Wipe bulk filler nipple until clean.
Remove cap from end of grease cartridge	Insert open end of gun barrel two inches below surface of grease.	Insert bulk filler nipple into loader pump receptacle.
Insert cartridge into barrel, open end down.	Slowly pull back follower rod to draw in grease. Pull follower rod back all the way and lock into place.	Pump grease until 8 inches of follower rod is exposed. (Between the follower rod handle and barrel cap)
Remove pull tab from top of grease cartridge. Make sure cartridge is pushed down completely.	Screw barrel back into head.	Pump grease until barrel is full. (When barrel is full, rod can be pulled out without spring tension)
Screw barrel into head until snug.	Unlock follower rod and push into barrel.	Release follower rod.
Unscrew barrel slightly. (Approximately two revolutions)	If no bleeder valve is installed, unscrew barrel slightly. (Approximately two revolutions) (Skip this step if bleeder valve is installed)	Push follower rod into barrel.
Release follower rod.	Release follower rod.	Prime. (see "Priming Your Grease Gun")
Push follower rod into barrel.	Push follower rod into barrel.	
Screw barrel into head.	Depress bleeder valve to release air. (If bleeder valve is installed)	Begin greasing.
Prime. (see "Priming Your Grease Gun")	Prime. (see "Priming Your Grease Gun")	
Begin greasing.	Begin greasing.	

### Priming Your Grease Gun


- Point outlet up at least 45 degrees.
- Using slow, complete strokes, stroke handle repeatedly until grease flows without air.  
(Should require 10 - 20 strokes)

### Greasing a Zerk (Grease Fitting)

- Press coupler onto zerk.
- Keep coupler and zerk as closely aligned as possible.
- Begin greasing.
- **To Remove Coupler From Zerk:**
  - Tilt coupler to one side, twist and pull.

Failure to follow above procedure may result in damage to coupler or fitting.

## Grease Gun Terms



## Troubleshooting Your Grease Gun

Problem	Cause(s)	Remedy
Grease does not flow when handle is stroked.	Gun needs to be re-primed	See "Re-Priming Your Grease Gun"
	Grease cartridge is still capped	<ul style="list-style-type: none"> <li>Check to ensure caps have been removed from both ends of cartridge</li> </ul>
	Grease cartridge or barrel is empty	<ul style="list-style-type: none"> <li>Insert new cartridge or fill barrel</li> <li>Prime gun</li> </ul>
	Blocked Grease Coupler	<ul style="list-style-type: none"> <li>Remove coupler and pump grease</li> <li>If grease flows without coupler, clean or replace extension</li> </ul>
	Blocked Grease Extension	<ul style="list-style-type: none"> <li>Remove extension and pump grease</li> <li>If grease flows without extension, clean or replace extension</li> </ul>
Grease leaks between gun head and extension or extension and coupler.	Threads need to be sealed	Apply thread sealant
Grease leaks from coupler body joint or between coupler jaws and grease fitting.	Damaged coupler	Replace coupler
	Damaged grease fitting	Replace fitting