




SERVICE PARTS LIST

BULLETIN NO.
54-24-0075

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN
1-1/8" (3Kg) SDS Rotary Hammer		
CATALOG NO. 5268-21	STARTING SERIAL NO. F82A	WIRING INSTRUCTION SEE PAGE 5



***NOTE:**
There are two Rubber Washers (83) that are to be installed in recessed pockets on the bottom of the Gearcase Cover (54). The washers are held in place by the two middle Gearcase Screws (9b).

● = Component of Rotary Hammer Service Kit No. 14-46-5268 (See page three)

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
9b	06-75-2408	M4 x 17mm Pan Hd. Taptite T-20 w/Nylok	6
14b	34-40-0068	O-Ring (1 on Piston #42b, 1 on Ram #14a)	2
18	14-29-0067	Gearbox Assembly	1
23a	05-78-0105	M4 x 10mm Pan Hd. Taptite Screw	2
26c	06-82-2025	M3.5 x 16mm Pan Hd. Plastite T-10 Screw	1
26d	05-88-1610	M3.5 x 10mm Pan Hd. Plastite T-10 Screw	7
34	45-88-0106	Washer	1
35	32-60-0042	Crank Gear Assembly with Needle Bearing	1
36	44-90-0152	Crank Shift Ring	1
37	40-50-0107	Crank Spring	1
38	14-09-0110	Crank Assembly	1
39	44-66-0122	Crank Shim	1
40	42-70-5268	● Retaining E-Ring	1
41	14-46-0117	Chisel Shifter Assembly	1
41a	-----	M2 x 27mm Dowel Pin	1
41b	-----	M2 x 40mm Dowel Pin	1
41c	-----	Chisel Bracket	1
41d	-----	Chisel Shift Driver	1
42a	44-94-0022	Connecting Rod	1
42b	44-62-0302	Piston	1
42c	44-60-0147	Wrist Pin	1
43	44-66-0303	Locking Plate	1
44	44-90-0127	Shift Ring	1
45	32-05-0202	Bevel Gear	1
46	45-88-0112	Thrust Washer	2

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
47	02-50-0105	Thrust Bearing	1
48	32-10-0094	Clutch Gear Assembly	1
49	44-66-0132	Clamp Plate	1
50	14-46-0037	Fork Assembly	1
50a	-----	Fork	1
50b	-----	Fork Spring	1
51	42-90-0022	Shifting Coupler	1
52	34-40-0093	● O-Ring	1
53	42-92-0052	● Gearcase Gasket (See page three)	1
54	28-20-0182	Gearcase Cover	1
55	44-10-0057	Selector Knob Assembly	1
55a	-----	Selector Ball	1
55b	-----	Selector Spring	1
55c	-----	Selector Knob	1
56	22-90-0132	Top Grommet	1
57	45-88-0152	Vibration Washer (1 each for top & bottom AVS)	2
58	44-20-0141	Top AVS Square Guide Pipe	1
59	40-50-0211	Top AVS Spring	1
60	42-38-0077	Vibration Bumper (2 each for top & bottom AVS)	4
61	42-38-0137	Bumper Holder (2 each for top & bottom AVS)	4
62a	42-36-0032	Retaining Plate (Top AVS)	1
63	05-78-0012	M4 x 52mm Scr. (1 each for top & bottom AVS)	2
64	42-42-0053	Forward/Reverse Button	1
65	23-66-0027	On-Off Switch	1
66	14-34-0107	Handle Assembly	1
66a	-----	Left Handle Halve	1
66b	-----	Right Handle Halve	1
68	42-68-0601	Power Cord Clamp	2
69	05-78-5313	M4 x 9.5mm Pan Hd. Plastite T-15 Screw	4
70	22-64-0032	120V Power Cord Assembly	1
80	42-55-5268	Blow Molded Carrying Case	1
83	45-88-0014	● Rubber Washer	2

● = Component of Rotary Hammer Service Kit No. 14-46-5268





FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	45-12-0045	● Dust Shield	1
2	44-90-5262	● Retaining Ring	1
3	45-22-0062	Collar with Steel Insert	1
4	02-02-0275	● 7mm Steel Ball	2
5	42-36-0017	● Ball Support Plate	1
6	40-50-0082	Conical Spring	1
7	14-34-0015	Side Handle Assembly	1
7a	44-66-0072	Clamp Collar	1
7b	05-81-5376	M8 x 53mm Screw	1
7c	-----	Side Handle Carrier Assembly	1
7f	45-88-5377	Washer	1
7g	31-05-5383	Side Handle	1
7h	44-94-5381	Depth Rod	1
8	45-22-0045	Side Handle Sleeve	1
9a	05-78-5316	M4 x 14mm Pan Hd. Taptite T-20 Screw	4
10	42-40-0027	Bushing Sleeve Assembly with Seals	1
11	45-88-0157	Washer	3
12	42-38-0127	● Bumper	2
13	14-46-0197	Spindle Assembly	1
13a	38-50-0052	Spindle	1
13b	43-06-0060	Brake Ring	1
13c	44-66-0203	Anvil Ring	1
13d	34-40-0032	● Square O-Ring	1
13e	42-06-0027	Anvil/Striker	1
13f	34-40-0052	● Anvil O-Ring	1
13g	42-06-0067	Ram Catcher	1
13h	44-90-0032	● Back Pressure Ring	1
13j	34-60-0027	● Anvil Retaining Ring	1
14a	45-56-0065	Ram	1

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
14b	34-40-0068	● O-Ring (1 on Ram #14a, 1 on Piston #42b)	2
15	42-76-0037	Spindle Collar	1
16	34-40-0082	● O-Ring	1
17	44-60-0119	Retaining Plate	1
18	14-29-0067	Gearbox Assembly	1


FIG.	PART NO.	DESCRIPTION	NO. REQ.
19	31-15-0039	Shroud	1
20	05-86-1000	M3 x 9.5mm Pan Hd. Tapt.	T-10 Scr. 2
21	34-40-5320	● O-Ring	1
22	14-50-0052	120V Armature Assembly	1
22a	02-04-5382	Ball Bearing	1
22b	23-16-0092	Commutator Insulator Disc	1
23b	05-78-0105	M4 x 10mm Pan Hd. Taptite Screw	2
24	31-05-0057	Baffle	1
25	42-28-0085	Field Isolation Block	2
26a	05-88-1610	M3.5 x 10mm Pan Hd. Plastite T-10 Screw	3
27	23-44-0063	Motor Housing/Brush Cover	1
28	06-82-0062	M3 x 8mm Pan Hd. Washer T-10 Screw	4
29	22-20-0019	120V Carbon Brush Assembly	2
29a	22-18-5268	● 120V Carbon Brush (Set of 2)	1
30	05-74-0990	M5 x 15mm Pan Hd. Taptite T-25 Screw	4
31	28-50-0107	Motor Housing Assembly	1
33	18-07-0097	120V Split Field	1
57	45-88-0152	Vibration Washer	2
60	42-38-0077	Vibration Bumper	4
61	42-38-0137	Bumper Holder	4
62b	44-66-0131	Retaining Plate (Bottom AVS)	1
63	05-78-0012	M4 x 52mm Scr. (1 each for top & bottom AVS)	2
74	44-52-0052	Foam Block	2
75	40-50-0138	Bottom AVS Spring	1
76	44-68-0155	Bottom AVS Square Guide Pipe	1
77	22-90-0152	Bottom Grommet	1
78	12-20-5268	Service Nameplate (Not Shown)	1
81	45-88-0042	Bumper/Washer Holder	1
82	05-90-0225	Lock Washer	4
90	45-06-0042	Motor Seal	1



LUBRICATION NOTES:

Urethyn GE00 Grease
No. 49-08-5355, 2.8oz. / 80g tube

A total of approx. 60 grams will be used. Prior to reinstalling, clean gear assemblies with a clean, dry cloth. Lightly coat all parts highlighted here with Urethyn GE00 grease. Apply a greater amount of grease to all internal and external gear teeth.



Bottom View of Gear Case Cover #54 with Gasket #53- There are two gaskets in Service Kit 14-46-5268. Visually inspect gear case cover to determine which gasket to install. Discard the other gasket.

●14-46-5268

Rotary Hammer Service Kit

(For the 5268-21 120V Rotary Hammer disregard and discard 230V Carbon Brushes)


- | | | | |
|-----|------------|------------------------------------|-----|
| 1 | 42-12-0045 | Dust Shield | (1) |
| 2 | 44-90-5262 | Retaining Ring | (1) |
| 4 | 02-02-0275 | 7mm Steel Ball | (2) |
| 5 | 42-36-0017 | Ball Support Plate | (1) |
| 12 | 42-38-0127 | Bumper | (2) |
| 13d | 34-40-0032 | Square O-Ring | (1) |
| 13f | 34-40-0052 | Anvil O-Ring | (1) |
| 13h | 44-90-0032 | Back Pressure Ring | (1) |
| 13j | 34-60-0027 | Anvil Retaining Ring | (1) |
| 14b | 34-40-0068 | O-Ring | (2) |
| 16 | 34-40-0082 | O-Ring | (1) |
| 21 | 34-40-5320 | O-Ring | (1) |
| 29a | 22-18-5268 | 120V Carbon Brush (Set of 2) | (1) |
| | | For model 5268-21. | |
| 29a | 22-18-5269 | 230V Carbon Brush (Set of 2) | (1) |
| | | For model 5268-50. DISCARD | |
| 40 | 42-70-5268 | Retaining E-Ring | (1) |
| 52 | 34-40-0093 | O-Ring | (1) |
| 53 | 42-92-0052 | Gearcase Gasket (See detail above) | (1) |
| 53 | 42-92-0053 | Gearcase Gasket (See detail above) | (1) |
| 83 | 45-88-0014 | Rubber Washer | (2) |
| | 58-22-5268 | Instruction Sheet | (1) |
| | 49-08-5355 | Urethyn GE00 Grease | |
| | | 60 grams required- | |
| | | (80 gram, 2.8oz tube) | (1) |

NOTE: It is recommended to order Motor Seal #90 (45-06-0042) at the same time that Rotary Hammer Service Kit No. 14-46-5268 is installed.

SCREW TORQUE SPECIFICATIONS

FIG.	PART NO.	WHERE USED	SEAT TORQUE	
			(KG/CM)	(IN/LBS)
9a	05-78-5316	Bushing Sleeve Assembly	26	22.5
9b	06-75-2408	Gearcase Cover (4) Rear and Middle	32	27.8
9b	06-75-2408	Gearcase Cover (2) Front	32	27.8
20	05-86-1000	Shroud	12	10.5
23a	05-78-0105	Clamp Plate	26	22.5
23b	05-78-0105	Rotor Bearing Plate	33	28.5
26a	05-88-1610	Motor Housing/Brush Cover	6.5	5.5
26c	06-82-2025	Selector Knob	8.5	7.5
26d	05-88-1610	Right Handle Halve	6.5	5.5
28	06-82-0062	Carbon Brush Assembly	5	4.5
30	05-74-0990	Motor Housing Assembly	33	28.5
63	05-78-0012	Retaining Plate (Top and Bottom)	20	17
69	05-78-5313	Cord Clamps (Power Cord)	14	12
69	05-78-5313	Cord Clamps (Glass Fiber Tube)	11	9.5
		Switch Screws	5.5	4.5

NOTE: As an aid to working on the gearcase and spindle assemblies, a bench top fixture can be made from a 3.25" piece of 4" PVC pipe. The contour of the pipe can be cut according to dimensions in the illustration.












SERVICE TOOLS:

61-10-0041
Ring Expander
Cone

61-10-0043
Push Sleeve

61-10-0045
Seal Press Pin

61-10-0049
Anvil Sleeve
Snap Ring Bar






AS AN AID TO REASSEMBLY, TAKE NOTICE OF WIRE ROUTING AND POSITION IN WIRE GUIDES AND TRAPS WHILE DISMANTLING TOOL.

BE CAREFUL AND AVOID PINCHING WIRES BETWEEN HANDLE HALVES WHEN ASSEMBLING.

It is recommended that a .75" piece of heat shrink tubing be used to contain wires #3 & #4 at the right side of the switch. Do the same for wires #5 & #6 on the other side.

Insulated sleeving to extend .25 min. beyond clamp area.



**** TO AVOID CONFUSION, PLEASE NOTE:**
The insulation color for field wire #5 is BLACK. Early production of the field used in the 5268-21 Hammer had green insulation on wire #5 or used black heat shrink tubing over the green insulation.


WIRING SPECIFICATIONS				
Wire No.	Wire Color	Origin or Gauge	Length	Terminals, Connectors and 1 or 2 End Wire Preparation
1	White	22-64-0032	-----	Component of cord set. Connect to position 1↓ on bottom of switch as shown.
2	Black	22-64-0032	-----	Component of cord set. Connect to position 2↓ on bottom of switch as shown.
3	Blue	23-94-0072	-----	Blue Leadwire Assembly. Connect to position 7 on switch and left brush holder as shown.
4	Yellow	18-07-0097	-----	Component of split field (front halve). Connect to position 6 on switch as shown.
5	Black**	18-07-0097	-----	Component of split field (rear halve). Connect to position 5 on switch as shown.
6	Red	23-94-0062	-----	Red Leadwire Assembly. Connect to position 8 on switch and right brush holder as shown.
7	White	18-07-0097	-----	Component of split field (rear halve). Connect to position 1 on the bottom of switch as shown.
8	Black	18-07-0097	-----	Component of split field (front halve). Connect to position 2 on bottom of switch as shown.



SERVICE PARTS LIST

BULLETIN NO.
54-24-0076

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN 54-24-0075
1-1/8" (3Kg) SDS Rotary Hammer		
CATALOG NO. 5268-21	STARTING SERIAL NO. F82B	WIRING INSTRUCTION SEE PAGE 5



★ = Part number change from previous service parts list.
● = Component of Rotary Hammer Service Kit No. 14-46-5268 (See page three)

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
9b	06-75-2408	M4 x 17mm Pan Hd. Taptite T-20 w/Nylok	6
14b	34-40-0068	O-Ring (1 on Piston #42b, 1 on Ram #14a)	2
18	14-29-0067	Gearbox Assembly	1
23a	05-78-0105	M4 x 10mm Pan Hd. Taptite Screw	2
26c	06-82-2025	M3.5 x 16mm Pan Hd. Plastite T-10 Screw	1
26d	05-88-1610	M3.5 x 10mm Pan Hd. Plastite T-10 Screw	7
34	45-88-0106	Washer	1
35	32-60-0042	Crank Gear Assembly with Needle Bearing	1
36	44-90-0152	Crank Shift Ring	1
37	40-50-0107	Crank Spring	1
38	14-09-0110	Crank Assembly	1
39	44-66-0122	Crank Shim	1
40	42-70-5268	● Retaining E-Ring	1
41	14-46-0117	Chisel Shifter Assembly	1
41a	-----	M2 x 27mm Dowel Pin	1
41b	-----	M2 x 40mm Dowel Pin	1
41c	-----	Chisel Bracket	1
41d	-----	Chisel Shift Driver	1
42a	44-94-0022	Connecting Rod	1
42b	44-62-0302	Piston	1
42c	44-60-0147	Wrist Pin	1
43	44-66-0303	Locking Plate	1
44	44-90-0127	Shift Ring	1
45	32-05-0202	Bevel Gear	1
46	45-88-0112	Thrust Washer	2

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
47	02-50-0105	Thrust Bearing	1
48	32-10-0094	Clutch Gear Assembly	1
49	44-66-0132	Clamp Plate	1
50	14-46-0037	Fork Assembly	1
50a	-----	Fork	1
50b	-----	Fork Spring	1
51	42-90-0022	Shifting Coupler	1
52	34-40-0093	● O-Ring	1
★ 53	42-92-0053	● Gearcase Gasket (See page three)	1
★ 54	28-20-0183	Gearcase Cover	1
55	44-10-0057	Selector Knob Assembly	1
55a	-----	Selector Ball	1
55b	-----	Selector Spring	1
55c	-----	Selector Knob	1
56	22-90-0132	Top Grommet	1
57	45-88-0152	Vibration Washer (1 each for top & bottom AVS)	2
58	44-20-0141	Top AVS Square Guide Pipe	1
59	40-50-0211	Top AVS Spring	1
60	42-38-0077	Vibration Bumper (2 each for top & bottom AVS)	4
61	42-38-0137	Bumper Holder (2 each for top & bottom AVS)	4
62a	42-36-0032	Retaining Plate (Top AVS)	1
63	05-78-0012	M4 x 52mm Scr. (1 each for top & bottom AVS)	2
64	42-42-0053	Forward/Reverse Button	1
65	23-66-0027	On-Off Switch	1
66	14-34-0107	Handle Assembly	1
66a	-----	Left Handle Halve	1
66b	-----	Right Handle Halve	1
68	42-68-0601	Power Cord Clamp	2
69	05-78-5313	M4 x 9.5mm Pan Hd. Plastite T-15 Screw	4
70	22-64-0032	120V Power Cord Assembly	1
80	42-55-5268	Blow Molded Carrying Case	1
83	45-88-0014	● Rubber Washer	2

● = Component of Rotary Hammer Service Kit No. 14-46-5268




FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
1	45-12-0045	● Dust Shield	1
2	44-90-5262	● Retaining Ring	1
3	45-22-0062	Collar with Steel Insert	1
4	02-02-0275	● 7mm Steel Ball	2
5	42-36-0017	● Ball Support Plate	1
6	40-50-0082	Conical Spring	1
7	14-34-0015	Side Handle Assembly	1
7a	44-66-0072	Clamp Collar	1
7b	05-81-5376	M8 x 53mm Screw	1
7c	-----	Side Handle Carrier Assembly	1
7f	45-88-5377	Washer	1
7g	31-05-5383	Side Handle	1
7h	44-94-5381	Depth Rod	1
8	45-22-0045	Side Handle Sleeve	1
9a	05-78-5316	M4 x 14mm Pan Hd. Taptite T-20 Screw	4
10	42-40-0027	Bushing Sleeve Assembly with Seals	1
11	45-88-0157	Washer	3
12	42-38-0127	● Bumper	2
13	14-46-0197	Spindle Assembly	1
13a	38-50-0052	Spindle	1
13b	43-06-0060	Brake Ring	1
13c	44-66-0203	Anvil Ring	1
13d	34-40-0032	● Square O-Ring	1
13e	42-06-0027	Anvil/Striker	1
13f	34-40-0052	● Anvil O-Ring	1
13g	42-06-0067	Ram Catcher	1
13h	44-90-0032	● Back Pressure Ring	1
13j	34-60-0027	● Anvil Retaining Ring	1
14a	45-56-0065	Ram	1

FIG.	PART NO.	DESCRIPTION OF PART	NO. REQ.
14b	34-40-0068	● O-Ring (1 on Ram #14a, 1 on Piston #42b)	2
15	42-76-0037	Spindle Collar	1
16	34-40-0082	● O-Ring	1
17	44-60-0119	Retaining Plate	1
18	14-29-0067	Gearbox Assembly	1






FIG.	PART NO.	DESCRIPTION	NO. REQ.
19	31-15-0039	Shroud	1
20	05-86-1000	M3 x 9.5mm Pan Hd. Tapt.	T-10 Scr. 2
21	34-40-5320	● O-Ring	1
22	14-50-0052	120V Armature Assembly	1
22a	02-04-5382	Ball Bearing	1
22b	23-16-0092	Commutator Insulator Disc	1
23b	05-78-0105	M4 x 10mm Pan Hd. Taptite Screw	2
24	31-05-0057	Baffle	1
25	42-28-0085	Field Isolation Block	2
26a	05-88-1610	M3.5 x 10mm Pan Hd. Plastite T-10 Screw	3
27	23-44-0063	Motor Housing/Brush Cover	1
28	06-82-0062	M3 x 8mm Pan Hd. Washer T-10 Screw	4
29	22-20-0019	120V Carbon Brush Assembly	2
29a	22-18-5268	● 120V Carbon Brush (Set of 2)	1
30	05-74-0990	M5 x 15mm Pan Hd. Taptite T-25 Screw	4
31	28-50-0107	Motor Housing Assembly	1
33	18-07-0097	120V Split Field	1
57	45-88-0152	Vibration Washer	2
60	42-38-0077	Vibration Bumper	4
61	42-38-0137	Bumper Holder	4
62b	44-66-0131	Retaining Plate (Bottom AVS)	1
63	05-78-0012	M4 x 52mm Scr. (1 each for top & bottom AVS)	2
74	44-52-0052	Foam Block	2
75	40-50-0138	Bottom AVS Spring	1
76	44-68-0155	Bottom AVS Square Guide Pipe	1
77	22-90-0152	Bottom Grommet	1
78	12-20-5268	Service Nameplate (Not Shown)	1
81	45-88-0042	Bumper/Washer Holder	1
82	05-90-0225	Lock Washer	4
90	45-06-0042	Motor Seal	1



LUBRICATION NOTES:
Urethyn GE00 Grease

No. 49-08-5355, 2.8oz. / 80g tube

A total of approx. 60 grams will be used. Prior to reinstalling, clean gear assemblies with a clean, dry cloth. Lightly coat all parts highlighted here with Urethyn GE00 grease. Apply a greater amount of grease to all internal and external gear teeth.



Bottom View of Gear Case Cover #54 with Gasket #53- There are two gaskets in Service Kit 14-46-5268. Visually inspect gear case cover to determine which gasket to install. Discard the other gasket.

●14-46-5268

Rotary Hammer Service Kit

(For the 5268-21 120V Rotary Hammer disregard and discard 230V Carbon Brushes)


1	42-12-0045	Dust Shield	(1)
2	44-90-5262	Retaining Ring	(1)
4	02-02-0275	7mm Steel Ball	(2)
5	42-36-0017	Ball Support Plate	(1)
12	42-38-0127	Bumper	(2)
13d	34-40-0032	Square O-Ring	(1)
13f	34-40-0052	Anvil O-Ring	(1)
13h	44-90-0032	Back Pressure Ring	(1)
13j	34-60-0027	Anvil Retaining Ring	(1)
14b	34-40-0068	O-Ring	(2)
16	34-40-0082	O-Ring	(1)
21	34-40-5320	O-Ring	(1)
29a	22-18-5268	120V Carbon Brush (Set of 2)	(1)
		For model 5268-21.	
29a	22-18-5269	230V Carbon Brush (Set of 2)	(1)
		For model 5268-50. DISCARD	
40	42-70-5268	Retaining E-Ring	(1)
52	34-40-0093	O-Ring	(1)
53	42-92-0052	Gearcase Gasket (See detail above)	(1)
53	42-92-0053	Gearcase Gasket (See detail above)	(1)
83	45-88-0014	Rubber Washer	(2)
	58-22-5268	Instruction Sheet	(1)
	49-08-5355	Urethyn GE00 Grease	
		60 grams required-	
		(80 gram, 2.8oz tube)	(1)

NOTE: It is recommended to order Motor Seal #90 (45-06-0042) at the same time that Rotary Hammer Service Kit No. 14-46-5268 is installed.

SCREW TORQUE SPECIFICATIONS

FIG.	PART NO.	WHERE USED	SEAT TORQUE	
			(KG/CM)	(IN/LBS)
9a	05-78-5316	Bushing Sleeve Assembly	26	22.5
9b	06-75-2408	Gearcase Cover (4) Rear and Middle	32	27.8
9b	06-75-2408	Gearcase Cover (2) Front	32	27.8
20	05-86-1000	Shroud	12	10.5
23a	05-78-0105	Clamp Plate	26	22.5
23b	05-78-0105	Rotor Bearing Plate	33	28.5
26a	05-88-1610	Motor Housing/Brush Cover	6.5	5.5
26c	06-82-2025	Selector Knob	8.5	7.5
26d	05-88-1610	Right Handle Halve	6.5	5.5
28	06-82-0062	Carbon Brush Assembly	5	4.5
30	05-74-0990	Motor Housing Assembly	33	28.5
63	05-78-0012	Retaining Plate (Top and Bottom)	20	17
69	05-78-5313	Cord Clamps (Power Cord)	14	12
69	05-78-5313	Cord Clamps (Glass Fiber Tube)	11	9.5
		Switch Screws	5.5	4.5

NOTE: As an aid to working on the gearcase and spindle assemblies, a bench top fixture can be made from a 3.25" piece of 4" PVC pipe. The contour of the pipe can be cut according to dimensions in the illustration.












SERVICE TOOLS:

61-10-0041
Ring Expander
Cone

61-10-0043
Push Sleeve

61-10-0045
Seal Press Pin

61-10-0049
Anvil Sleeve
Snap Ring Bar






AS AN AID TO REASSEMBLY, TAKE NOTICE OF WIRE ROUTING AND POSITION IN WIRE GUIDES AND TRAPS WHILE DISMANTLING TOOL.

BE CAREFUL AND AVOID PINCHING WIRES BETWEEN HANDLE HALVES WHEN ASSEMBLING.

It is recommended that a .75" piece of heat shrink tubing be used to contain wires #3 & #4 at the right side of the switch. Do the same for wires #5 & #6 on the other side.

Insulated sleeving to extend .25 min. beyond clamp area.



**** TO AVOID CONFUSION, PLEASE NOTE:**
The insulation color for field wire #5 is BLACK. Early production of the field used in the 5268-21 Hammer had green insulation on wire #5 or used black heat shrink tubing over the green insulation.


WIRING SPECIFICATIONS				
Wire No.	Wire Color	Origin or Gauge	Length	Terminals, Connectors and 1 or 2 End Wire Preparation
1	White	22-64-0032	-----	Component of cord set. Connect to position 1↓ on bottom of switch as shown.
2	Black	22-64-0032	-----	Component of cord set. Connect to position 2↓ on bottom of switch as shown.
3	Blue	23-94-0072	-----	Blue Leadwire Assembly. Connect to position 7 on switch and left brush holder as shown.
4	Yellow	18-07-0097	-----	Component of split field (front halve). Connect to position 6 on switch as shown.
5	Black**	18-07-0097	-----	Component of split field (rear halve). Connect to position 5 on switch as shown.
6	Red	23-94-0062	-----	Red Leadwire Assembly. Connect to position 8 on switch and right brush holder as shown.
7	White	18-07-0097	-----	Component of split field (rear halve). Connect to position 1 on the bottom of switch as shown.
8	Black	18-07-0097	-----	Component of split field (front halve). Connect to position 2 on bottom of switch as shown.



SERVICE PARTS LIST

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN
1-1/8" ROTARY HAMMER		
CATALOG NO. 5359-21	SERIAL NUMBER 409A (See Service Note)	WIRING INSTRUCTION 58-01-1860

EXAMPLE:
 Component Parts (Small #)
 Are Included When Ordering
 The Assembly (Large #).



SERVICE NOTE: When servicing a 5359-21 Rotary Hammer with a serial number starting with 409A, first identify the series being serviced (Series I or Series II). Series I has a small taper on the strain relief. Use this bulletin, 54-24-5000, to order parts and service Series I tools. Series II has a large taper on the strain relief. Use bulletin 54-24-5001 (listed under serial number 409B) to order parts and service Series II tools.





FIG.	PART NO.	DESCRIPTION OF PART	QTY.
3	12-20-5359	SERVICE NAMEPLATE KIT	1
8	45-88-1245	WASHER	1
9	44-90-0340	SNAP RING (EXT.)	1
10	31-15-0257	CRANKCASE COVER	1
102	31-15-0255	BRUSH COVER	2
119	05-78-0745	TAPTITE SCREW	5
127	05-78-0715	SCREW	7
200	31-40-0042	GEARCASE	1
204	44-86-0625	SPLINED RETAINER	1
206	31-15-0307	CRANKCASE	1
208	45-88-8825	WASHER (ADD AS REQUIRED)	1
209	34-40-4440	O-RING	1
210	02-80-6025	THRUST BEARING SET	1
211	14-73-0247	WOBBLE SHAFT ASSEMBLY	1
212	36-66-3162	REDUCTION GEAR SHAFT	1
214	45-88-1250	WASHER	1
215	40-50-8897	SPRING	1
216	45-22-0302	COUPLING SLEEVE	1
★ 217	45-88-8414	WASHER	1
218	36-92-0747	WOBBLE PLATE	1
219	32-60-2622	REDUCTION GEAR	1
220	32-60-2157	OFFSET GEAR	1
221	32-60-2165	INTERNAL GEAR	1
222	44-82-0192	RAM	1
223	44-62-0157	PISTON	1
224	44-60-1405	WRIST PIN	1
225	45-88-1180	WASHER	2
226	44-90-4500	SHIFT RING	1
228	44-60-1485	PIN	1
229	44-66-6055	RETAINING PLATE	1
★ 232	-----	SDS SPINDLE	1
233	40-50-7977	BELLEVILLE SPRING	5
234	45-88-7767	STOP WASHER	1
★ 235	-----	SPINDLE GEAR	1
★ 236	-----	RETAINING RING (EXT.)	1
237	45-88-1255	WASHER	1
238	02-80-0150	THRUST BEARING	1
239	45-88-0775	RETAINING RING	1
241	44-82-0089	RAM CATCHER	1
243	42-76-0727	THRUST COLLAR	1
245	45-56-2537	STRIKER	1
248	45-88-1265	WASHER	1

FIG.	PART NO.	DESCRIPTION OF PART	QTY.
249	45-88-1264	STOP WASHER	1
251	02-50-2185	NEEDLE BEARING	2
253	31-86-0102	SPACER	1
255	40-50-8045	SPRING	1
256	02-02-0275	BALL	1
257	42-36-1755	SUPPORT PLATE	1
258	44-90-4285	HOLDING RING	1
259	45-88-1270	WASHER	2
261	44-10-0077	SHIFT LEVER	1
★ 262	44-66-0101	PLATE	1
264	-----	WASHER	1
265	44-96-0101	ROLLER	4
266	02-02-0110	BALL	4
267	05-77-0030	BOLT	1
268	45-88-1182	WASHER	1
269	45-88-1183	WASHER	1
270	44-90-0115	RING	1
271	45-88-1184	WASHER	1
272	45-88-1185	WASHER	1
273	45-88-1186	WASHER	1
275	05-74-0700	SCREW	2
276	05-74-0717	SCREW	2
415	45-60-0511	BEARING ASSY	1
420	36-66-4267	INTERMEDIATE GEAR SET	1
426	45-88-1170	RETAINING RING	1
427	45-88-1280	WASHER	1
600	43-46-0172	DEPTH GAGE (NOT SHOWN)	1
701	49-15-5300	SIDE HANDLE (NOT SHOWN)	1
1100	31-44-5359	HANDLE SET	1
1204	34-40-4454	O-RING	1
1207	43-44-0375	GASKET	1
1209	34-40-5359	O-RING	1
1210	34-40-4452	O-RING	1
1211	34-40-4451	O-RING	1
1212	34-40-4459	O-RING	1
1213	34-40-4456	O-RING	1
1214	42-76-0275	COLLAR	1
1215	43-87-0080	ISOLATION BLOCK	1
1218	44-90-4415	RETAINING RING	1
1219	34-40-0130	O-RING	1
1220	05-74-0685	SOCKET HEAD SCREW	4
1222	05-74-0695	SOCKET HEAD SCREW	2
1223	05-74-0697	SCREW	2
1224	34-40-0132	O-RING	1
1225	45-06-0215	FELT WASHER	1
1226	44-90-0375	SNAP RING	1
★ 1227	42-52-0065	DUST CAP	1
1228	38-50-0011	SDS SPINDLE KIT	1

Call Tech Support if you need help determining the Series

FIG.	PART NO.	DESCRIPTION OF PART	QTY.
3	12-20-5359	SERVICE NAMEPLATE KIT	1
4	22-64-0506	CORD SET	1
7	44-60-0015	GROOVED DOWEL PIN	1
100	31-50-0955	MOTOR HOUSING	1
105	18-07-0121	FIELD -SERVICE	1
116	31-05-0220	AIR DEFLECTOR RING	1
117	45-30-0210	SLUG	4
120	22-20-0232	BRUSH HOLDER	2
121	31-17-0184	WIRE CLAMP	1
122	23-94-1034	WIRE	1
123	42-70-1100	FIELD CENTERING CLIP	2
124	05-78-0747	SCREW	1
125	31-17-0240	CORD CLAMP	1
126	05-78-0720	SCREW	2
127	05-78-0715	SCREW	7
★ 128	23-94-1042	WIRE (BLACK)	1
★ 129	23-94-1037	WIRE (YELLOW)	1
130	42-92-0015	BEARING COVER	1
131	45-88-1340	WASHER	1
135	23-66-1687	SWITCH	1
401	31-15-0442	MOTOR COVER	1
406	16-07-0123	ARMATURE - SERVICE	1
407	22-84-0940	FAN	1
408	02-04-1800	BALL BEARING	1
409	02-04-1817	BALL BEARING	1
410	43-06-0135	INSULATING DISC	1
413	45-22-0465	SLEEVE	1
414	45-36-1595	SPACER	1
420	36-66-4267	INTERMEDIATE GEAR SET	1
1100	31-44-5359	HANDLE SET	1
1201	22-18-0942	BRUSH (2) SERVICE KIT	1
1205	42-96-0170	BEARING CUP	1
1208	44-76-0285	STRAIN RELIEF	1
1216	45-30-0220	SLUG	2
1221	05-74-0705	SOCKET HEAD SCREW	4

SEE BACK PAGE OF THIS BULLETIN
FOR ADDITIONAL LUBRICATION
AND SERVICE NOTES



Service Kit 14-46-5359 Contains:

Qty.	Cat. No.	Description	Qty.	Cat. No.	Description
4	05-74-0685	Socket Head Screw	1	42-52-0065	Dust Cap
2	05-74-0695	Socket Head Screw	1	42-76-0275	Collar
2	05-74-0697	Screw	2	42-96-0170	Bearing Cup
4	05-74-0705	Socket Head Screw	1	43-44-0375	Gasket
1	22-18-0942	Brush Service Kit (2)	1	43-87-0080	Isolation Block
1	34-40-0130	O-Ring	1	44-76-0285	Strain Relief
1	34-40-0132	O-Ring	1	44-90-0375	Snap Ring
1	34-40-4451	O-Ring	1	44-90-4415	Retaining Ring
1	34-40-4452	O-Ring	1	45-06-0215	Felt Washer
1	34-40-4454	O-Ring	2	45-30-0220	Slug
1	34-40-4456	O-Ring	2	45-88-1180	Washers
1	34-40-4459	O-Ring	1	49-08-4250	Type "P" Grease (1.5 oz.)
			1	49-08-4255	Type "Q" Grease (1.5 oz.)

Type "P" Grease (Cat. No. 49-08-4250)


1. Place 1/2 oz. at needle bearing / splined retainer area of gearcase (200).
2. Grease assembled wobble shaft (211) with 1/2 oz. of grease.
3. Place 1/8 oz. in armature pinion / intermediate shaft assembly (420) cavity.
4. Place 1/4 oz. of grease in wobble shaft drive gear cavity of crankcase (206).
5. Grease clutch (235) and clutch springs (233) on spindle (232) with 1/8 oz. of grease.

NOTE: Total amount used; 1 1/2 oz. (one complete tube)

Type "Q" Grease (Cat. No. 49-08-4255)

1. Coat the spindle (232) inside and out.
2. Coat all parts assembled on or in spindle except for clutch.
3. Coat piston (223) (inside and out), ram (222), wrist pin (224) and wrist pin washers (225). DO NOT coat the flat face of the ram.

NOTE: Total amount used; 3/4 oz. (1/2 of a full tube)




Torque (in lb.)	Description	Thread Locking Sealant
22	Motor/armature bolts (2)	None
22	Motor housing bolts (4)	None
9	Cord Clamp screws (2)	None
85	Anti-vibration post (1)	None
10	Handle screws (3)	None
16	Motor cover screws (4)	None
50	Spindle retaining bolts (2)	Blue
22-26	Gearcase screws (4)	None

SERVICE NOTES:

5359-21

1. To remove the gearcase (200), remove the retaining ring (1226), shift lever (261), plate (262), screws (1223), dust cap (1227), spacer (253), retainer (1226), sleeve (1214), holding ring (258), ball (256), support plate (257), and spring (255).
2. To remove the spindle (232), the two mounting bolts (275) must be removed with a metric allen wrench.
3. To remove the ram (222), tap the end of the striker (245) with a hammer, this frees the ram from the ram catcher. Ram may be found in piston rather than in ram catcher.
4. To remove the ram catcher (241), striker (245) and stop washer (249) from the spindle (232), remove the internal retaining ring (1218) with a small screwdriver by pushing on the ring through the two small ports in the spindle where the ring is visible. Push the ring in and towards the open end of the spindle, use service tool 61-10-0185 if necessary. Press out all internal parts.
5. To remove the rear thrust bearing (238), remove the spiral lock retaining ring (239) with a screwdriver and then remove the thrust bearing.
6. To remove the spindle gear/clutch (235), press the spindle gear against the disk springs (233) and remove the retaining ring (236) that fits into the gear counter bore. NOTE: Washer (264) is no longer being used with new spindle kit.
7. To remove the wobble shaft assembly (211), turn the shaft so the wobble finger of the wobble plate (218) leans toward the motor housing (100). Pull out on the shaft, tilt and wiggle it to get it to clear the crankcase (206).
8. To disassemble the wobble shaft assembly (211), press the reduction gear (219) off, remove all remaining parts.
9. To remove the bearing housing (415), try turning it by twisting on the lugs by hand. If it can be moved, continue to twist and pull to remove. If it will not move, it must be removed with an internal bearing puller.
10. To remove the handle (1100), push out dowel pin (7), open handle, remove snap ring (9) and washer (8) from the isolation block (1215), disconnect field leads under brush covers (102) and remove handle.
11. To remove motor, remove two screws (1222) from the top of the crankcase (206) and 4 screws (1221) from deep pockets in motor housing (100). Slide motor and motor housing out of crankcase.
12. To remove armature (406) from motor assembly, pull brushes (1201) off of commutator, push back brush holders (120) to provide clearance for insulating disc (410), slide bearing cover (130) from under armature ball bearing (409) and slide armature out.
13. When reassembling bearing housing (415) to crankcase (206) do not press it completely into place before the piston (223) and wobble shaft (211) are in place.
14. When reassembling the wobble shaft assembly (211), a clearance of .001 to .003 inch must be maintained between the reduction gear (219) and the inner race of the wobble plate (218). The ground side of the gear must face the wobble plate.
15. When reassembling the clutch be sure to stack the disk springs (233), as shown.
16. Thrust bearing (238) on the spindle (232) must be assembled as shown.
17. To push the internal retaining ring (1218) into the spindle (232) that retains the striker (245), stop washer (249) and ram catcher (241), use an old, used piston. The position of the ring can be visually checked by looking in the removal ports.
18. Check slugs (117 and 1216), replace if worn or missing.
19. Bearing Cup (1205) to be placed in motor cover (401) before assembly.



SEE BACK PAGE OF THIS
BULLETIN FOR ADDITIONAL
LUBRICATION AND
SERVICE NOTES

Service Notes – How to check the Static Slip of Clutch Mechanism

Note! Before checking the 'static' slip clutch torque a tool's clutch assembly must be dynamically slipped for a minimum of 5 seconds; to dynamically slip the clutch assembly requires drilling with the tool and 'binding a bit in the work' and slipping the clutch faces for 5+ SECONDS.

Parts required to check the Static Slip Clutch of the 5359-21 Rotary Hammer are as follows.


- Chuck Adapter # 48-03-3005
- ½" - 20 Hex Nut



Checking 'static' torque — 5359-21

- insert the 48-66-3005 chuck adapter w/ ½"-20 hex nut threaded onto the adapter
- turn / place shifting lever into the "hammer w/rotation mode"
- remove the four (4) screws from the motor cover
- remove the motor cover from the crankcase
- place hammer upside down in a machinist vise and tighten securely
- install ¾" socket onto ft-lbs torque wrench, which corresponds to hex of ½"-20 nut
- hold the armature firm by holding onto the fan
- turn torque wrench in a clockwise direction (as viewed from the bit end of the tool) while holding the armature fan, observe at what value the clutch slips
- 5359-21 — minimum slip torque 20 ft-lbs / maximum slip torque 36 ft-lbs

Service Notes – Disassembling the spindle – Assembling gear reduction shaft



Disassembling the spindle

- 1) remove spiral retaining ring [A]
- 2) remove
 - washer, o-ring, two (2) thin washers, thrust bearing & thick washer assembly [9]
 - retaining plate [8]
 - shift ring [7]
- 3) remove spindle gear [4] with the aide of a 90° external snap ring pliers and 61 30 0290 press fixture (see illustration & Product Support Bulletin #271 & #324) - compress the spindle gear against the belleville spring washers [1] while removing retaining ring [6]
- 4) remove flat washer [5]
- 5) remove four roller pins [3] and stop washer [2]
- 6) remove the four (4) steel balls [B] — compress the five (5) belleville spring washers [1] using 'pipe' press fixture to compress the assembly which will allow for removal of steel balls with the help of a magnetized tip screwdriver - press fixture can be made from 1 3/8" pipe (see illustration below) — failure to use press fixture can cause damage to top belleville spring washer or all belleville spring washers – requiring replacement before re-assembling



Press Fixture for removal of steel balls made from 1 3/8" Black or Galvanized Pipe cutting four [4] notches 90° from each other.

NOTE: Tools having spindle kit 38-50-0011 will not have flat washer #5.







fig 6 is X1 control washer see step 4 to determine if needed




control dimension X2 — 3.678" – 3.690"
 measured between face of 45-88-1183 washer [15] & face of flat washer [5], see illustration below
 add washer(s) [16] to the assembly as needed to obtain X2 control dimension
 most, if not all hammers will require control washer(s)

Assembling the reduction gear shaft

1) assemble the reduction gear shaft [8] with the following parts:

- washer [9]
- spring [10]
- coupling sleeve [11]
- wobble plate [1]

2) press reduction gear [2] onto reduction gear shaft [8] with the ground face toward wobble plate; a clearance of 0.001" to 0.003" **must be maintained** between the reduction gear [2] and inner race of the wobble plate [1]



3) lightly **grease entire length of reduction gear shaft [8]** and coupling sleeve [11] - lightly grease the thrust bearing assembly [3,4,&5] and place them onto the shaft

4) check for control dimension X1 of 3.954" to 3.980", if < 3.953" **add a single 45-88-8825 0.020" washer [6]** to the assembly


5) place o-ring [7] on shaft, it serves to hold thrust bearing assembly (and if needed the 0.020" washer) in place

6) assemble internal gear [12], offset gear [13] and 45 88-1182 washer [14] and 45-88-1183 washer [15] onto wobble shaft assembly

7) recess of 45-88-1183 washer [15] must face needle bearing / front of gear case

8) check for control dimension X2, if it does not fall between 3.678" – 3.690" chose a suitable washer(s) according to chart and add it (them) to the reduction gear shaft assembly - if required place control washer(s) [16] in front of 45 88-1182 washer [14], sandwiching it (them) between 45 88-1182 washer [14] and 45-88-1183 washer [15]

		control washer(s) [16] added to the assembly as listed		
		0.039" 45-88-1186	0.016" 45-88-1185	0.008" 45-88-1184
control dimension X2				
3.621	3.622	1	-	1
3.622	3.630	1	1	-
3.630	3.638	1	-	1
3.638	3.646	1	-	-
3.646	3.654	-	2	-
3.654	3.661	-	1	1
3.662	3.669	-	1	-
3.670	3.677	-	-	1
3.678	3.690	-	-	-





SERVICE PARTS LIST

SPECIFY CATALOG NO. AND SERIAL NO. WHEN ORDERING PARTS		REVISED BULLETIN
1-1/8" ROTARY HAMMER		54-24-5000
CATALOG NO. 5359-21	SERIAL NUMBER 409B (409A Series II)	WIRING INSTRUCTION 58-01-1861

EXAMPLE:
 00 0 Component Parts (Small #)
 Are Included When Ordering
 The Assembly (Large #).




FIG.	PART NO.	DESCRIPTION OF PART	QTY.
3	12-20-5359	SERVICE NAMEPLATE KIT	1
8	45-88-1245	WASHER	1
9	44-90-0340	SNAP RING (EXT.)	1
10	31-15-0257	CRANKCASE COVER	1
102	31-15-0255	BRUSH COVER	2
119	05-78-0745	TAPTITE SCREW	5
127	05-78-0715	SCREW	7
200	31-40-0042	GEARCASE	1
204	44-86-0625	SPLINED RETAINER	1
206	31-15-0307	CRANKCASE	1
208	45-88-8825	WASHER (ADD AS REQUIRED)	1
209	34-40-4440	O-RING	1
210	02-80-6025	THRUST BEARING SET	1
211	14-73-0247	WOBBLE SHAFT ASSEMBLY	1
212	36-66-3162	REDUCTION GEAR SHAFT	1
214	45-88-1250	WASHER	1
215	40-50-8897	SPRING	1
216	45-22-0302	COUPLING SLEEVE	1
★ 217	45-88-8414	WASHER	1
218	36-92-0747	WOBBLE PLATE	1
219	32-60-2622	REDUCTION GEAR	1
220	32-60-2157	OFFSET GEAR	1
221	32-60-2165	INTERNAL GEAR	1
222	44-82-0192	RAM	1
223	44-62-0157	PISTON	1
224	44-60-1405	WRIST PIN	1
225	45-88-1180	WASHER	2
226	44-90-4500	SHIFT RING	1
228	44-60-1485	PIN	1
★ 229	44-66-6055	RETAINING PLATE	1
232	38-50-0058	SDS SPINDLE	1
233	40-50-7977	BELLEVILLE SPRING	5
★ 234	45-88-7767	STOP WASHER	1
★ 235	32-10-0055	SPINDLE GEAR	1
236	40-50-8492	RETAINING RING (EXT.)	1
237	45-88-1255	WASHER	1
238	02-80-0150	THRUST BEARING	1
239	45-88-0775	RETAINING RING	1
241	44-82-0089	RAM CATCHER	1
243	42-76-0727	THRUST COLLAR	1
245	45-56-2537	STRIKER	1
248	45-88-1265	WASHER	1

FIG.	PART NO.	DESCRIPTION OF PART	QTY.
249	45-88-1264	STOP WASHER	1
251	02-50-2185	NEEDLE BEARING	2
253	31-86-0102	SPACER	1
255	40-50-8045	SPRING	1
256	02-02-0275	BALL	1
257	42-36-1755	SUPPORT PLATE	1
258	44-90-4285	HOLDING RING	1
259	45-88-1270	WASHER	2
261	44-10-0077	SHIFT LEVER	1
262	44-66-0101	PLATE	1
265	44-96-0101	ROLLER	4
266	02-02-0110	BALL	4
267	05-77-0030	BOLT	1
268	45-88-1182	WASHER	1
269	45-88-1183	WASHER	1
270	44-90-0115	RING	1
271	45-88-1184	WASHER	1
272	45-88-1185	WASHER	1
273	45-88-1186	WASHER	1
275	05-74-0700	SCREW	2
276	05-74-0717	SCREW	2
415	45-60-0511	BEARING ASSY	1
420	36-66-4267	INTERMEDIATE GEAR SET	1
426	45-88-1170	RETAINING RING	1
427	45-88-1280	WASHER	1
600	43-46-0172	DEPTH GAGE (NOT SHOWN)	1
701	49-15-5300	SIDE HANDLE (NOT SHOWN)	1
★ 1100	31-44-0011	HANDLE SET	1
1204	34-40-4454	O-RING	1
1207	43-44-0375	GASKET	1
1209	34-40-5359	O-RING	1
1210	34-40-4452	O-RING	1
1211	34-40-4451	O-RING	1
1212	34-40-4459	O-RING	1
1213	34-40-4456	O-RING	1
1214	42-76-0275	COLLAR	1
1215	43-87-0080	ISOLATION BLOCK	1
1218	44-90-4415	RETAINING RING	1
1219	34-40-0130	O-RING	1
1220	05-74-0685	SOCKET HEAD SCREW	4
1222	05-74-0695	SOCKET HEAD SCREW	2
1223	05-74-0697	SCREW	2
1224	34-40-0132	O-RING	1
1225	45-06-0215	FELT WASHER	1
1226	44-90-0375	SNAP RING	1
★ 1227	42-52-0065	DUST CAP	1
1228	38-50-0011	SDS SPINDLE KIT	1

Type "P" Grease (Cat. No. 49-08-4250)


1. Place 1/2 oz. at needle bearing / splined retainer area of gearcase (200).
2. Grease assembled wobble shaft (211) with 1/2 oz. of grease.
3. Place 1/8 oz. in armature pinion / intermediate shaft assembly (420) cavity.
4. Place 1/4 oz. of grease in wobble shaft drive gear cavity of crankcase (206).
5. Grease clutch (235) and clutch springs (233) on spindle (232) with 1/8 oz. of grease.

NOTE: Total amount used; 1 1/2 oz. (one complete tube)

Type "Q" Grease (Cat. No. 49-08-4255)

1. Coat the spindle (232) inside and out.
2. Coat all parts assembled on or in spindle except for clutch.
3. Coat piston (223) (inside and out), ram (222), wrist pin (224) and wrist pin washers (225). DO NOT coat the flat face of the ram.

NOTE: Total amount used; 3/4 oz. (1/2 of a full tube)




Torque (in lb.)	Description	Thread Locking Sealant
22	Motor/armature bolts (2)	None
22	Motor housing bolts (4)	None
9	Cord Clamp screws (2)	None
85	Anti-vibration post (1)	None
10	Handle screws (3)	None
16	Motor cover screws (4)	None
50	Spindle retaining bolts (2)	Blue
22-26	Gearcase screws (4)	None

SERVICE NOTES:

5359-21

1. To remove the gearcase (200), remove the retaining ring (1226), shift lever (261), plate (262), screws (1223), dust cap (1227), spacer (253), retainer (1226), sleeve (1214), holding ring (258), ball (256), support plate (257), and spring (255).
2. To remove spindle (232), the two mounting bolts (275) must be removed with a 4 mm allen wrench.
3. To remove ram (222) from ram catcher, tap the end of striker (245) with a screwdriver.
4. To remove ram catcher (241), striker (245) and stop washer (249) from the spindle (232), remove the internal retaining ring (1218) with a small screwdriver by pushing on the ring through the two small ports in the spindle where the ring is visible. Push the ring in and towards the open end of the spindle.
5. To remove spindle gear/clutch (235), press the spindle gear against disk springs (233) and remove the retaining ring (236).
6. To remove wobble shaft assembly (211), turn the wobble shaft so the wobble finger of plate (218) leans toward the gearcase (200). Pull out on the shaft, tilt and pull it to get it to clear the crankcase (206).
7. To disassemble wobble shaft assembly (211), press reduction gear (219) off, remove all remaining parts.
8. To remove bearing housing (415), try turning/twisting on the lugs by hand. If it will not move, use a large flat blade screwdriver.
9. To remove the handle (1100), push out dowel pin (7), open handle, remove snap ring (9) and washer (8) from the isolation block (1215), disconnect field leads and remove handle.
10. To remove motor, remove two screws (1222) from the top of the crankcase (206) and 4 screws (1221). Disconnect field leads and slide motor and motor housing out of crankcase.
11. To remove armature (406) from motor assembly, pull brushes (1201) off of commutator, push back brush holders (120) to provide clearance for insulating disc (410), slide bearing cover (130) from under insulating disc (410) and slide armature out.
12. When reassembling bearing housing (415) to crankcase (206) do not press it completely into place before the piston (223) and wobble shaft (211) are in place.
13. When reassembling the wobble shaft assembly (211), a clearance of .001 to .003 inch must be maintained between the reduction gear (219) and the inner race of the wobble plate (218). The ground side of the gear must face the wobble plate.
14. When reassembling the clutch be sure to stack the disk springs (233), as shown. (Refer to Note 18)
15. To install internal retaining ring (1218) into spindle (232), use an old, used piston.
16. Check slugs (117 and 1216), replace if worn or missing.
17. Bearing Cup (1205) to be placed in motor cover (401) before assembly.



**SEE BACK PAGE OF THIS BULLETIN
FOR ADDITIONAL LUBRICATION
AND SERVICE NOTES**

Service Notes – How to check the Static Slip of Clutch Mechanism

Note! Before checking the ‘static’ slip clutch torque a tool’s clutch assembly must be dynamically slipped for a minimum of 5 seconds; to dynamically slip the clutch assembly requires drilling with the tool and ‘binding a bit in the work’ and slipping the clutch faces for 5+ SECONDS.

Parts required to check the Static Slip Clutch of the 5359-21 Rotary Hammer are as follows.


- Chuck Adapter # 48-03-3005
- ½” - 20 Hex Nut



Checking ‘static’ torque — 5359-21

- insert the 48-66-3005 chuck adapter w/ ½”-20 hex nut threaded onto the adapter
- turn / place shifting lever into the “hammer w/rotation mode”
- remove the four (4) screws from the motor cover
- remove the motor cover from the crankcase
- place hammer upside down in a machinist vise and tighten securely
- install ¾” socket onto ft-lbs torque wrench, which corresponds to hex of ½”-20 nut
- hold the armature firm by holding onto the fan
- turn torque wrench in a clockwise direction (as viewed from the bit end of the tool) while holding the armature fan, observe at what value the clutch slips
- 5359-21 — minimum slip torque 20 ft-lbs / maximum slip torque 36 ft-lbs

Service Notes – Disassembling the spindle – Assembling gear reduction shaft




Disassembling the spindle



- 1) remove spiral retaining ring [A]
- 2) remove
 - washer, o-ring, two (2) thin washers, thrust bearing & thick washer assembly [9]
 - retaining plate [8]
 - shift ring [7]
- 3) remove spindle gear [4] with the aide of a 90° external snap ring pliers and 61 30 0290 press fixture (see illustration & Product Support Bulletin #271 & #324) - compress the spindle gear against the belleville spring washers [1] while removing retaining ring [6]
- 4) remove flat washer [5]
- 5) remove four roller pins [3] and stop washer [2]
- 6) remove the four (4) steel balls [B] — compress the five (5) belleville spring washers [1] using ‘pipe’ press fixture to compress the assembly which will allow for removal of steel balls with the help of a magnetized tip screwdriver - press fixture can be made from 1 3/8” pipe (see illustration below) — failure to use press fixture can cause damage to top belleville spring washer or all belleville spring washers – requiring replacement before re-assembling



Press Fixture for removal of steel balls made from 1 3/8” Black or Galvanized Pipe cutting four [4] notches 90° from each other.


NOTE: Tools having spindle kit 38-50-0011 will not have flat washer #5.





control dimension X2 — 3.678" – 3.690"
 measured between face of 45-88-1183 washer [15] & face of flat washer [5], see illustration below
 add washer(s) [16] to the assembly as needed to obtain X2 control dimension
 most, if not all hammers will require control washer(s)

Assembling the reduction gear shaft

- 1) assemble the reduction gear shaft [8] with the following parts:
 - washer [9]
 - spring [10]
 - coupling sleeve [11]
 - wobble plate [1]
- 2) press reduction gear [2] onto reduction gear shaft [8] with the ground face toward wobble plate; a clearance of 0.001" to 0.003" **must be maintained** between the reduction gear [2] and inner race of the wobble plate [1]
 
- 3) lightly **grease entire length of reduction gear shaft [8]** and coupling sleeve [11] - lightly grease the thrust bearing assembly [3,4,&5] and place them onto the shaft
- 4) check for control dimension X1 of 3.954" to 3.980", if < 3.953" **add a single 45-88-8825 0.020" washer [6]** to the assembly
- 5) place o-ring [7] on shaft, it serves to hold thrust bearing assembly (and if needed the 0.020" washer) in place
- 6) assemble internal gear [12], offset gear [13] and 45 88-1182 washer [14] and 45-88-1183 washer [15] onto wobble shaft assembly
- 7) recess of 45-88-1183 washer [15] must face needle bearing / front of gear case
- 8) check for control dimension **X2**, if it does not fall between 3.678" – 3.690" chose a suitable washer(s) according to chart and add it (them) to the reduction gear shaft assembly - if required place control washer(s) [16] in front of 45 88-1182 washer [14], sandwiching it (them) between 45 88-1182 washer [14] and 45-88-1183 washer [15]

		control washer(s) [16] added to the assembly as listed		
		0.039" 45-88-1186	0.016" 45-88-1185	0.008" 45-88-1184
control dimension X2				
3.621	3.622	1	-	1
3.622	3.630	1	1	-
3.630	3.638	1	-	1
3.638	3.646	1	-	-
3.646	3.654	-	2	-
3.654	3.661	-	1	1
3.662	3.669	-	1	-
3.670	3.677	-	-	1
3.678	3.690	-	-	-

