



General Guidelines

- It is the user's responsibility to read and follow all instructions.
- Keep these instructions with the product at all times and review before each use.
- It is the responsibility of this product's owner to furnish the instructions to any person that borrows or purchases the product.
- Inspect the product before use to ensure all pieces are included, are in safe working order, and free of defects or damage.
- Never modify this product in any way.
- Never use this product in a way for which it is not intended.
- All circumstances cannot be addressed in these instructions. Please use common sense and practice general safety measures when using this product.
- Parts and/or instructions are subject to change without notice.

Safety

- Do not exceed the listed weight capacity.
- Do not exceed the recommended tire width.
- Only use on a level, relatively even surface. Remove all small hard objects such as pebbles or stones, as they can act like small ball bearings and create a poor surface for use. Dirt, sand, or grass are acceptable.
- Make sure there is adequate room for loading and unloading your vehicle and there are no obstructions.
- It is recommended to use a spotter to help safely guide your vehicle up the ramps. Any bystanders should stay a safe distance away from the vehicle while loading or unloading.
- Only use attachments and/or adapters supplied by the manufacturer. Do not use jacks or other lifting devices on the surface of the ramp.
- Failure to follow these guidelines may result in a void warranty, property damage, and/or serious personal injury.

Model #	Application	Max Tire Width	Weight Capacity
RR-FS-10	Car	8"	1,500 lbs per ramp
RR-FS	Car	12"	1,500 lbs per ramp
RR-FS-16-SC	Car	14"	1,500 lbs per ramp
RR-FS-MC	Motorcycle	8"	750 lbs per ramp

Loading the Vehicle

1. Place the FlatStoppers in line with the front and rear tires. Use a tape measure to ensure they are spaced equidistant from each other the entire length.
2. Proceed slowly and cautiously. With a steady, even throttle, drive up the ramps with all tires centered on the ramps, wheels pointed straight ahead.
3. Do not drive up the ramps with any part of the tire overlapping or extending beyond the edge of the FlatStopper. Never accelerate or apply brakes suddenly.
4. Once the vehicle reaches the top of the ramps, you will feel the tires settle into the tire cradles. Gently apply brakes if necessary to stop the vehicle from moving any farther.
5. When the tires are resting in the FlatStoppers, place the vehicle in park (or in reverse gear for manual transmissions). Set the emergency brake.



Unloading the Vehicle

1. Make sure there is adequate room and no obstructions behind the vehicle.
2. Release the emergency brake and shift the vehicle into reverse.
3. Proceed slowly and cautiously, keeping tires straight. NEVER drive forward over the front of the FlatStoppers.

Motorcycle Model

Separate the ramps and remove the kickstand support before use. Position the kickstand support with the coated side up, underneath the motorcycle kickstand.

This model may be used with certain motorcycle dollies. Position the FlatStoppers in the dolly tray and place the kickstand support in the kickstand tray. To help prevent sliding, use double-sided tape or hook-and-loop tabs (not included) at the sides of the FlatStoppers, connecting them to the sides of the motorcycle dolly.

