

Primer Masking	
1	 <p>Clean Clean part with soap and water, followed by a VOC compliant surface cleaner.</p>
2	 <p>Back Masking Back mask primer application area using tape and paper.</p>
3	 <p>Overspray Protection Apply plastic film to remaining exposed areas, cut out repair area.</p>
4	 <p>Seal Edge Seal edge of masking film using wide width masking tape.</p>

Product List	
<p>3M™ Car Wash Soap Concentrate, 1 gallon, PN 38377</p>	
<p>3M™ All Purpose Cleaner and Degreaser Concentrate, 1 gallon, PN 38350</p>	
<p>3M™ Scotchblok™ Masking Paper, 18 in. x 750 ft., PN 06718</p>	
<p>3M™ Overspray Protective Sheeting, 12 ft. x 400 ft. roll, PN 06727; 16 ft. x 350 ft. roll, PN 06728; 20 ft. x 250 ft. roll, PN 06742</p>	
<p>Scotch® Performance Green Masking Tape 233+, 18mm width (.71 in.), PN 26334; 36mm width (1.41 in.), PN 26338; 48mm width (1.9 in.), PN 26340</p>	

Think About Your Health	
<p>3M™ E-A-R™ Skull Screws™ Ear Plug, PN P1300</p>	
<p>3M™ Half Facepiece Respirator, PN 07182</p>	
<p>3M™ Lexa™ Protective Eyewear, PN 15200</p>	