



VacPan Automatic Dustpan Kit for RV Central Vacuum Systems

VacPan Installation Instructions

1. VacPan requires a minimum 2 – ¼” toe kick height.
2. Once the VacPan location is determined, cut 6 – ¾” long x 1 ¾” high slot in the cabinet toe kick to accept the VacPan.
3. Run vacuum tube piping and low-voltage wire from the main piping line to the VacPan location.
4. Access for final piping connections must be made. From below, cut an access hole underneath the cabinet, positioned so that final piping connections can be made through the access hole. Allow for ½” vertical play in vacuum tube piping at VacPan location so that final piping connections can be made.
5. Attach low-voltage wire to the VacPan terminal connections marked “low-voltage only.”
6. Prior to final installation, check for an airtight seal between the VacPan and elbow. Teflon tape may be used if required.
7. Slide VacPan into mounting slot and secure to toe kick using the two #6 screws provided.
8. Reach through access hole and make final piping connections.

VacPan Operating Instructions

Simply switch on the VacPan automatic dustpan by pushing the raised tab with your foot. Switching on the VacPan activates your central vacuum. Brush dirt and debris toward the VacPan. When cleaning is complete, switch off the VacPan and the central vacuum system by pushing the raised tab with your foot.