



**CUT** – Measure and cut desired length of hose at 90° angle.



**INSTALL** – Slide spiral fitting and nut onto hose. Push hose onto fitting until hose reaches threads.



**TIGHTEN** – Tighten fitting nut until snug. Slide bend restrictor up and snap onto nut.