

CUSTOM LENGTHS



CUT – Measure and cut desired length of hose at 90° angle.



INSTALL – Slide spiral fitting and nut onto hose. Push hose onto fitting until hose reaches threads.



TIGHTEN – Tighten fitting nut until snug. Slide bend restrictor up and snap onto nut.

FIELD REPAIRABLE



CUT – Cut damaged portion of hose at 90° angle. Slide fitting nuts onto hose.



INSTALL – Slide hose onto fitting until hose reaches threads.



TIGHTEN – Tighten fitting nuts until snug.