

NO EDGE BLENDING TAPE

The fast and sure way to mask panel edges and swage lines. Eliminates unnecessary re-work due to unwanted hard painted edges.

No Edge Blending Tape

PART NO:	SIZE:	UNITS:
1012.2005	20mm x 5m	10
1012.2025	20mm x 25m	1



FEATURES

The fast and sure way to mask swage lines and panel edges to avoid hard paint edges. Eliminates unnecessary rework due to unwanted paint edges.

BENEFITS

- Seamless blending from old to new paintwork
- Ideal for body swage lines
- No paint edges
- Non stretch
- Just one size for every occasion
- More absorbent
- Available in a multiple roll dispensing box



HOW TO USE THIS PRODUCT:

No Edge Blending Tape



1. Choose the swage line to blend up to.



2. Apply the tape onto the panel next to the swage line ensuring that the tape edge is level with the panel bend. Then mask the rest of the vehicle.



3. After masking, spray the panel as normal.



4. Ensure that the paintwork is dry before de-masking.



5. Remove the masking material exposing a seamless transition.



6. This will now result in a seamless transition between old and new paintwork along the swage line edge - avoiding any unnecessary rework.

Discover other tapes on our website.