



RM69

Brake Tubing Reamer

THE RIGHT
WAY TO
PREP TUBING



Prepare Tubing For Flaring In Seconds

- Deburr 3/16", 1/4", 5/16", and 3/8" tubing
- Advanced six-flute design produces smoother, cleaner tubing
- Eliminates additional labor due to bad flares
- Reduces wear on flaring tool punches



After cutting, tubing needs deburring



Deburred tubing is smooth, ready for flaring