


PARTS BREAKDOWN



Parts List

Index No.	Part No.	Description	Qty	Index No.	Part No.	Description	Qty
1	EUROHVT1-01	Air Cap Set	1	15A	EUROHVT1-15A	E Ring	2
2	EUROHVT1-02	Fluid Nozzle (1.0mm)	1	15B	EUROHVT1-15B	Trigger Pin	1
3	EUROHVT1-03	Needle Valve Packing	1	16A	EUROHVT1-16A	Fluid Actuator Pin	1
4	EUROHVT1-04	Needle Valve Packing Seat	1	17	EUROHVT1-17	Trigger	1
5	EUROHVT1-05	Spreader Adjusting Valve Set	1	18	EUROHVT1-18	Air Valve Spring	1
8	EUROHVT1-08	Fluid Adjusting Screw	1	19	EUROHVT1-19	Air Valve	1
9	EUROHVT1-09	Needle Valve Spring	1	20	EUROHVT1-20	Air Valve Seat Set	1
10	EUROHVT1-10	Fluid Needle Set	1	20A	EUROHVT1-20A	Air Valve Seat	1
11	EUROHVT1-11	0.6L Cup	1	20B	EUROHVT1-20B	Air Valve Packing	1
12	EUROHVT1-12	Gun Body	1	20C	EUROHVT1-20C	Valve Body	1
13	EUROHVT1-13	Air Hose Joint	1	20D	EUROHVT1-20D	O-Ring	1
14	EUROHVT1-14	Tap	1	22	EUROHVT1-22	250ml Cup	1