


PARTS BREAKDOWN



Parts List

Index No.	Part No.	Description	Qty	Index No.	Part No.	Description	Qty
1	1423-01*	Nosepiece 3/16" (4.8mm)	1	15	1423-15	Aluminum Body	1
2	1423-02	Outer Cylinder	1	16	1423-16	Screw	4
3	1423-03	Lock Nut	1	17	1423-17	Screw Washer	4
4	1423-04	Jaw Carrier	1	18	1423-18	Stainless Washer	4
5	1423-05*	Jaw	3	19	1423-19	Nut	4
6	1423-06*	Jaw Pusher	1	20	1423-20	Pin	2
7	1423-07*	Spring	1	21	1423-21	Washer	8
8	1423-08	Pulling Bar	1	22	1423-22	Links	4
9	1423-09	Grip	2	23	1423-23	Metal Fixture	2
10	1423-10	Handle	2	24	1423-24	Core Collector Base	1
11	1423-11*	Nosepiece 5/32" (4.0mm)	1	25	1423-25	Core Collector Bottle	1
12	1423-12*	Nosepiece 1/8" (3.2mm)	1	26	1423-26	Wrench	1
14	1423-14*	Nosepiece 1/4" (6.4mm)	2				

Please note the parts with asterisk (*) wear down and are available for replacement.