


PARTS BREAKDOWN



Parts List

Index	Part No.	Description	Qty
1	4008-A01	Air Cap Ring	1
2	4008-A02	Air Cap	1
3	4008-A03	Nozzle	2
4	4008-A04	Nozzle Packing Gasket	1
5	4008-A05	Baffle	1
6	4008-A06	Trigger Stud	1
7	4008-A07	Needle Packing	1
8	4008-A08	Needle Packing Screw	1
9	4008-A09	Pattern Adj. Valve Set	1
10	4008-A10	Packing	1
11	4008-A11	Bolt	1
12	4008-A12	Needle Sleeve	1
13	4008-A13	Needle	1
14	4008-A14	Spring	1
15	4008-A15	Fluid Adj. Screw	1
16	4008-A16	Air Valve Packing Screw	1
17	4008-A17	Air Valve Packing	2
18	4008-A18	Air Valve Seat	1
19	4008-A19	Gasket	1
20	4008-A20	Air Valve	1
21	4008-A21	Spring	1
22	4008-A22	Trigger	1
23	4008-A23	Fluid Connector	1
24	4008-A24	Paint Cup Set	1
25	4008-A25	Gun Body	1
26	4008-A26	Air Connector	1
27	4008-A27	Air Adj. Valve Set	1