



<u>Parts No.</u>	<u>Description</u>	<u>Q'ty</u>
4531-01	Handle	1
4531-02	Trigger	1
4531-03	Cylinder	1
4531-04	Front / Rear Cap	2
4531-05	Hold Down Plate	1
4531-06	Washer	1
4531-07	Fulcrum Pin	2
4531-08	Snap Ring	2
4531-09	Release Lever	1
4531-10	Friction Key	1
4531-11	Push Plate (Metal)	1
4531-12	Release Lever Spring	1
4531-13	Friction Spring	1
4531-14	Friction Rod	1
4531-15	8mm Push Plate Nut	2
4531-16	Knob Nut	1
4531-17	Knob	1
4531-18	Nozzle	1
4531-19	Push Plate (Plastic)	1