

NIGHTSTICK®

Tough, Durable, Affordable™

Safety Light / Flashlight

Each Safety Light combines a full-size flashlight and a floodlight/flashing safety light in a compact, light-weight package. Two body mounted switches control the lighting functions. The top button powers the tight-beam, long-throw 150 lumens flashlight in either momentary or constant-on mode. The bottom button controls the safety light array with options for constant-on or flashing/alternating (depending on model) operation. Power comes from 4 – AA batteries (included).



150 Flashlight Lumens

120 Safety Light Lumens

- Constant-on or flashing safety light
- Long-throw flashlight beam
- Long run-times
- Powered by 4 AA batteries (included)



Momentary/Constant Flashlight



Dual-Color Constant



Dual-Color Alternating



NSP-1170

SAFETY LIGHT series

NIGHTSTICK®

Tough, Durable, Affordable™

High-efficiency deep parabolic reflector

FEATURES

- Flashlight with CREE® LED technology – 50,000 + hours LED life
- Floodlight/safety light with premium LED technology – 35,000 + hours LED life
- Momentary or constant-on white flashlight (all models)
- High/low-brightness single color floodlight or flashing safety light (1162, 1164, 1166 & 1168)
- Dual-color floodlight or alternating safety light (1170, 1172, 1176, 1178 & 1180)
- White floodlight or flashing amber safety light (1174)
- Sharp focused beam flashlight
- Wide-beam unfocused floodlight/safety light
- Engineered polymer housing
- Non-slip grip
- Comfortable oval shape
- Soft touch finish
- Dual body switches
- Water resistant
- Impact & chemical resistant
- Powered by 4 premium AA alkaline batteries (included)
- Limited 1 Year Warranty*

SPECIFICATIONS

- Lumens: flashlight-150, floodlight/safety light-120
- Run-time: flashlight-10 hrs, floodlight/safety light-model dependent (see chart)
- Water rating: IP-X4 water resistant
- Drop rating: 2 meters
- Length: 10.9in, width: 1.3 x .09in, weight: 8.2oz

INCLUDED

- Safetylight/flashlight
- 4 Premium AA alkaline batteries
- Magnetic clip
- Lanyard ring



NSP-1162



Momentary or Constant-on Flashlight
Single-Color Constant High
Single-Color Constant Low
Single-Color Flashing

NSP-1164



Momentary or Constant-on Flashlight
Single-Color Constant High
Single-Color Constant Low
Single-Color Flashing

NSP-1166



Momentary or Constant-on Flashlight
Single-Color Constant High
Single-Color Constant Low
Single-Color Flashing

NSP-1168



Momentary or Constant-on Flashlight
Single-Color Constant High
Single-Color Constant Low
Single-Color Flashing

NSP-1172



Momentary or Constant-on Flashlight
Dual-Color Constant
Dual-Color Alternating

NSP-1174



Momentary or Constant-on Flashlight
White Constant
Amber Flashing

NSP-1176



Momentary or Constant-on Flashlight
Dual-Color Constant
Dual-Color Alternating

NSP-1178



Momentary or Constant-on Flashlight
Dual-Color Constant
Dual-Color Alternating

NSP-1180



Momentary or Constant-on Flashlight
Dual-Color Constant
Dual-Color Alternating

ACCESSORIES/KITS

MODELS					
Model	Safety Light Color	Safety Light Functions	Constant Safety Light Run-Time Hours	Flashing Safety Light Run-Time Hours	UPC 0 17398
NSP-1162	Red	Constant - half power - flashing	4 full power 8 half power	16	80102 7
NSP-1164	Blue	Constant - half power - flashing	4 full power 8 half power	16	80103 4
NSP-1166	White	Constant - half power - flashing	4 full power 8 half power	16	80104 1
NSP-1168	Amber	Constant - half power - flashing	4 full power 8 half power	16	80105 8
NSP-1170	Blue & Red	Constant or alternating flash	4 full power	16 alternating flasher	80106 5
NSP-1172	White & Red	Constant or alternating flash	4 full power	16 alternating flasher	80107 2
NSP-1174	White & Amber	Constant white - flashing amber	30 led floodlight = 8	24	80119 5
NSP-1174-K01	White & Amber	Constant white - flashing amber	30 led floodlight = 8	24	80125 6
NSP-1176	White & Amber	Constant or alternating flash	4 full power	16 alternating flasher	80114 0
NSP-1178	White & Blue	Constant or alternating flash	4 full power	16 alternating flasher	80138 6
NSP-1180	Amber & Green	Constant or alternating flash	4 constant amber / green	16 alternating flasher	80207 9



Safety cones
Part #: 1260-RCONE
UPC: 0 17398 80085 3
Part #: 1260-YCONE
UPC: 0 17398 80086 0



Large magnetic base
Part #: 1160-BASE
UPC: 0 17398 80026 6



Magnetic stand
Part #: 1160-MSTAND
UPC: 0 17398 80101 0



Magnetic clip
Part #: 1160-MAGNET
UPC: 0 17398 80084 6



Safety Light Kit
NSP-1174-K01
UPC: 0 17398 80125 6



Impact bumpers
Part #: 1260-BUMPERS
UPC: 0 17398 80135 5

*Limited 1 Year Warranty Product is warranted to be free from defects in workmanship and materials to the original purchaser for one (1) year from the date of purchase, and includes the LEDs, housing, lenses, electronics, switches, rechargeable batteries and chargers. Disposable non-rechargeable batteries are excluded from this warranty. Normal wear and failures which are caused by accidents, misuse, abuse, faulty installation and lightning damage are also excluded.



INS-116X-12


Safety Light Operating Instructions Models NSP-1162 / 1164 / 1166 / 1168 / 1170 / 1172 / 1174 / 1176 / 1178 / 1180 / 1182

CAUTION: DO NOT use in explosive atmospheres, near flammable liquids, or where explosion proof lamps are required
DO NOT use in the proximity of vehicles or equipment when there is a risk of flammable liquids coming into contact with the hand-lamp

CAUTION: For Light Duty Use Only

WARNING: NOT FOR USE ABOVE HAZARDOUS LOCATIONS

Thank you for purchasing this Nightstick flashlight. **Save these instructions.** Please read these instructions before using your flashlight.



ALL MODELS

INSTALLING OR REPLACING BATTERIES

1. Remove the battery cover on the lower back of the light.
2. Install the 4 AA alkaline batteries and align the battery + / - with the light housing. For best performance and run-time always use premium quality AA alkaline batteries.
3. Replace the battery cover.

BATTERY NOTES

- Batteries may lose power when stored for long periods.
- Alkaline batteries can leak and cause corrosion if stored for long periods. Always remove batteries if the light will be unused for extended periods.
- Batteries should be stored between 68-78°F (20-25°C)

ATTACHING THE LANYARD RING

The lanyard ring is made of pliable material. Loop a suitable lanyard through the rectangular lanyard attachment hole. Slide the flashlight into the ring. The ring will conform to the light body and hold the light.

REMOVABLE MAGNETIC CLIP

Snap the magnetic clip onto the light body. Attach to any steel surface. The light can rotate inside the clip.

SAFETY

CAUTION BRIGHT LED RADIATION: AVOID DIRECT EYE EXPOSURE. The light is a Class 2 LED product per IEC 60825-1 Edition 1.2.2001.

- Do not use this FLASHLIGHT in explosive or hazardous areas.

OPERATING THE LIGHT

All models have two body switches that control the flashlight and the safety light. The flashlight and safety light functions can be operated independently and together.

Models 1162 / 1164 / 1166 / 1168

Safety Light

1162-red, 1164 -blue, 1166-white, 1168-amber

1. The upper switch controls the flashlight. Lightly press the switch for momentary flashlight operation. For constant on, press the switch until it clicks. Press again for off.
2. The lower switch controls the safety light. Press for full power.
3. Press again for half-power. Press again to activate flashing safety light. Press again for off.

Flashlight
Momentary or constant



Safety light

Models 1170 / 1172 / 1176 / 1178 / 1180 / 1182

Safety Light

1170-blue/red, 1172-white/red, 1176-white/amber, 1178-white/blue, 1180-amber/green, 1182-blue/green

1. The upper switch controls the flashlight. Lightly press the switch for momentary flashlight operation. For constant on, press the switch until it clicks. Press again for off.
2. The lower switch controls the safety light. Press for constant (non-flashing) safety light. Press again to activate alternating flasher. Press again for off.

Model 1174

Safety Light

1174-amber

1. The upper switch controls the flashlight. Lightly press the switch for momentary flashlight operation. For constant on, press the switch until it clicks. Press again for off.
2. The lower switch controls the flood /safety light. Press for floodlight. Press again to activate flashing amber light. Press again for off.

WARRANTY

Limited Lifetime Warranty

Product is warranted to be free from defects in workmanship and materials for the lifetime of the original owner. Includes the housing, lenses, electronics and switches. Batteries, normal wear and abuse are excluded.

Not Covered

Consequential damages, incidental damages or incidental expenses, including damage to property. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, which may vary from state to state.

Warranty Claims - USA

Contact Bayco for USA warranty claims. Call or email and Bayco Customer Service will provide a Return Goods Authorization (RGA) to facilitate rapid warranty action. After receiving the RGA, send the product (shipping prepaid) to BAYCO. Include a dated proof of purchase and a brief description of the defect with your name, address and phone number. Your product will either be repaired or replaced at the option of Bayco and returned as soon as practical, but no later than 45 days after being received by Bayco.

Warranty questions and international claims

If you live outside the USA or have questions about this warranty or an inquiry about other Bayco products contact BAYCO.

BAYCO PRODUCTS LIMITED 1-YEAR WARRANTY

WARRANTY

Bayco Products, Inc. warrants this product to be free from defects in workmanship and materials to the original purchaser for one (1) year from the date of purchase, and includes the LEDs, housing, lenses, electronics, switches, rechargeable batteries and chargers. Bulbs (other than LEDs) are covered for ninety (90) days from the date of purchase. Disposable non-rechargeable batteries are excluded from this warranty. Normal wear and failures which are caused by accidents, misuse, abuse, faulty installation and lightning damage are also excluded.

Consequential damages, incidental damages or incidental expenses, including damage to property are also not covered under this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, which may vary from state to state.

IN NO EVENT WILL BAYCO PRODUCTS, INC. OR ITS AFFILIATES OR SUPPLIERS BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY KIND REGARDLESS OF THE FORM OF ACTION, WHETHER IN CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY OR OTHERWISE. THE TOTAL CUMULATIVE LIABILITY TO CUSTOMER, FROM ALL CAUSES OF ACTION AND ALL THEORIES OF LIABILITY, WILL BE LIMITED TO AND WILL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT PAID BY CUSTOMER.

If this product is used for rental purposes, the warranty term is reduced to 90 days from the date of purchase.

WARRANTY CLAIMS – USA

Return the product to the place of purchase for all warranty related issues. If this is not possible, contact Bayco Customer Service for a Return Goods Authorization (RGA). Do not return this product to Bayco without first receiving an RGA Number from Bayco Customer Service. When returning the product, the RGA Number must be written on the outside of the shipping box.

WARRANTY CLAIMS – OUTSIDE OF USA

Return the product to the place where purchased for all warranty related issues.

EXTENT OF COVERED WARRANTY WORK

Bayco will repair or replace this product at our option. If it is determined that the warranty is no longer in effect, Bayco will contact you with a repair estimate before beginning any work.

WARRANTY QUESTIONS

If you have any questions about this warranty or any other Bayco product inquiries, please contact Bayco Customer Service.

Nightstick Product Battery Replacement Information

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
FDL-300R	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
FDL-300R-K01	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
MT-100	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-100BL	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-100CTD	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-100R	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-110	Unscrew Tail Cap	None	1 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-120	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-130	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-140B	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-200	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-210	Unscrew Tail Cap	None	1 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-220	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-230	Unscrew Tail Cap	None	1 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MT-90	Unscrew Tail Cap	None	1 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MTU-106	Unscrew Tail Cap	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
MTU-136	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1102A	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1136	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1162	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1164	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1166	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1168	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only	N/A	No	No	N/A	N/A

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
NSP-1170	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1172	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1174	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1174-K01	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1176	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1178	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1180	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1206B	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1206R	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1224B	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1224CTD	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1224R	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1236	Slide Battery Cover toward base of light	None	4 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1260	Slide Battery Cover toward base of light	None	4 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1310CTD	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1310RM	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1312RM	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1400B	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1400R	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1400T	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1402B	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1404B	Slide Battery Cover toward base of light	None	2 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-1632	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	AAA Carrier	No	N/A	N/A
NSP-1634	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	AAA Carrier	No	N/A	N/A

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
NSP-1636	Unscrew Cap at base of light	None	3 - AAA	NiCad or NiMH Only*	N/A	AAA Carrier	No	N/A	N/A
NSP-2422B	Unscrew Bezel and slide Reflector/LED Module out	None	3 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-2422R	Unscrew Bezel and slide Reflector/LED Module out	None	3 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-410	Unscrew Tail Cap	None	1 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-420	Unscrew Tail Cap	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-430	Unscrew Tail Cap	None	2 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4602B	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4603B	Loosen fitting on back of head & rotate door downward	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4604B	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4605B	Loosen fitting on back of head & rotate door downward	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4606B	Loosen fitting on back of head & rotate door downward	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4608B	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4608BC	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4610B	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4612B	Loosen fitting on rear battery compartment & rotate door downward	None	3 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4614B	Loosen fitting on back of head & rotate door downward	None	3 - AAA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4616B	Loosen fitting on rear battery compartment & rotate door downward	Phillips Screwdriver	3 - AA	NiCad or NiMH Only*	N/A	No	No	N/A	N/A
NSP-4650B	Loosen fitting on back of light & rotate door downward	Slotted Screwdriver	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
NSP-9842XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	9842-CARRIER	9844-BATT Only	N/A	N/A
NSR-9844XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	9842-CARRIER	No	9844-BATT Only	N/A
NSR-9854XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	9842-CARRIER	No	9844-BATT Only	N/A
TAC-300B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-300B-K01	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-300T	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
TAC-300Y	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-302B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-302B-K01	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-310XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-350B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-360XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	No	No	N/A	N/A
TAC-400B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-400T	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-400Y	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-410XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
TAC-450B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-460XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
TAC-460XL-K01	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	560-BATT Only	N/A	N/A
TAC-500B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-500T	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-500Y	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	400-BATT Only	N/A
TAC-510XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
TAC-540XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	560-BATT Only	N/A	N/A
TAC-550B	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
TAC-560XL	Unscrew Tail Cap	None	2 - CR-123	N/A	No, will damage product	500-CARRIER	No	560-BATT Only	N/A
XPP-5410G	Unscrew Tail Cap	Phillips Screwdriver	2 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92, Energizer EN92 Duracell MX2400, Duracell PC2400 or Duracell EN92
XPP-5412G	Unscrew Tail Cap	Phillips Screwdriver	3 - AAAA	Invalidates IS Certification	N/A	No	No	N/A	Duracell MX2500 or Energizer E96
XPP-5420B	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5420G	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91

Product Part Number	How to Open Battery Compartment	Tool Required	Battery Type & Quantity	Replacing AA, AAA or AAAA Alkaline w/ Rechargeable	Replacing CR-123 w/ Rechargeable	Battery Carrier Required	Nightstick Rechargeable Upgrade Option	Nightstick Rechargeable Replacement Battery	Intrinsically Safe Certification Alkaline Battery Requirements**
XPP-5420GX	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422B	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422G	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422GX	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422GM	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5422GMX	Loosen Bezel Screw, unscrew Bezel and slide Reflector/LED Module out	Phillips Screwdriver	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5450G	Loosen fitting on back of head & rotate door downward	Phillips Screwdriver	3 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92 or Energizer EN92
XPP-5452G	Loosen fitting on back of head & rotate door downward	Phillips Screwdriver	3 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92 or Energizer EN92
XPP-5454G	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92 or Energizer EN92
XPP-5454GC	Loosen fitting on back of head & rotate door downward	Slotted Screwdriver	3 - AAA	Invalidates IS Certification	N/A	No	No	N/A	Energizer E92 or Energizer EN92
XPP-5456G	Loosen fitting on rear battery compartment & rotate door downward	Allen Wrench	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5458G	Loosen fitting on rear battery compartment & rotate door downward	Allen Wrench	3 - AA	Invalidates IS Certification	N/A	No	No	N/A	Duracell PC1500, Energizer EN91 or Energizer L91
XPP-5570G	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	5572-BATT Only	N/A	Energizer EN91 or Energizer L91
XPP-5570GA	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	5572-BATT Only	N/A	Energizer EN91 or Energizer L91
XPP-5570R	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	5572-BATT Only	N/A	Energizer EN91 or Energizer L91
XPP-5570RA	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	5572-BATT Only	N/A	Energizer EN91 or Energizer L91
XPR-5572G	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91
XPR-5572GA	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91
XPR-5572R	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91
XPR-5572RA	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91
XPR-5572RM	Loosen fitting on bottom of handle & rotate door open	Torx Wrench/Screwdriver	6 - AA	Invalidates IS Certification	N/A	5570-BATT	No	5572-BATT Only	Energizer EN91 or Energizer L91

** Not offered by Bayco Products. These would be commercially available rechargeable NiCad or NiMH Battery(ies). Do NOT use Lithium-ion Rechargeable Battery(ies)*

*** Using a different battery other than what is listed will invalidate Intrinsically Safe Certification Rating*

Declaration of Conformity
NSP-1162, NSP-1164, NSP-1166,
NSP-1168, NSP-1170, NSP-1172,
NSP-1174, NSP-1176, NSP-1178,
NSP-1180

The equipment which accompanies this declaration is in conformity with EU Directive(s):
EU Directive 2011/65/EU, concerning the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS), as adopted by EU member states on January 2, 2013 (including restrictions on the use of Deca-BDE) ("EU RoHS"). The specifics of this compliance are as follows:

These Products are fully compliant and do not contain the restricted substances above levels noted in EU RoHS.

Including:


- Cadmium (Cd),
- Lead (Pb),
- Mercury (Hg),
- Hexavalent chromium (Cr ⁶⁺),
- the following flame retardants:
 - polybrominated biphenyls (PBB)
 - polybrominated diphenyl ethers (PBDE)

Phthalates:

- (DnHP) Di-n-Hexyl Phthalate
- (DnBP) Di-n-Butyl Phthalate
- (BBP) Di-Ethyl Hexyl Phthalate
- (DEHP) Di-n-Octyl Phthalate
- (DINP) Di-Isononyl PHthalate
- (DIDP) Di-Isodecyl Phthalate

Description of Equipment (NSP-1162, NSP-1164, NSP-1166, NSP-1168, NSP-1170, NSP-1172, NSP-1174, NSP-1176, NSP-1178, NSP-1180)

This product is a portable safety flashlight.



Signature:
Bijan Bayat
President / CEO
3/01/2014