

Instructions for 450 Series Incandescent Light on Retractable Reel

INS-450-12

Electrical Rating - All models use 125 Volts 60 HZ

CAUTION - TO REDUCE THE RISK OF ELECTRIC SHOCK AND FIRE - PULL PLUG WHEN SERVICING, CONNECTING/DISCONNECTING FROM THE CORD REEL OR WHEN RE-LAMPING - USE ONLY 75 WATT OR SMALLER BULB

CAUTION

DO NOT <u>use this cord reel</u> in explosive atmospheres, near flammable liquids, or where explosion proof lamps are required.

DO NOT use in the proximity of vehicles or equipment when there is a risk of flammable liquids coming into contact with the hand lamp

DO NOT immerse in water

DO NOT use in areas where water can accumulate or in rain or mist **CAUTION**: Risk of Electric Shock – For Light Duty Dry Location Use Only

GENERAL USE CORD REEL ONLY. NOT FOR HARD USE. FOR INDOOR DRY LOCATION USE ONLY FOR LIGHT DUTY RESIDENTIAL USE ONLY

WARNING: NOT FOR USE ABOVE HAZARDOUS LOCATIONS CAUTION: DO NOT USE IN HAZARDOUS LOCATIONS AS REQUIRED BY THE CANADIAN ELECTRICAL CODE, PART I

IMPORTANT SAFETY INSTRUCTIONS

This product has a 3 prong polarized plug on the power cord. Do not attempt to bypass this safety feature by removing the round plug and defeat his safety feature. This plug will fit into a grounded outlet only one way. If the plug does not fit fully into the outlet, contact a qualified electrician. Never use with a two wire extension cord.

CAUTION: PULL OUT CORD TO FULL LENGTH WHEN USING RECEPTACLE **CAUTION:** DO NOT ALLOW THE CORD TO RETRACT BY ITSELF AS DAMAGE OR INJURY MAY OCCUR FROM EXCESSIVE REWIND SPEED

CAUTION: Drywall will not hold the weight of the reel assembly

CAUTION: Read and understand mounting instructions before attempting installation and use of this product

<u>Thank you for purchasing this Bayco cord reel</u>. Please read these instructions before using.

OPERATION

- To operate, plug into a 120 Volt 60 HZ grounded outlet.
- The work light has a push-push switch to turn the light on or off.
- Pull out desired length of cord. Notice a clicking noise when pulling. Cord will stay at
 the desired length during clicking and rewind after a pull past the clicking noise.
 Extended length when retracted can be adjusted by sliding plastic ball to desired
 position.

CAUTION: DO NOT ALLOW CORD TO RETRACT BY ITSELF, AS DAMAGE TO CORD END FITTINGS MAY OCCUR FROM EXCESSIVE REWIND SPEED.

TO CLEAN OUTSIDE OF UNIT: Unplug the unit before cleaning and dry thoroughly before re-using. Use a soft cloth with mild detergent. DO NOT use solvents such as gasoline, turpentine, etc., to clean the unit. NEVER immerse the reel or cord end fittings (receptacles or lamps) in water.

FEATURES

- The cord is 20ft long; with polarized plug.
- Metal shield holds 75 watt bulb maximum
- 7 amp circuit breaker
- · Mounts on ceiling or wall
- Adjustable cord stop.

BULB REPLACEMENT


- · Disconnect the reel unit from electrical outlet
- Open bulb cage and unscrew lamp from socket. Caution: bulb may be hot
- Use a rough service lamp to Increase lamp life.
- Install new lamp (maximum 75 Watts) and tighten finger tight only. Close lamp cage door



MOUNTING

Ceiling or Wall Installation

- Select a location within 2 feet of an electrical outlet. The outlet for a garage door opener is desirable.
- Drywall will not hold the weight of the reel assembly, so locate a ceiling joist or wall stud and using the mounting bracket as a template, mark the holes so they are centered on the ceiling joist or stud.
- 3. Attach the mounting bracket to the stud using the 2 wood screws provided.
- Align the holes on the side of the reel with the holes in the side of the mounting bracket and insert the pin.
- 5. Place the retaining ring on the pin and twist until the entire ring is through the hole in the pin. DO NOT operate this reel without the retaining ring in place on the pin.



SAFETY / CARE

- Caution: do not allow the cord to retract by it self as damage or injury may occur from excessive rewind speed.
- Adjust the cord stop to hold the receptacle at the desired length when the cord is retracted.
- Before cleaning the reel always unplug from the power source.
- Clean the outside of the cord reel only. Use a soft cloth with mild detergent. Do not
 use petroleum based to clean the cord reel. Never immerse the cord reel or
 receptacles or work lights in water. Dry thoroughly before attempting to reattach to
 power source.

WARRANTY

PRODUCTS COVERED UNDER THIS LIMITED WARRANTY:

This product is warranted to the original purchaser for 1 year and only covers failures due to defects in materials or workmanship. If this product is used for rental purposes, the warranty term is reduced to 90 days from the date of purchase.

NOT COVERED

The warranty does not cover normal wear and tear or cosmetic damage. The Limited Warranty also does not cover damages which occurred in shipment or failures which are caused by accidents, misuse, abuse, faulty installation and lightning damage. Consequential damages, incidental damages or incidental expenses, including damage to property. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights, which may vary from state to state. This warranty does not apply to certain Bayco professional products that carry a specific warranty unique to those products.

WARRANTY CLAIMS - USA

Contact Bayco for USA warranty claims. Call and Bayco Customer Service will provide a Return Goods Authorization (RGA) to facilitate rapid warranty action. After receiving the RGA, send the product (shipping prepaid) to BAYCO. Include a dated proof of purchase and a brief description of the defect with your name, address and phone number. Your product will either be repaired or replaced at the option of Bayco and returned as soon as practical, but no later than 45 days after being received by Bayco.

WARRANTY CLAIMS - CANADA

Return the product to the place where purchased with a dated proof of purchase and a brief description of the defect with your name, address and phone number. Your product will either be replaced or purchase price refunded.

REQUEST FOR WARRANTY ACTION

If you have any questions about this warranty or any other Bayco product inquiries contact BAYCO.