


Parts List for LPHT120 Type 1

Item Number	Part Number	Description	Qty Required
1	90565370	HANDLE ASSEMBLY	1
10	90568531	BLADE ASSEMBLY	1
11	5145461-00	SHEATH	1
862	5145090-00	BAG	1
866	90605861N	BATTERY PACK	1
866	90605861N	BATTERY PACK	1
871	90640340	CHARGER	1



Find more Black & Decker products on our website.

Check out a selection of outdoor tools and equipment offered in our online store.