



PARTS LIST

Part #	Key #	Detail	Qty/Unit
82-492	001	4' Blade	1
82-765	001	5' Blade	1
82-493	001	6' Blade	1
82-494	001	8' Blade	1
82-495	001	10' Blade	1
82-496	001	12' Blade	1
82-497	001	14' Blade	1
82-498	001	16' Blade	1
50-802	002	Frame and Handle cpl.	1
50-803	003	Engine, Honda GX35	1
50-804	004	Blade Adapter cpl.	1
50-805	005	Drive cpl.	1

PARTS LIST


Part #	Key #	Detail	Qty/Unit
50-806	006	Lock Nut, MB	4
50-807	007	Washer	4
50-808	008	Shock Mount	4
50-809	009	Washer	4
50-810	010	Lock Nut, MB	4
50-811	011	Oil Seal, 15x30x7	1
50-812	012	Socket Head Screw, M6x25	4
50-813	013	Bearing Cover	1
50-814	014	Bearing	1
50-815	015	Drive Shaft	1
50-816	016	Bearing	1
50-817	017	Grease Fitting	1
50-818	018	Bracket	1
50-819	019	Screw	1
50-820	020	Hex Nut, M12	2
50-821	021	Washer	2
50-822	022	Sleeve	2
50-856	056	Washer	2
50-823	023	Hex Head Screw, M12x50	2





PARTS LIST

Part #	Key #	Detail	Qty/Unit
50-824	024	Rubber Connection	1
50-825	025	Bearing	1
50-826	026	Screw, M8x25	4
50-827	027	Spring Washer	4
50-828	028	Washer	4
50-829	029	Housing	1
50-830	030	Screw, M6x40	4
50-831	031	Spring Washer	4
50-832	032	Washer	4
50-833	033	Retaining Ring	1
50-834	034	Drive Shaft	1
50-835	035	Bearing	1
50-836	036	Clutch cpl.	1



PARTS LIST

Part #	Key #	Detail	Qty/Unit
50-837	037	Mounting Plate	1
50-838	038	Lock Nut, MB	1
50-839	039	Washer	2
50-840	040	Spring Washer	1
50-841	041	Support Stand	1
50-842	042	Washer	1
50-843	043	Hex Head Screw M8x35	1
50-844	044	Plug	1
50-845	045	Hex Nut, M8	4
50-846	046	Spring Washer	4
50-847	047	Pivot	4
50-848	048	Washer	4
50-849	049	Hex Head Screw, M8x40	4
50-850	050	Upper Handle	2
50-851	051	Handle Pipe	2
50-852	052	Grip Handle	2
50-496	053	Throttle Cable	1
50-854	054	On-Off Switch	1
50-855	055	Sleeve	4