


# Right Angle Seam Seal Remover

## Parts Breakdown



Ref. No.	Part No.	Description	Q'ty /Tool	Ref. No.	Part No.	Description	Q'ty /Too
1	SPI9121A01A	Air Inlet (1/4" PF)	1	27	SPI9121A27	Steel Ball	1
	SPI9121A01B	Air Inlet (1/4" PT)		28	SPI9121A28	Front End Plate	1
	SPI9121A01C	Air Inlet (1/4" NPT)		29	SPI9121A29	Ball Bearing 608ZZ	1
2	SPI9121A02	Exhaust Deflector	1	30	SPI9121A30	Washer	1
3	SPI9121A03	Valve Bushing	1	31	SPI9121A31	Ball Bearing 6001ZZ	1
4	SPI9121A04	O-Ring	1	32	SPI9121A32	Gear Cage	1
5	SPI9121A05	Throttle Valve	1	33	SPI9121A33	Idel Gear	2
6	SPI9121A06	O-Ring	1	34	SPI9121A34	Needle Bearing	2
7	SPI9121A07	Spring	1	35	SPI9121A35	Gear Shaft	2
8	SPI9121A08	Throttle Lever	1	36	SPI9121A36	Ball Bearing 6000ZZ	1
9	SPI9121A09	Screw(M4x0.75x4L)	2	37	SPI9121A37	Internal Gear	1
10	SPI9121A10	Spring	1	38	SPI9121A38	Clamp Nut	1
11	SPI9121A11	Pin	1	39	SPI9121A39	Clamp Ring	1
12	SPI9121A12	Pin $\varnothing$ 3x24L	1	40	SPI9121A40	Dead Handle	1
14	SPI9121A14	Air Regulator	1	41	SPI9121A41	Nut	1
15	SPI9121A15	O-Ring SM-08	1	42A	SPI9121A42A	Spindle	1
16	SPI9121A16	O-Ring SM-12	1	43	SPI9121A43	Spanner	1
17	SPI9121A17	Valve Screw	1	44	SPI9121A44	O-Ring	1
18	SPI9121A18	Control Valve	1	45	SPI9121A45	Safety Guard	1
19	SPI9121A19	Motor Housing	1	46	SPI9121A46	Washer	1
20	SPI9121A20	Ball Bearing 626ZZ	1	47	SPI9121A47	Screw M6X1.0X18L	1
21	SPI9121A21	Dowel Pin	2	48	SPI9121A48	Hex. Wrench 5m/m	1
22	SPI9121A22	Rear End Plate	1				
23	SPI9121A23	Rotor Blade	4	RK	SPI9121ARK	Repair Kit Ref. No-- 20, 23(x4), 29, 30, 31, 34,	
24	SPI9121A24	Rotor	1				
26	SPI9121A26	Cylinder	1	SK	SPI9121ASK	Service Kit Ref. No-- 4, 6, 7, 10, 15, 16, 44	