



Special Tools for Repair

0.7 hp. Pistol Grip Tools

Models: 50320, 50321, 50324, 50340

96346 – Bearing Separator (2")

96232 – Arbor Press (#2)

96213 – Bearing Removal Tool

96240 – Bearing Press Tool

94925 – Pin Wrench (50340)

95263 – 17 mm Wrench (50320, 50321, 50340)

96066 – 3/4" Socket

96349 – Torque Wrench (30 – 150 in. lbs.)

Use to safely tighten governor assembly onto the rotor.

53698 – Carrier Wrench

Use with torque wrench to safely tighten governor assembly onto the rotor.