#### **B1218-BM**



#### **BCK18-022**



Breaker bar for holding the bottom, side or top of the crimper or cutter. Also can turn the head for cutting and crimping.



### **BCK18 Instructions**

#### **CAUTION:**

- Always wear eye protection when using this product.
- Keep hands and fingers well away from the cutting blade while this tool is operated.

#### **B1218 Wire Shear**

# This tool is designed to cut stranded copper wire only. It will cut up to 4 AWG.

For bench work, use the Bench Mount Adapter (B1218-BM) attach the B1218 to the adapter via the 3/8" stud on the adapter plate.



For use away from a work bench, use a 3/8" ratchet or included breaker bar to hold the Shear



Using a 3/8" ratchet open the Shear to accommodate the size wire being cut



Hold the tool with a 3/8"ratchet at the base of the tool.



Using a 3/8" drive ratchet (manual or cordless driven), drive the cutting head through the wire.



Reverse the ratchet and back off the cutting blades



## EZRED

#### Replacement parts:

Lower blade: B1218-LB Upper blade: B1218-UB Bench Mount: B1218-BM

Check out the collection of wire and cable tools we offer.