




AIR Saw

Item No : QD-221



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List QD-221

	NO.	INDEX NO.	DESCRIPTION	Q'TY
★	01	QD-221P01	Cylinder Housing	1
★	02	QD-221P02	Cylinder	1
●	03	QD-221P03	Piston Rod	1
●	04	QD-221P04	Spring Seat	1
●	05	QD-221P05	Piston	1
★	06	QD-221P06	Throttle Housing	1
★	07	QD-221P07	Throttle Bushing	1
★	08	QD-221P08	Valve Stem	1
★	09	QD-221P09	Valve Plug	1
●	10	QD-221P10	O-Ring (∅9.19x2.62)	1
●	10A	QD-221P10A	Rubber Cushion	1
★	11	QD-221P11	Gasket	1
★	12	QD-221P12	Head	1
●	14	QD-221P14	Saw Blade Holder	1
★	15	QD-221P15	Lever Assembly	1
★	17	QD-221P17	Grip	1
★	19	QD-221P19	Guard	1
★	21	QD-221P21	Front Spring	1
★	22	QD-221P22	Rear Spring	1
★	23	QD-221P23	Cone Spring	1
★	26	QD-221P26	Spring Pin (∅3x23)	1
▲	28	QD-221P28	O-Ring (P006)	1
▲	29	QD-221P29	O-Ring (P5)	1
★	30	QD-221P30	Air Regulator	1
▲	32	QD-221P32	O-Ring (P6)	1
▲	33	QD-221P33	O-Ring (P11)	1
▲	34	QD-221P34	O-Ring (P10.82x1.78)	1
★	35	QD-221T35	Cap Screw (M3x18) (4 pcs)	1 set
★	35A	QD-221T35A	Cap Screw (M3x12) (3 pcs)	1 set
★	36	QD-221P36	Set Screw (M4x3)	1
★	37	QD-221T37	Set Screw (M6x8) (2 pcs)	1 set
★	41	QD-221P41	Hose Assy 1/4"	1
★	42	QD-221P42	Exhaust Hose	1
★	43	QD-221P43	Sponge	1
★	45	QD-221P45	Stop Ring	1
★	48	QD-221P48	Hex Wrench (M3)	1
●	49	QD-221T49	File Set	1 set
●	50	QD-221P50	32T Blade	1
●	51	QD-221P51	24T Blade	1