




Straight Type Air Shear

Item No : QG-103



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List QG-103

	NO.	INDEX NO.	DESCRIPTION	Q'TY
★	01	QG-103P01	Screw	1
★	02	QG-103P02	O-Ring (P12)	1
★	03	QG-103T03	O-Ring (P8) (2 pcs)	1 set
★	04	QG-103P04	Air Regulator	1
★	05	QG-103P05	Spring	1
★	06	QG-103P06	Valve Stem Bushing	1
★	07	QG-103P07	Valve Stem	1
★	08	QG-103P08	O-Ring(3.5*1.4)	1
★	09	QG-103P09	Air Inlet	1
★	10	QG-103P10	Exhaust Sleeve	1
★	11	QG-103P11	O-Ring (26.7*1.78)	1
★	12	QG-103P12	Spring Pin	1
★	13	QG-103P13	Throttle Lever	1
★	14	QG-103P14	Rubber	1
★	15	QG-103P15	Motor Housing	1
▲	16	---	Bearing (696ZZ)	1
▲	17	---	Rear Plate	1
★	18	QG-103T18	Positioning Pin (2 pcs)	1 set
●	19	QG-103T19	Rotor Blade (4 pcs)	1 set
★	20	QG-103P20	Rotor(6T)	1
★	21	QG-103P21	Cylinder	1
★	22	QG-103P22	Cone Muffler	1
▲	23	---	Front Plate	1
▲	24	---	Bearing (608ZZ)	1
★	25	QG-103P25	Washer	1
★	26	QG-103P26	Internal Gear(42T)	1
●	27	QG-103T27	Idler Gear (18T) (3 pcs)	1 set
●	28	---	Planet Pin	3
●	29	---	Idler Spindle	1
★	30	QG-103P30	Clamp Nut	1
▲	31	QG-103T31	Bearing (6200ZZ) (2 pcs)	1 set
●	32	QG-103P32	Crank Shaft	1
●	33	QG-103P33	Cam	1
★	34	QG-103P34	Head Cap	1
▲	35	QG-103P35	Bushing	1
★	36	QG-103P36	Head	1
●	37	QG-103P37	Sliding Shaft	1
●	38	QG-103P38	Punch	1
▲	39	QG-103P39	Screw	1
●	40	QG-103P40	Die	1
▲	41	QG-103P41	Nut	1
★		QG-103T01	Rear End Plate Assembly(16.17)	1 set
★		QG-103T02	Front End Plate Assembly(23.24)	1 set
★		QG-103T03	Gear Plate Assembly(28.29)	1 set

Discover other air cutting tools on our website.