




Air Screwdriver

Item No : RA-301



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



Part List RA-301

	NO.	INDEX NO.	DESCRIPTION	Q'TY
★	01	RA-301P01	Motor Housing	1
★	01A	RA-301P01A	Grip	1
★	02	RA-301P02	Roller Pin (3x27.8)	1
★	03	RA-301P03	Air Inlet Bushing	1
★	04	RA-301P04	Trigger	1
★	05	RA-301P05	Valve Stem	1
★	06	RA-301P06	Throttle Bushing	1
▲	07	RA-301P07	O-Ring (3.5x1.5)	1
▲	07A	RA-301P07A	O-Ring (3.9x2.25x2)	1
★	08	RA-301P08	Spring	1
▲	09	RA-301P09	O-Ring (P14)	1
★	10	RA-301P10	Reverse Knob	1
▲	13	RA-301T13	Ball Bearing (2 pcs)	1 set
▲	14	RA-301P14	Rear End Plate	1
★	15	RA-301P15	Rotor	1
●	16	RA-301T16	Rotor Blade (5 pcs)	1 set
★	17	RA-301P17	Cylinder Dowel	1
★	18	RA-301P18	Cylinder	1
▲	19	RA-301P19	Front End Plate	1
★	20	RA-301P20	Spring	1
★	21	RA-301P21	Spring Guide	1
★	22	RA-301P22	Internal Gear	1
●	23	RA-301T23	Planet Gear (3 pcs)	1 set
●	24	RA-301T24	Planet Pin (4x13.8) (3 pcs)	1 set
●	26	RA-301P26	Working Spindle	1
▲	27	RA-301P27	Ball Bearing	1
★	28	RA-301P28	Clamp Nut	1
●	29	RA-301P29	Driving Dog	1
●	30	RA-301T30	Retaining Ring (3 pcs)	1 set
▲	31	RA-301P31	Retaining Ring	1
▲	32	RA-301P32	Cam Spindle	1
★	33	RA-301P33	Steel Ball	1
▲	34	RA-301P34	Clutch Carrier	1
★	35	RA-301T35	Steel Ball (4 pcs)	1 set
▲	36	RA-301P36	Washer	1
★	37	RA-301P37	Spring	1
▲	38	RA-301P38	Washer	1
▲	39	RA-301P39	Adjusting Nut	1
★	40	RA-301P40	Spacer	1
★	41	RA-301P41	Clutch Housing	1
●	42	RA-301P42	Ball Retainer	1
●	43	RA-301P43	Spring	1
●	44	RA-301P44	Washer	1
★	46	RA-301P46	Set Screw	1
▲	47	RA-301P47	O-Ring (P14)	1
★	48	RA-301P48	Exhaust Muffler	1
★	49	RA-301T49	Screw (2 pcs)	1 set
★	50	RA-301P50	Hex Gear (1/4")	1
★	51	RA-301P51	Spanner (17mm)	1