




# Air Screwdriver

## Item No : RA-302



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



# Part List RA-302

	NO.	INDEX NO.	DESCRIPTION	QTY
★	01	RA-302P01	Motor Housing	1
★	01A	RA-302P01A	Grip	1
★	02	RA-302P02	Roller Pin (3x27.8)	1
★	03	RA-302P03	Air Inlet Bushing	1
★	04	RA-302P04	Trigger	1
★	05	RA-302P05	Valve Stem	1
★	06	RA-302P06	Throttle Bushing	1
▲	07	RA-302P07	O-Ring (3.5x1.5)	1
▲	07A	RA-302P07A	O-Ring (3.9x2.25x2)	1
★	08	RA-302P08	Spring	1
▲	09	RA-302P09	O-Ring (P14)	1
★	10	RA-302P10	Reverse Knob	1
▲	13	RA-302T13	Ball Bearing (2 pcs)	1 set
▲	14	RA-302P14	Rear End Plate	1
★	15	RA-302P15	Rotor	1
●	16	RA-302T16	Rotor Blade (6 pcs)	1 set
★	17	RA-302P17	Cylinder Dowel	1
★	18	RA-302P18	Cylinder	1
▲	19	RA-302P19	Front End Plate	1
★	20	RA-302P20	Spring	1
★	21	RA-302P21	Spring Guide	1
★	22	RA-302T22	Internal Gear (2 pcs)	1 set
●	23	RA-302T23	Planet Gear (6 pcs)	1 set
●	24	RA-302T24	Planet Pin (4x13.8) (6 pcs)	1 set
●	26	RA-302P26	Working Spindle	1
▲	27	RA-302P27	Ball Bearing	1
★	28	RA-302P28	Clamp Nut	1
●	29	RA-302P29	Driving Dog	1
●	30	RA-302T30	Retaining Ring (3 pcs)	1 set
▲	31	RA-302P31	Retaining Ring	1
▲	32	RA-302P32	Cam Spindle	1
★	33	RA-302P33	Steel Ball	1
▲	34	RA-302P34	Clutch Carrier	1
★	35	RA-302T35	Steel Ball (4 pcs)	1 set
▲	36	RA-302P36	Washer	1
★	37	RA-302P37	Spring	1
▲	38	RA-302P38	Washer	1
▲	39	RA-302P39	Adjusting Nut	1
★	40	RA-302P40	Spacer	1
★	41	RA-302P41	Clutch Housing	1
●	42	RA-302P42	Ball Retainer	1
●	43	RA-302P43	Spring	1
●	44	RA-302P44	Washer	1
★	45	RA-302P45	Pinion Gear	1
★	46	RA-302P46	Set Screw (M4*4)	1
▲	47	RA-302P47	O-Ring (P14)	1
★	48	RA-302P48	Exhaust Muffler	1
★	49	RA-302T49	Screw (2 pcs)	1 set
★	50	RA-302P50	Reduction Spindle	1
★	51	RA-302P51	Center Gear	1
★	52	RA-302P52	Hex Wrench (1/4")	1
★	53	RA-302P53	Spanner (17mm)	1