




# Air Screwdriver

Item No : RA-802



● The consumable parts ▲ The replacement parts ★ The non-replacement parts



# Part List

Item No : RA-802



	NO.	INDEX NO.	DESCRIPTION	Q'TY
●	1	RA-802T01	Retaining Ring (3 pcs)	1 SET
●	2	RA-802P02	Washer	1
●	3	RA-802P03	Spring	1
●	4	RA-802P04	Ball Retainer	1
★	5	RA-802P05	Clutch Housing	1
★	6	RA-802P06	Spacer	1
▲	7	RA-802P07	Adjust Nut	1
▲	8	RA-802P08	Washer	1
★	9	RA-802P09	Spring	1
▲	10	RA-802P10	Washer	1
★	11	RA-802T11	Steel Ball (1/4") (4 pcs)	1 SET
▲	12	RA-802P12	Clutch Carrier	1
★	13	RA-802P13	Steel Ball (1/8")	1
▲	14	RA-802P14	Cam Spindle	1
●	15	RA-802P15	Internal Stop Ring	1
●	16	RA-802P16	Drive Dog	1
★	17	RA-802P17	Ring	1
★	18	RA-802P18	Clamp Nut	1
▲	19	RA-802P19	Ball Bearing (6201zz)	1
★	20	RA-802T20	Internal Gear (2 pcs)	1 SET
★	21	RA-802P21	Spring Guide	1
★	22	RA-802P22	Cone Spring	1
●	23	RA-802P23	Work Spindle	1
●	24	RA-802T24	Needle Roller (ψ4×13.8) (6 pcs)	1 SET
●	25	RA-802T25	Idler Gear (6 pcs)	1 SET
●	26	RA-802P26	Reduction Gear	1
●	27	RA-802P27	Reduction Spindle	1
●	28	RA-802P28	Pinion Gear	1
▲	29	RA-802T29	Bearing (2 pcs)	1 SET

	NO.	INDEX NO.	DESCRIPTION	Q'TY
▲	30	RA-802P30	Front Plate	1
★	31	RA-802P31	Pin (ψ2×55)	1
●	32	RA-802T32	Rotor Blade (5 pcs)	1 SET
★	33	RA-802P33	Rotor	1
★	34	RA-802P34	Cylinder	1
▲	35	RA-802P35	End Plate	1
★	36	RA-802P36	Cylinder Washer	1
★	37	RA-802P37	Housing	1
★	38	RA-802P38	Pin (ψ2.5×26.8)	1
★	39	RA-802P39	Trigger	1
★	40	RA-802P40	Spring	1
▲	41	RA-802P41	O-Ring (ψ10.82×1.78)	1
★	42	RA-802P42	Reverse Valve	1
▲	43	RA-802P43	O-Ring (ψ15.5×1.5)	1
★	44	RA-802P44	Reverse Valve Bush	1
▲	45	RA-802P45	O-Ring (ψ4.42×2.62)	1
★	46	RA-802P46	Throttle Valve	1
▲	47	RA-802P47	O-Ring (ψ15×2)	1
★	48	RA-802P48	Muffler	1
★	49	RA-802P49	Taping Screw (ψ3×10)	1
★	50	RA-802P50	Air Inlet	1
●	51	RA-802P51	Wave Washer	1
★	52	RA-802P52	Exhaust Diffuser	1
▲	53	RA-802P53	O-Ring (ψ10.8×2.4)	1
★	54	RA-802P54	Pin (ψ3×22.8)	1
★	55	RA-802P55	Cover	1
★	56	RA-802P56	Wrench (17mm)	1
★	57	RA-802P57	Hexagon Wrench Key (1/4")	1