







- **1** Tail cap
- 2 Lip seal, tail cap
- **3** Electrical contact
- 4 Battery spring\*
- 5 Barrel/LED Switch
  - Assembly\*\*
- **6** O-ring, barrel
- **7** Head
- 8 O-ring, head 9 Reflector
- **10** Clear lens
- 11 O-ring, face cap
- **12** Face cap

2-CELL

\*Item 4 inserts into item 1

OPERATION: Large end of battery spring must be snapped into tailcap. Install batteries with the "+" end facing the head end of the flashlight. Backwards installation can damage the LED. Turn flashlight on and off by twisting the head. Rotate the head to focus the beam. Candle Mode — unscrew the head to detach. Invert head and place tail end of the flashlight into the inverted head. Flashlight will act as a candle.

INSPECTION AND MAINTENANCE: If flashlight is used less than once a month, remove the batteries between uses. Lubricate all threads and rubber 0-rings with petroleum jelly twice yearly. Inspect flashlight monthly and carefully remove any damaged batteries and clean any corrosion.

**TROUBLESHOOTING:** If flashlight does not turn on or stay on - 1. Replace the batteries. If the problem persists, then 2. Check the tail cap. The metal surfaces contacting the barrel, tail cap and spring assembly should be clean, shiny and free of corrosion or other obstruction. Clean as needed.

**WARNINGS:** • To AVOID RISK OF EYE INJURY, LOOK AWAY IMMEDIATELY IF BEAM IS SHONE DIRECTLY INTO YOUR EYES. • AVOID EXPOSING BATTERIES TO FIRE OR EXCESSIVE HEAT, as this may cause leakage or explosion. • To AVOID RISK OF INJURY TO EYES OR SKIN, AVOID CONTACT WITH ANY MATERIAL LEAKED FROM A BATTERY • THIS FLASHLIGHT IS NOT A TOY; not recommended for use by children.



2-Cell AAA LED Flashlight

Part Number: Model Number: **SP32016** 156-000-017

- Twist head to turn on/off and focus beam (spot to flood)
- Latest-generation LED for higher brightness and efficiency
- Limited Lifetime Warranty Details inside
- Features "Candle Mode" operability





