

ENGLISH

- 1 Tail cap
- 2 Lip seal, tail cap
- 3 Electrical contact
- 4 Battery spring*
- 5 Barrel/LED Switch Assembly**
- 6 O-ring, barrel
- 7 Head assembly**

*Item 4 inserts into item 1

OPERATION: Large end of battery spring must be snapped into tailcap. Install 1 AAA alkaline battery with the “+” end facing the head end of the flashlight. Backwards installation can damage the LED. Turn flashlight on and off by twisting the head. Rotate the head to focus the beam.

INSPECTION AND MAINTENANCE: If flashlight is used less than once a month, remove the batteries between uses. Lubricate all threads and rubber O-rings with petroleum jelly twice yearly. Inspect flashlight monthly and carefully remove any damaged batteries and clean any corrosion.

TROUBLESHOOTING: If flashlight does not turn on or stay on - 1. Replace the batteries. If the problem persists, then 2. Check the tail cap. The metal surfaces contacting the barrel, tail cap and spring assembly should be clean, shiny and free of corrosion or other obstruction. Clean as needed.

WARNINGS: • To AVOID RISK OF EYE INJURY, LOOK AWAY IMMEDIATELY IF BEAM IS SHONE DIRECTLY INTO YOUR EYES. • AVOID EXPOSING BATTERIES TO FIRE OR EXCESSIVE HEAT, as this may cause leakage or explosion. • To AVOID RISK OF INJURY TO EYES OR SKIN, AVOID CONTACT WITH ANY MATERIAL LEAKED FROM A BATTERY • THIS FLASHLIGHT IS NOT A TOY; not recommended for use by children.

TEN YEAR LIMITED WARRANTY Mag Instrument, Inc. warrants to the original owner that this flashlight is free from defects in parts and workmanship for ten years from the date of first retail purchase. Mag or an authorized Mag Warranty Service Center will, free of charge, repair or, at its option, replace a defective flashlight or component. (Mag does not warrant the future availability of particular colors or decorations, and may replace a custom flashlight with a standard flashlight.) This warranty is in lieu of all other warranties, express or implied.

EXCLUSIONS: This warranty does not cover: 1. Dead batteries, battery leakage or explosion; 2. LED failure; or 3. Product damage due to alteration, misuse, battery leakage or lack of maintenance.

MAG DISCLAIMS ANY RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES. Some countries, provinces, and states do not allow exclusion or limitation of implied warranties, incidental or consequential damages and/or limitations on transferability, so the above limitations and exclusions may not apply to you.

HOW AND WHEN TO MAKE A WARRANTY CLAIM: 1. In case of dead batteries, replace batteries; do not send batteries or flashlight to Mag. 2. If flashlight is damaged by battery leakage, determine what brand of battery caused the damage and follow the battery manufacturer’s instructions regarding damage claims; do not send batteries or flashlight to Mag. 3. For warranty returns: Send the flashlight (postage or shipping prepaid) to the nearest authorized Mag Warranty Service Center (find at maglite.com/support/service_center or ask your local Mag retailer).

This warranty gives you specific legal rights, and you may have other rights which vary from one jurisdiction to another. Where any term of this warranty is prohibited by the law of any jurisdiction, such term shall there be null and void, but the remainder of this warranty shall remain in full force and effect. THESE STATEMENTS DO NOT AFFECT THE STATUTORY RIGHTS OF A CONSUMER.

WARNING: Cancer and Reproductive Harm -
 AVERTISSEMENT: Cancer et Troubles de l'appareil reproducteur
 ADVERTENCIA: Cáncer y Daño Reproductivo


MAG-LITE LED
SOLITAIRE




Model Number: **SJ3A016L** Part Number: **160-000-007**



MAG-LITE
SOLITAIRE
 LED FLASHLIGHT



ULTRA BRIGHT
47
LUMENS



- Twist head to turn on/off and focus beam (spot to flood) •
- Latest-generation LED for high brightness and longer battery life •
- Ten Year Limited Warranty – Details inside



1-CELL AAA

423-000-825 3/19

BLACK

Learn more about flashlights we have.