



Model XRH05Z Parts List

A = Standard Equipment

O = Circuit Diagram

Item#	Part#	Description	Q'ty	Unit
001	286263-4	CAP 35	1	PC.
002	233940-9	RING SPRING 19	1	PC.
003	417629-9	CHUCK COVER	1	PC.
004	257241-1	RING 21	1	PC.
005	345187-4	GUIDE WASHER	1	PC.
006	233916-6	CONICAL COMP. SPRING 21-29	1	PC.
007	921923-8	HEX. BOLT M8X120	1	PC.
008	345280-4	HEX. WASHER	1	PC.
009	417630-4	GRIP BASE	1	PC.
010	158057-6	GRIP 36 COMPLETE	1	PC.
013	450980-4	CHANGE LEVER	1	PC.
014	233279-0	COMPRESSION SPRING 4	1	PC.
015	453706-3	LOCK BUTTON	1	PC.
016	213278-8	O RING 17	1	PC.
017	158945-7	GEAR HOUSING COMPLETE	1	PC.
C10	213345-9	OIL SEAL 25	1	PC.
018	266560-4	TAPPING SCREW 4X40	4	PC.
019	153290-5	NEEDLE BEARING COMPLETE	1	PC.
020	961017-7	STOP RING E-3	2	PC.
021	417796-0	GUIDE BASE	1	PC.
022	233344-5	COMPRESSION SPRING 4	2	PC.
023	163430-7	LOCK PLATE COMPLETE	1	PC.
024	266374-1	TAPPING SCREW 4X25	2	PC.
025	233929-7	RING SPRING 29	1	PC.
026	267460-1	WASHER 31	1	PC.
027	233401-9	COMPRESSION SPRING 32	1	PC.
028	227109-5	SPUR GEAR 51	1	PC.
029	216022-2	STEEL BALL 7.0	1	PC.
030	158574-6	TOOL HOLDER COMPLETE	1	PC.
031	267229-3	FLAT WASHER 28	1	PC.
032	331769-8	SLEEVE 9	1	PC.
033	324669-9	IMPACT BOLT	1	PC.
034	324402-9	RING 10	1	PC.
035	421955-0	CUSHION RING 13	1	PC.
036	324216-6	O RING CASE	1	PC.
037	213073-6	O RING 9	1	PC.
038	233917-4	RING SPRING 28	1	PC.
039	326404-1	STRIKER	1	
040	213227-5	O RING 16	1	PC.
041	318132-2	PISTON CYLINDER	1	PC.
042	346036-8	GUIDE PLATE	1	PC.
043	324215-8	PISTON JOINT	1	PC.
044	234098-7	COMPRESSION SPRING 14	1	PC.
045	211012-0	BALL BEARING 606ZZ	1	PC.
046	961003-8	RETAINING RING S-7	1	PC.
047	233343-7	COMPRESSION SPRING 7	1	PC.
048	227179-4	SPUR GEAR 10	1	PC.
049	325976-3	CAM SHAFT	1	PC.
050	331992-5	CLUTCH CAM	1	PC.
051	219014-0	SWASH BEARING 10	1	PC.
052	325640-6	SLEEVE 9	1	PC.
053	227549-7	SPIRAL BEVEL GEAR 26	1	PC.

054	266273-7	HEX. SOCKET HEAD BOLT M4X12	2 PC.
055	346038-4	BEARING RETAINER B	1 PC.
056	211032-4	BALL BEARING 608ZZ	1 PC.
057	324212-4	RING 8	1 PC.
058	961011-9	STOP RING E-4	1 PC.
059	941102-2	FLAT WASHER 5	1 PC.
060	233342-9	COMPRESSION SPRING 6	1 PC.
061	345220-2	CHANGE PLATE	1 PC.
062	922148-7	HEX. SOCKET HEAD BOLT M4X25	2 PC.
063	158944-9	INNER SUPPORT COMPLETE	1 PC.
064	213728-3	O-RING 68	1 PC.
065	318392-6	INNER HOUSING	1 PC.
066	443143-9	FILTER	1 PC.
067	424185-2	CAP	1 PC.
068	234097-9	COMPRESSION SPRING 10	2 PC.
069	266273-7	HEX. SOCKET HEAD BOLT M4X12	2 PC.
070	213231-4	OIL SEAL 15	1 PC.
071	213437-4	O RING 28	1 PC.
072	632828-4	YOKE UNIT	1 PC.
073	961082-6	RETAINING RING WR12	1 PC.
074	331596-3	SLEEVE 12	1 PC.
075	211131-2	BALL BEARING 6001DDW	1 PC.
076	961016-9	STOP RING E-10	1 PC.
077	346037-6	BEARING RETAINER A	1 PC.
078	519235-7	ARMATURE ASS'Y 36V	1 PC.
	D10	INC. 73-76,79,80	
079	240037-7	FAN 44	1 PC.
080	210022-4	BALL BEARING 626DDW	1 PC.
081	620281-6	LIGHT CIRCUIT	1
082	644507-2	BRUSH HOLDER	1 PC.
083	643829-7	HOLDER CAP	2 PC.
084	CB442	CARBON BRUSH SET CB-442 (295023-2)	1 SET
085	266326-2	TAPPING SCREW 4X18	2 PC.
086	644508-0	BRUSH HOLDER	1 PC.
087	644808-8	TERMINAL	2 PC.
088	620280-8	CONTROLLER	1
089	187834-9	HOUSING SET	1
	C10	263005-3 RUBBER PIN 6	8 PC.
	C20	263025-7 RUBBER PIN 4	4 PC.
	C30	346783-1 PLATE	4
	C40	803F15-0 INDICATION LABEL	1
	C50	803F13-4 CAUTION LABEL	1
	D10	INC. 99	
090	187771-7	HANDLE SET	1
	D10	INC. 95	
092	650721-0	SWITCH	1
093	454980-6	F/R CHANGE LEVER	1
094	256261-2	PIN 6	2 PC.
095	187771-7	HANDLE SET	1
	D10	INC. 90	
096	266326-2	TAPPING SCREW 4X18	4 PC.
097	815K29-7	XRH05 SERIAL NO. LABEL	1
099	187834-9	HOUSING SET	1
	C10	263005-3 RUBBER PIN 6	8 PC.
	C20	263025-7 RUBBER PIN 4	4 PC.
	C30	346783-1 PLATE	4
	C40	803F15-0 INDICATION LABEL	1
	C50	803F13-4 CAUTION LABEL	1

	D10	INC. 89	
100	815K22-1	XRH05 NAME PLATE	1
101	266326-2	TAPPING SCREW 4X18	10 PC.
102	803F14-2	CLEAR LABEL	1
103	893072-0	CLEAR LABEL	1 PC.
A01	194683-7	GREASE VESSEL SET	1 PC.
A02	324219-0	DEPTH GAUGE	1 PC.
A03	443122-7	CLOTH	1 PC.
A04	831271-6	TOOL BAG	1 PC.