


#5401D Wall Mount Model





Use level to verify the lock is vertical





Mark the position of the screw holes on the surface

Instructions:

Opening the key storage compartment door

- 1. Open shutter door to reveal the dials and the release button
- 2. Rotate dials to the current combination (if the lock is new, the combination is set at the factory to 0-0-0-0)
- 3. Press down on the release button to open the door
- 4. Pull the door fully open
- 5. Add or remove keys
- 6. Close compartment door
- 7. Scramble the combination dials to lock the door and conceal your combination (A)
- 8. Close the shutter door (B)

To set a new combination:

The initial combination is set at the factory to 0-0-0-0.

- 1. Open the compartment door (see instructions above)
- 2. Push the reset lever left and down. The lever remains in this position
- 3. Rotate dials to your desired combination
- 4. Push the reset lever, up and right, back to the original position
- 5. Close the key storage compartment door
- 6. Scramble the combination dials to lock the door and conceal your combination (A)
- 7. Close the shutter door (B)

To hang wall mount model

You will need: pencil or marker, Phillips head screwdriver, level, drill, and drill bit. For certain surfaces (masonry) anchors and a hammer are recommended.

- 1. Open the compartment door (see instructions above)
- 2. Position the lock on the desired surface
- 3. Use level to verify the lock is vertical
- 4. Mark the position of the screw holes on the surface
- 5. Remove lock
- 6. Drill holes
- 7. If necessary, use hammer to place anchors
- 8. Position lock
- 9. Insert and tighten screws
- 10. Close compartment door
- Scramble the combination dials to lock the door and conceal your combination (A)
- 12. Close the shutter door

Reminder:

- (A) The release button will open the lock until you scramble the dials
- (B) Keep the shutter door closed to increase weather resistance and to conceal the dials from view