

PARKING MAT

Helps You Park Safely and Easily.



**CAUTION: Mat can move.
Always drive on and off the mat
slowly to prevent mat movement.**

INSTALLATION INSTRUCTIONS

- ▶ Park vehicle carefully in desired position.
- ▶ Mark the position of the tire on the floor/pavement for the tire that will be on the mat.
- ▶ Remove vehicle.
- ▶ Using the tire marks, position the mat so that the tire will be in the center of the mat between the two bumps. Mark the mat position.
- ▶ Make sure the floor/pavement is clean and free of oil.
- ▶ Remove backing from adhesive strip on bottom of mat. Place mat in position and press down firmly.

MAXSA™