

HOW TO USE:



Step 1:
Spray sufficient amount of lubricant on the paint surface.
NOTE: Do not allow the lubricant to run dry on the surface.



Step 2:
Using DA or handheld, slide Autoscrub across the lubricated paint surface in a back and forth motion with light to medium pressure.
NOTE: Work in a 12" x 12" area at a time. Do not allow lubricant to dry on the surface



Step 3:
Wipe and buff dry residual lubricant off the paint surface using light pressure.



Step 1:
Spray sufficient amount of lubricant on the glass surface.
NOTE: Do not allow the lubricant to run dry on the surface.



Step 2:
Using DA or handheld, slide Autoscrub across the lubricated glass surface in a back and forth motion with light to medium pressure.
NOTE: Work in a 12" x 12" area at a time. Do not allow lubricant to dry on the surface



Step 3:
Wipe and buff dry residual lubricant off the glass surface using light pressure.