



Instruction Manual

NSR-2168

THANK YOU FOR PURCHASING THE NSR-2168 RECHARGEABLE WORK LIGHT.
SAVE THESE INSTRUCTIONS.



Please read these instructions before using your work light. Be sure to charge the work light before the first use.

- CAUTION: Do not use this work light in explosive atmospheres, near flammable liquids, or where explosion-proof lamps are required. Do not immerse in water.
- CAUTION: For light duty work only.

WARNINGS

- Lithium-ion batteries must be used and charged properly. Improper use can result in serious injury, fire, or death.
- NOT FOR USE IN HAZARDOUS LOCATIONS. Do not use this product in explosive atmospheres, near flammable liquids, or where explosion proof or intrinsically safe lighting is required.
- DO NOT use this product in the proximity of vehicles or equipment when there is a risk of flammable liquids coming into contact with the flashlight.
- Light can become hot while on. To prevent damage DO NOT cover or place next to any potentially flammable materials while in use.
- Do not leave the battery in direct sunlight or use or store the battery inside cars in hot weather.
- Do not expose the battery to water or salt water, or allow the battery to get wet.
- Do not store the battery with metallic objects that may cause a short circuit.
- Immediately discontinue use of the battery if the battery emits an unusual smell, feels hot, changes color, changes shape or appears abnormal in any way.
- Keep out of the reach of children.

INITIAL USE

Fully charge the 2168 before the first use, or if the battery is new or has been unused for several months. The maximum charge time required is approximately 6 hours (typical).

DAILY USE

- Use only the supplied Nightstick AC or DC adapter. For best performance, charge the 2168 when the floodlight beam starts to dim.
- Connect the AC or DC power adapter to the body of the work light.
- The LED indicator changes to constant red indicating the 2168 is properly plugged into the charger and is in fact charging. The LED indicator remains red until the battery is fully charged. At full charge, the LED indicator turns green.
- The total time to full charge the 2168 varies depending on the remaining charge in the battery pack.

- To confirm a full charge, keep the 2168 plugged into the charger. The LED indicator will change to red. If the 2168 is fully charged, the LED indicator will turn green. If not, it remains red until the charge is completed and the LED indicator turns green. The 2168 will now be fully charged.

OPERATION

TURNING THE WORK LIGHT ON/OFF

- Floodlight Low
- Floodlight High
- Off

FLOODLIGHT LOW MODE

Press the body switch once until it clicks and then release for floodlight low mode.

FLOODLIGHT HIGH MODE

Press the body switch again until it clicks and then release for floodlight high mode.

TURNING THE FLOODLIGHT OFF

Press the body switch again until it clicks and the floodlight will turn off.

INTEGRATED MAGNETS AND MAGNETIC HOOK

The work light has three integrated magnets, one in the body of the light, one at the tip of the light and one in the bottom of the body. These magnets will support the weight of the light when magnetically attached to a ferrous metal surface. The removable Magnetic Hook can also be attached to either of the integrated magnets and offers additional hands-free options.

CLEANING

- Disconnect the light from the power source
- Wipe with a clean dry soft cloth
- Do not use any solvent or abrasive cleaners

