

LIMITED WARRANTY

PERFORMANCE TOOL extends only the following warranties, and only to original retail purchasers. These warranties give specific legal rights. Except where prohibited by local law, the law of the State of Washington governs all warranties and all exclusions and limitations of warranties and remedies. There may be other rights which vary from state to state.

PERFORMANCE TOOL warrants the product to be free from defects in materials and workmanship under normal use and service. A defective product may be returned for a free replacement within 90 days from the date of purchase, provided that product is returned to place of purchase immediately after discovery of defect. After 90 days and up to 1 year from date of purchase, PERFORMANCE TOOL will replace at no charge any parts which our examination shall disclose to be defective and under warranty. These warranties shall be valid only when a sales receipt showing the date of purchase accompanies the defective product or defective part(s) being returned.

These warranties exclude blades, bits, punches, dies, bulbs, fuses, and other consumables which must be replaced under normal use and service. These warranties shall not apply to any product or part which is used for a purpose for which it is not designed, or which has been repaired or altered in any way so as to affect adversely its performance or reliability, nor shall these warranties apply to any product or part which has been subject to misuse, neglect, accident or wear and tear incident to normal use and service.

PERFORMANCE TOOL does not authorize any other person to make any warranty or to assume any liability in connection with its products.

Except for warranties of title and the limited express warranties set forth above, PERFORMANCE TOOL makes no express or implied warranties of any kind with respect to its products. In particular, PERFORMANCE TOOL makes no implied warranty of merchantability and no implied warranty of fitness for any particular purpose, except that for goods purchased primarily for personal, family or household use and not for commercial or business use, PERFORMANCE TOOL makes an implied warranty of merchantability (and, if otherwise applicable, an implied warranty of fitness for a particular purpose), but only for the particular qualities or characteristics, and for the duration, expressly warranted above. The laws on limitation of implied warranties may differ from state to state, so the above limitations may not apply in all cases.

PERFORMANCE TOOL shall not be liable for consequential, incidental or special damages resulting from or in any manner related to any product, or to the design, use, or any inability to use the product. The sole and exclusive remedy for a defective product or part shall be the repair, or replacement thereof as provided above. The laws on limitation of remedies or on consequential, incidental or special damages may vary from state to state, so the above limitations may not apply in all cases.

Metal Storage Bin Rack

Stock Number W5193

OWNER'S MANUAL



FOR YOUR SAFETY,
please read these instructions carefully and retain them for future use.

**Performance
Tool®**

SPECIFICATIONS

NOTE: Specifications are subject to change without notice.

Small Red Bins: 32 (5-1/2 x 3-1/4 in.)
 Large Blue Bins: 15 (8-1/4 x 5 in.)
 Rack Height: 45 in. Tall
 Rack Width: 37 in. Wide
 Rack Depth: 11 in. Deep
 Construction: Powder Coated Steel

TOOLS REQUIRED

- #2 Phillips head screwdriver
- 10 mm wrench or socket and ratchet

ASSEMBLY INSTRUCTIONS

1. Place the top tray upside down on a flat surface.
2. Position one of the L-bar frame legs on the inside of the brackets on the tray. NOTE: The tear drop shaped holes should be on the longer side of the tray, with the larger circle portion of the openings facing down.
3. Use a large screw, washer and nut to fasten the L-bar frame legs to the top tray brackets on both sides.
4. Place the base on the end of the legs, with the legs inside the brackets on the base, and fasten with a large screw, washer and nut.
5. Place the bottom bin support bracket on the bottom set of holes in the legs.
6. Align the holes in the base support brackets with the threaded holes on the base, and holes in the legs. Fasten the top holes with a large screw, washer and nut. Fasten the bottom holes with two small machine screws.
7. Insert remaining bin support brackets on to the legs. Make sure the 3 holes in the support bracket are closer to the top.
8. Align the vertical support bracket with the bolts on back of the bin support brackets, and lock into place.

PARTS LIST

| No. | Description | Qty. | No. | Description | Qty. |
|-----|--------------------------|------|-----|----------------------|------|
| 1 | Base | 1 | 6 | Top Tray | 1 |
| 2 | Base Support Brackets | 2 | 7 | Large Machine Screws | 18 |
| 3 | L-Bar Frame Legs | 2 | 8 | Round Washers | 18 |
| 4 | Bin Support Brackets | 7 | 9 | Hex Nuts | 18 |
| 5 | Vertical Support Bracket | 1 | 10 | Small Machine Screws | 2 |

Replacement Parts No. W5193HW Hardware kit (Nuts & Bolts)

