




20 LED FLEXIBLE  
WORK LIGHT  
INSTRUCTION MANUAL

**SB01AL**



**SAVE THIS INSTRUCTION MANUAL FOR FUTURE REFERENCE.**

# FEATURES



1. Light mode pushbutton (high/medium/off/flash)
2. 20 ultra bright LEDs
3. Flexible rubber groove stand
4. Back cover
5. Back cover screw
6. Magnetic discs (exposed to show details)
7. Battery compartment containing three (3) "AA" alkaline dry cell batteries (included)
8. Back cover screw hole
9. Battery strap
10. Light holder (locks light on stand)
11. Magnetic base
12. Attachment bar (for securing the light to the light holder)

## ⚠ GENERAL SAFETY WARNINGS AND INSTRUCTIONS

### READ ALL INSTRUCTIONS

**⚠ WARNING:** Read all instructions before operating spotlight. Failure to follow all instructions listed below may result in electric shock, fire and/or serious injury.

### SAFETY GUIDELINES / DEFINITIONS

**⚠ DANGER:** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

**⚠ WARNING:** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

**⚠ CAUTION:** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

**CAUTION:** Used without the safety alert symbol indicates potentially hazardous situation which, if not avoided, may result in property damage.

**RISK OF UNSAFE OPERATION.** When using tools or equipment, basic safety precautions should always be followed to reduce the risk of personal injury. Improper operation, maintenance or modification of tools or equipment could result in serious injury and property damage. There are certain applications for which tools and equipment are designed. Manufacturer strongly recommends that this product NOT be modified and/or used for any application other than for which it was designed. Read and understand all warnings and operating instructions before using any tool or equipment.

### IMPORTANT SAFETY INSTRUCTIONS

**⚠ WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK:**

- Do not put light in water or other liquid. Do not place or store appliance where it can fall or be pulled into a tub or sink.
- Keep light lamp away from materials that may burn.
- Do not clean this appliance with a water spray or the like.

**⚠ CAUTION: TO REDUCE THE RISK OF INJURY OR PROPERTY DAMAGE:**

**• Avoid dangerous environments:**

- Don't use the light in damp or wet locations. This unit is NOT waterproof. Do not immerse light in water or other liquids.
- Do not operate the light near flammable liquids or in gaseous or explosive atmospheres. Internal sparks may ignite fumes causing personal injury.

- Do not expose this unit to extremely high temperatures, flames or sparks.
- **To reduce the risk of injury**, close supervision is necessary when the light is used near children.
- **Store idle appliances indoors.** When not in use, appliances should be stored indoors in dry and high or locked-up places – out of reach of children.
- **Use of accessories and attachments.** Use only attachments recommended or sold by the manufacturer.
- **CHECK DAMAGED PARTS.** Before further use of the light, a guard or other part that is damaged should be carefully checked to determine that it will operate properly and perform its intended function. A guard or other part that is damaged should be properly repaired or replaced by an authorized service center unless otherwise indicated elsewhere in this instruction manual. Have defective switches replaced by authorized service center. Do not use light if switch does not turn it on and off.
- Do not operate this unit with a missing or damaged lens.
- Do not touch the LED surface at any time.
- Never look directly into the light or shine the light into another person's eyes.
- Do not disassemble the main body of the unit. Other than the 3 "AA" size dry cell batteries, there are no user-replaceable parts.

**⚠ WARNING: Batteries can explode, or leak, and can cause injury or fire. To reduce this risk:**

- Carefully follow all instructions and warnings on the battery label and package.
- Always insert batteries correctly with regard to polarity (+ and –), marked on the battery and the equipment.
- Do not short battery terminals.
- Do not charge batteries.
- Do not mix old and new batteries. Replace all of them at the same time with new batteries of the same brand and type.
- Remove dead batteries immediately and dispose of per local codes.
- Do not dispose of batteries in fire.
- Keep batteries out of reach of children.
- Remove batteries if the device will not be used for several months.

"Transporting batteries can possibly cause fires if the battery terminals inadvertently come in contact with conductive materials such as keys, coins, hand tools and the like. The US Department of Transportation Hazardous Material Regulations (HMR) actually prohibit transporting batteries in commerce or on airplanes (i.e. packed in suitcases and carryon luggage) UNLESS they are properly protected from short circuits. So when transporting individual batteries, make sure that the battery terminals are protected and well insulated from materials that could contact them and cause a short circuit."

# SAVE THESE INSTRUCTIONS

## INTRODUCTION

Congratulations on purchasing your new Flexible Work Light. **Read this Instruction Manual and follow the instructions carefully before using your new Flexible Work Light.**

## POWER SUPPLY

The unit is powered by three "AA" alkaline dry cell batteries (supplied). Unscrew the back cover screw (counter-clockwise) and remove the back cover. Gently pull the battery strap to remove the old batteries. Pull the strap gently so as not to break it. Insert batteries as described in compartment, making sure the battery strap is first replaced beneath the new batteries, observing the cautions that follow. Replace and secure the back cover by screwing the back cover screw clockwise. Do not be over-tighten.

**Note:** Use only "AA" alkaline dry cell batteries in this unit.

## CAUTIONS

- When replacing the "AA" alkaline dry cell batteries: DO NOT mix old and new batteries. Always insert batteries correctly with regard to polarity (+ and –), marked on the battery and the equipment. Remove dead batteries immediately and dispose of per local codes.
- Follow all warnings regarding batteries in the Important Safety Instructions section of this manual.

## OPERATING THE LIGHT

Position the unit, adjusting the flexible stand's legs or detaching the light and positioning using the magnetic discs as desired. Press the light mode pushbutton on the top of the unit.

- Press once for high intensity.
- Press again for medium intensity.
- Press a third time for to turn the light off.
- Press and hold the light mode pushbutton for about five seconds for flashing LEDs.

## Detaching the light from the flexible stand

TO DETACH THE LIGHT:

- Slide the attachment bar out of the light holder groove.
- Once the light is detached, the magnetic discs allow you to position it on any metallic surface.

TO ATTACH THE LIGHT BACK ON THE STAND:

- Slide the attachment bar back into the light holder groove.

## ⚠ CAUTION: TO REDUCE THE RISK OF PRODUCT DAMAGE:

- When light is attached using the either the flexible stand or magnetic discs, do not shake the light or object that it is attached to. Do not attach the light to any electrical wires or anything that it is not secure.

- Only use the flexible stand and magnetic discs for attaching the work light. The flexible stand and magnetic discs are not intended to support additional weight. Do not attach anything additional to the light or risk of breakage may occur.

## CARE AND MAINTENANCE

Never submerge the unit in liquids of any kind. If the unit gets dirty, gently clean the outer surfaces of the closed body casing with a soft cloth moistened with a mild solution of water and detergent.

Except for the batteries, there are no user-serviceable parts inside. Contact the manufacturer if any components have become worn or broken.

### Safe Battery Disposal

Refer to the Safety Warnings in the front of this Instruction Manual when selecting and replacing batteries. Always dispose of used batteries properly.

### **⚠ WARNING: TO REDUCE THE RISK OF INJURY/EXPLOSION:**

- Do not dispose of batteries in fire as this may result in an explosion.
- Do not expose the unit containing batteries to fire or intense heat as it may explode.

## SPECIFICATIONS

Work light:	20 bright white LEDs
Power source:	3 "AA" alkaline batteries (included)