Particulate Filters 2000 and 2200 Series, P100

User Instructions for 3M[™] Particulate Filter 2091/07000 (AAD), P100;

3M[™] Particulate Filter 2096. P100. with Nuisance Level Acid Gas Relief*

applicable government occupational exposure limits, whichever is lower.

PEL or applicable government occupational exposure limits, whichever is lower.

3M[™] Advanced Particulate Filter 2296, P100, with Nuisance Level Acid Gas Relief*;

3M[™] Advanced Particulate Filter 2297, P100, with Nuisance Level Organic Vapor Relief**.

P100 particulate filters and as Brazil Ministry of Labor approved P3 SL particulate filters.

Standard specific information is provided where applicable. All other information is common to both standards.

3MTM Particulate Filter 2097/07184 (AAD). P100. with Nuisance Level Organic Vapor Relief**: and

3M[™] Advanced Particulate Filter 2291, P100;

IMPORTANT: Keep these *User Instructions* for reference.

A WARNING

This filter helps protect against certain airborne contaminants. Misuse may result in sickness or death.

For use only with 3M 5000 series, 6000 series, 7000 series and FF-400 series half and full facepiece respirators according to the NIOSH approval label.

* 3M recommended for relief against nuisance levels of acid gases. Nuisance level acid gas refers to concentrations less than the OSHA PEL or

** 3M recommended for relief against nuisance levels of organic vapors. Nuisance level organic vapor refers to concentrations less than the OSHA

The 2091, 2096 and 2097 respirator filters have dual approval as United States (US) National Institute for Occupational Safety and Health (NIOSH)

07000 and 07184 are catalog numbers only. NIOSH approved as 3M 2091 P100 Particulate Filter and 3M 2097 P100 Particulate Filter.

2097/07184

98-0060-0067-7_5

34-8717-5678-8

IMPORTANT

Before use, the wearer must read and understand these User *Instructions* and the *User Instructions* for the 5000 series. 6000 series. 7000 series and FF-400 series half or full facepiece respirator to be used with these filters. These filters are NIOSH approved only for use with 3M 5000 series, 6000 series, 7000 series and FF-400 series half and full facepieces. Keep these User Instructions for reference.

Use For

Particulate Filters 2091 and 2291, P100

- Solids such as those from processing minerals, coal, iron ore, cotton, flour, and certain other substances.
- Liquid or oil based particles from sprays that do not also emit harmful vapors.
- Metal fumes produced from welding, brazing, cutting and other operations involving heating of metals.
- Radioactive particulate materials such as uranium and plutonium. Asbestos.

Particulate Filters 2096 and 2296, P100 with nuisance level acid gas relief*

- Solids such as those from processing minerals, coal, iron ore, cotton, flour, and certain other substances.
- Liquid or oil based particles from sprays that do not also emit harmful vapors.
- Metal fumes produced from welding, brazing, cutting and other operations involving heating of metals.
- Radioactive particulate materials such as uranium and plutonium - Asbestos.
- 3M recommended for relief from nuisance levels of acid gases such as sulfur dioxide, hydrogen fluoride and/or chlorine.

* Nuisance level acid das refers to concentrations less than the OSHA PEL or applicable occupational exposure limits, whichever is lower.

Particulate Filter 2097 and 2297, P100 with nuisance level organic vapor relief**

- Solids such as those from processing minerals, coal, iron ore, cotton, flour, and certain other substances.
- Liquid or oil based particles from sprays that do not also emit harmful vapors.
- Metal fumes produced from welding, brazing, cutting and other operations involving heating of metals.
- Radioactive particulate materials such as uranium and plutonium.
- Asbestos.
- 3M recommended for ozone protection up to 10 times the OSHA PEL (Not NIOSH certified for use against ozone).
- 3M recommended for relief from nuisance levels of organic vapors. ** Nuisance level organic vapor refers to concentrations less than the OSHA PEL or applicable government occupational exposure limits, whichever is lower.

Do Not Use For

Particulate Filter 2091 and 2291, P100

- Do not use for gases and vapors when concentrations are at or above the OSHA PEL, or applicable government regulations, whichever is lower, including those present in paint spraying operations, unless combined with approved chemical cartridges.
- Do not use for sandblasting.

Particulate Filter 2096 and 2296, P100 with nuisance level acid gas relief*

Do not use for gases and vapors when concentrations are at or above the OSHA PEL, or applicable government regulations, whichever is lower, including those present in paint spraving operations, unless combined with approved chemical cartridges.

** Nuisance level organic vapor refers to concentrations less than the OSHA PEL or applicable government occupational exposure limits. whichever is lower.

3. Do not alter, clean (e.g. vacuum, wash, use compressed air), abuse or misuse these filters and/or respirator.

4. Do not use with beards or other facial hair or other conditions that prevent a good seal between the face and the sealing surface of the respirator.

Do not use for sandblasting.

* Nuisance level acid gas refers to concentrations less than the OSHA PEL or applicable occupational exposure limits, whichever is lower.

Particulate Filter 2097 and 2297. P100 with nuisance level organic vapor relief**

- Do not use for gases and vapors when concentrations are at or above the OSHA PEL, or applicable government regulations, whichever is lower, including those present in paint spraving operations, unless combined with approved chemical cartridges.

- Do not use for ozone when concentrations exceed 10 times the OSHA PEL

- Do not use for sandblasting.

Biological Particles

These particulate filters can help reduce inhalation exposures to certain airborne biological particles (e.g. mold, Bacillus anthracis, avian influenza. Mycobacterium tuberculosis, etc.) but cannot eliminate the risk of contracting infection, illness or disease, OSHA and other government agencies have not established safe exposure limits for these contaminants.

Use Instructions

1. Failure to follow all instructions and limitations on the use of these filters and/or failure to wear the respirator during all times of exposure can reduce respirator effectiveness and may result in sickness or death.

2. Before occupational use of these filters, a written respiratory protection program must be implemented meeting all the local applicable requirements. In the U.S., follow OSHA 29 CFR 1910.134 which includes medical evaluation, training and fit testing. In the U.S., users must also comply with applicable OSHA substance specific standards. In Canada, CSA standard Z94.4 requirements must be met and/or requirements of the applicable jurisdiction, as appropriate. In Brazil, follow the requirements of the Respiratory Protection Program of the Ministry of Labor.

3. The airborne contaminants which can be dangerous to your health include those so small that you cannot see them.

4. Leave the contaminated area immediately and contact your supervisor if you smell or taste contaminants or if dizziness. irritation, or other distress occurs.

5. Store the filters and respirator away from contaminated areas when not in use

6. Dispose of used product in accordance with applicable regulations.

Use Limitations

1. These filters do not supply oxygen. Do not use in atmospheres containing less than 19.5% oxygen.

2. Do not use when concentrations of contaminants:

- are immediately dangerous to life or health,
- are unknown.
- exceed the 3M recommendations in the "Use For" and "Do Not Use For" sections of these User Instructions.
- are greater than 10 times the permissible exposure limit (PEL) with half facepiece respirators and full facepiece respirators when qualitatively fit tested,
- are greater than 50 times the PEL with full facepiece respirators when quantitatively fit tested, or
- exceed specific local applicable government regulations (such as OSHA standards in the U.S.) or other applicable government regulations, whichever is lower.

In Brazil, according to the Respiratory Protection Program of the Ministry of Labor. do not use when concentrations of contaminants are greater than 10 times the permissible exposure limit using a half facepiece or 100 times the permissible exposure limit using a full facepiece.

Time Use Limitations

- 1. If filters become damaged, soiled or breathing becomes difficult, leave the contaminated area immediately and replace the filters.
- 2. If used in environments containing only oil aerosols, dispose of filters after 40 hours of use or 30 days, whichever is first.
- 3. If used for ozone protection (3M 2097 and 2297 P100 Particulate Filter and nuisance level organic vapor), replace filters in accordance with an established change schedule, or earlier if smell, taste or irritation from contaminants is detected.

Storage Conditions and Shelf Life

Before use, store filters in the original packaging, away from contaminated areas, dust, sunlight, extreme temperatures, excessive moisture and damaging chemicals. When stored in accordance with temperature and humidity conditions specified below, the filter may be used until the "use by" date specified on packaging. Always inspect product and conduct a user seal check before use as specified in the respirator User Instructions. If you cannot achieve a proper seal, do not enter the contaminated area. See your supervisor.



End of Shelf Life Use respirators before the "use by" date specified on packaging



Storage Temperature Range -20°C (-4°F) to +30°C (+86°F)



Storage Maximum Relative Humidity <80% RH

NIOSH Approved: P100 Particulate Filter

At least 99.97% filtration efficiency against solid and liquid aerosols including oils.

For Compliance in Brazil NOTE: Particulate Filters 2091, 2096, 2097, P3 SL

In Brazil, Ministry of Labor approved as filter class P3 SL. NOTE:

- 1. In Brazil do not use when concentrations of contaminants are greater than 100 times the permissible exposure limit using full facepiece.
- Do not use in deficient or enriched oxygen atmospheres.
- 3. Storage, Transportation and Care: store in a clean and dry place and away from contaminants and extreme temperature and humidity.
- 4. The components of this filter are made of materials which are not expected to cause adverse health effects.
- 5. It is necessary to have special care to use this product in explosives atmospheres.



THIS FILTER IS APPROVED ONLY IN THE FOLLOWING CONFIGURATIONS:



			HIS FILTE	R IS APP	ROVED C	ONLY IN T	'HE FOL	LOWING	CONFIG	URATIO	NS:												per		RCOMP	ONENTO																						7	
		Yane and A		SPIRATOR							CEPIECE									SECUP	TERNATE SENTER DAPTER	ASSEMBLY	/E COVER TERNATE	R ADAPTER TERNATE							TERNATE EATHING	TERNATE	VE ADAPTER	TERNATE GULATOR	TERNATE	BELTS	.DER STRAP		HOSE					ESSORIES					
						AL									AL T					ON	A OF	VALVE	AL	FILTE AL				CAL				AL.	AL	AIRLIN	RE AL	PL.		SHOUL		AL.					ACCI				
		PROTECTION ¹			5302 5103 5203	5303 5104	5204 5304	5105 5205 5305	5106 5206	6200 6200	6300 6100DD	6200DD 6300DD 7501	7503 7501F 7501F	7503F 6700	6800 6900 7800SmS	7800MS	FF-401 FF-402 FF-403	6501 6502	6501QL 6502QL	6503QL 6894	6884 6874 6864	7890 W-3231	FF-400-10 701		7988 6001 6001i	6001CN 6001iCN	6002 6002CN 6003	6003CN 6004	6004CN 6005 6005CN	6006 6006	6009 6009CN	6009S W-3188 SA-1600	SA-2600 W-3238	W-3187 W-3253 W-3255	W-3232 SA-1009	SA-1029 GVP-127 W-3217	W-2963 520-02-23	W-3229 W-9435-25 W-9435-50	W-9435-100 W-2929-25	W-2929-50 W-2929-100 W-3020-25	W-3020-50 W-3020-100	7883 6885 6886	6878 7915	7993 7925 7894	7986 7899	7990 7991 FF-400-15	FF-400-17 FF-400-20 FF-400-06	LIM	AND ITATIONS ² / RTISSEMENTS ET TRICTIONS ²
	84A-1029 84A-1030 84A-1031 84A-1032 84A-1033 84A-1034	OV/CL/HC/SD/HF/P100/HS > AM/MA/P100 > OV/FM/P100 > OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100 > P100 > OV/P100 >	x x				X X		X X 2	ХХ	ХХ	хххх	(X											X X X X X X X X																								ABC ABC ABC ABC ABC ABC	CHJLMNOP CHJLMNOP CHJKLMNOP CHJKLMNOP BCJLMNOP CHJLMNOP
	84A-4596 84A-7111 84A-1035 84A-5056 84A-1036 84A-5057	OV/P100 > OV/P100 > SD/HC/CL/CD/HS/P100 > SD/HC/CL/CD/HS/P100 > OV/SD/HC/CL/HS/P100 > OV/SD/HC/CL/HF/HS/P100 >								X X X X X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X X	X X X X X X X X												X X X X X X X X X X		X X																						ABC ABC ABC ABC ABC ABC	CHJLMNOP CHJLMNOPS CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP
	84A-5858 84A-1038 84A-5859 84A-1039 84A-5860 84A-1040	AM/MA/P100 > OV/FM/P100 > OV/FM/P100 > OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100 > OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100 > MV/CL/P100 >	x x x x x x x x x x x x x x x x x x x							X X X X X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X	X X X X X X X X												X X X X X X X X X X X X X X X					X X // // // // // // // // // // // //																			ABC ABC ABC ABC ABC ABC	CHJLMNOP CHJKLMNOP CHJKLMNOP CHJKLMNOP CHJKLMNOP CHJLMNOPS
	84A-2050 84A-2121 84A-7369 84A-7370 84A-7371 84A-7372	P100/SA/CF > P100/SA/CF > P100 > OV/P100 > OV/P100 > SD/HC/CL/CD/HS/P100 >	x							ХХ	ХХ	хххх		X X										X			x x													X X / / / / / / / / / / / / / / / / / /								ABCD ABCD AB AB AB AB AB	DEGJLMNOPS DEGJLMNOPS DCJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP
	84A-7374 84A-7375 84A-7376 84A-7377 84A-7378 84A-1074 84A-1075	OV/FM/P100 > OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100 > MV/CL/P100 > SD/MV/CL/P100 > P100 > OV/P100 >												x x x x x x x x x x x x x x x x										X X X X X X X X X X X X X X X X X X X					X	X 	X	X										ххх	ххх	Х				ABC ABC ABC ABC ABC ABC	CHJKLMNOP CHJKLMNOP CHJLMNOPS CHJLMNOP CHJLMNOP CHJLMNOP
	84A-4605 84A-7129 84A-1076 84A-5078 84A-1077 84A-5079 84A-1078	OV/P100 > OV/P100 > SD/HC/CL/CD/HS/P100 > SD/HC/CL/CD/HS/P100 > OV/SD/HC/CL/HF/HS/P100 > OV/SD/HC/CL/HF/HS/P100 > AM/MA/P100 >													X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X						X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X			X X		X X X																X X X X X X	X X X X X X	X X X X X X X X X X X X X X X X X X X X				ABC ABC ABC ABC ABC ABC ABC ABC	CHJLMNOP CHJLMNOPS CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP
	84A-1079 84A-5943 84A-1080 84A-5944 84A-1081 84A-5945 84A-6295	OV/FM/P100 > OV/FM/P100 > OV/SD/HC/CL/CD/HF/HS/AM/MA/FM/P100 > OV/SD/HC/CL/CD/HF/HS/AM/MA/FM/P100 > MV/CL/P100 > MV/CL/P100 > SD/ MV/CL/P100 >												X X X X X X	X X X X X X X X X X X X						X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X			X X X X X X X X X X X																		X X X X X X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X				ABC ABC ABC ABC ABC ABC ABC	CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOPS CHJLMNOPS CHJLMNOPS
	84A-2226 84A-3487 84A-3488 84A-7044 84A-3489 84A-3490 84A-3491	P100/SA/CF > P100/SA/CF > OV/P100/SA/CF > OV/P100/SA/CF > SD/HC/CL/CD/HS/P100/SA/CF > OV/SD/HC/CL/HF/HS/P100/SA/CF > AM/MA/P100/SA/CF >													X X X X X X X X X X X X X X X X X X X X X X					X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X			X 1 X 2 X 2 X 2 X 2 X 2 X 2 X 2 X 2	X	X	X X					X X X X X X X X X X		X X X X X X X X X X X X				X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X				X X X X X X		x x x x x x x x x x x x x				ABCD ABCD ABCD ABCD ABCD ABCD ABCD ABCD	DEGJLMNOPS DEGJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS
	84A-3493 84A-3494 84A-6349 84A-3584 84A-3585 84A-7055	OV/SD/HC/CL/CD/HF/HS/AM/MA/FM/P100/SA/CF X MV/CL/P100/SA/CF X SD/MV/CL/P100/SA/CF X P100/SA/PD X OV/P100/SA/PD X OV/P100/SA/PD X													X X X X X X X X X X X X X X X X X X X X X X					X X X X X X X X X X X X	X X X X X X X X X X X			X X X X X X X X X		x			X		X X 				`			X X X X X X X X X X X X X X X		XX		X X X X X X	X X X X X X X X X X X X X X X X X X	X X X X X X X				ABCDI ABCDI ABCDI ABCDI ABCDI ABCDI	EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS DEGJLMNOPS EGHJLMNOPS EGHJLMNOPS
	84A-3588 84A-3589 84A-3590 84A-3591 84A-6360 84A-1042 84A-1043	AM/MA/P100/SA/PD >> OV/FM/P100/SA/PD >> OV/SD/HC/CL/CD/HF/HS/AM/MA/FM/P100/SA/PD >> MV/CL/P100/SA/PD >> SD/MV/CL/P100/SA/PD >> P100 >>	`											X X	X X X X					X X X X X X X X X	X X X X X X X X			X X X X X X X X X X X X X X	X X				X		X	X	X X X X X X X X		X X X X X X X X X			X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X	(XX XX	X X X X		X X X X X X X X X X X X	X X	X				ABCDI ABCDI ABCDI ABCDI ABCDI ABCDI	EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS 8CJLMNOP
	84A-4614 84A-7165 84A-1044 84A-5112 84A-1045 84A-5113	OV/P100 > OV/P100 > SD/HC/CL/CD/HS/P100 > SD/HC/CL/CD/HS/P100 > OV/SD/HC/CL/HS/P100 > OV/SD/HC/CL/HF/HS/P100 >														X X X X X X X X X X X X X X X X X X X X						X X X X X X X X X	X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X X	X X X																	X X X X X X X X	X X X X X X X X X X X X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X		ABC ABC ABC ABC ABC ABC ABC	CHJLMNOP CHJLMNOPS CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP
	84A-1047 84A-6111 84A-1048 84A-6112 84A-1049 84A-6113	OV/FM/P100 > OV/FM/P100 > OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100 > OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100 > MV/CL/P100 > MV/CL/P100 >														X X X X X X X X X X X X X X X X X X						X X X X X X X X X	X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X				X X // // // // // // // // // // // //			X											X X X X X X X X X	X X X X X X X X X X X X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X X X X X X X X X X X X	X X X X X X		ABC ABC ABC ABC ABC ABC	CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOPS CHJLMNOPS
	84A-2296 84A-1050 84A-1051 84A-7066 84A-1052 84A-1053	P100/SA/CF > P100/SA/CF > OV/P100/SA/CF > OV/P100/SA/CF > SD/HC/CL/CD/HS/P100/SA/CF > OV/SD/HC/CL/HF/HS/P100/SA/CF >	x													X X X X X X X X X X X X X X X X X X						X X 	X X X X X X X X X X X	X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X	X	X X					X X X X X X X X X X		X X X X X X						X X 			X X X X X X X	X X X X X X X X X X X X X X X X X X X X X X X X X X X	(X X (X X (X X (X X	X X X X X X X X		ABCD ABCD ABCDI ABCDI ABCDI ABCDI	DEGJLMNOPS DEGJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS
	84A-1056 84A-1057 84A-6379 84A-1066 84A-1067 84A-7077	OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100/SA/CF X MV/CL/P100/SA/CF X SD/MV/CL/P100/SA/CF X P100/SA/PD X OV/P100/SA/PD X OV/P100/SA/PD X														X X X X X X X X X X X X X X X X X X X X							X X X X X X X X X X X	X X X X X X X X X X X X X X X X	X X X X X X X X X X X X X X X X X X X	X	X											X X X X X X X X X X X X X X X X X X X X					X X X X X X X X	X X X X X X X X X X X X X X X X X X X X X X X X X X X		X X 		ABCDI ABCDI ABCDI ABCDI ABCDI ABCDI	EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS DEGJLMNOPS EGHJLMNOPS EGHJLMNOPS
	84A-1069 84A-1070 84A-1071 84A-1072 84A-1073 84A-6390 84A-4871	OV/SD/HC/CL/HF/HS/P100/SA/PD >> AM/MA/P100/SA/PD >> OV/FM/P100/SA/PD >> OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100/SA/PD >> MV/CL/P100/SA/PD >> SD/MV/CL/P100/SA/PD >> P100 >>	X													X X X X X X X X X X X X X X X X X X X X X X X X X X							X X X X X X X X	X X X X X X X X X X X X X X X X X X X X					X	X	X	X	X X X X X X X X		X X X X X X X X			X X X X X X		X X X X X X			X X	X X X X X X	(X X (X X	X X X X X X 		ABCDI ABCDI ABCDI ABCDI ABCDI ABCDI (AB	EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS EGHJLMNOPS BCJLMNOP
Aussel Aussel Machine X	84A-7089 84A-4873 84A-7147 84A-4874 84A-5134 84A-4875 84A-5135	OV/P100 > OV/P100 > OV/P100 > SD/HC/CL/CD/HS/P100 > SD/HC/CL/CD/HS/P100 > OV/SD/HC/CL/HF/HS/P100 > OV/SD/HC/CL/HF/HS/P100 >	`														x x						× × × × × × × × ×	X X X X X X X X X X X X X X																							(X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X	(ABC (ABC (ABC (ABC (ABC (ABC (ABC (ABC (ABC	CHJLMNOPS CHJLMNOP CHJLMNOPS CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP
84.499 P100SACE X <	84A-6026 84A-4877 84A-6027 84A-4878 84A-6028 84A-6028 84A-6029	AM/MA/P100 X OV/FM/P100 X OV/FM/P100 X OV/SD/HC/CL/CD/HF/HS/AM/MA/FM/P100 X OV/SD/HC/CL/CD/HF/HS/AM/MA/FM/P100 X MV/CL/P100 X MV/CL/P100 X	X														X X X X X X						× X X X X X X X X	× X					X X // // // // // // // // // // // //																		(X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X (X X X	(AB((AB((AB((AB((AB((AB((ABC (ABC	CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOPS CHJLMNOPS
84.6488 SDHC/CL/CP/HS/P100 X </td <td>84A-4949 84A-4984 84A-6466 84A-6599 84A-6467 84A-7196 84A-6600</td> <td>P100/SA/CF X P100/SA/CF X P100 X P100 X OV/P100 X OV/P100 X OV/P100 X</td> <td></td> <td>X X X X X X X X</td> <td>X X X X X X X X X X X X</td> <td>X X X X</td> <td></td> <td></td> <td></td> <td>X X</td> <td>Х</td> <td></td> <td>X</td> <td>< x x x</td> <td>(ABCD (ABCD AB AB AB AB AB (ABC ABC</td> <td>DEGJLMNOPS DEGJLMNOPS BCJLMNOP BCJLMNOP CHJLMNOP CHJLMNOPS CHJLMNOP</td>	84A-4949 84A-4984 84A-6466 84A-6599 84A-6467 84A-7196 84A-6600	P100/SA/CF X P100/SA/CF X P100 X P100 X OV/P100 X OV/P100 X OV/P100 X																X X X X X X X X	X X X X X X X X X X X X	X X X X				X X	Х																					X	< x x x	(ABCD (ABCD AB AB AB AB AB (ABC ABC	DEGJLMNOPS DEGJLMNOPS BCJLMNOP BCJLMNOP CHJLMNOP CHJLMNOPS CHJLMNOP
84-6472 0////////////////////////////////////	84A-6468 84A-6601 84A-6469 84A-6602 84A-6602 84A-6603 84A-6603	SD/HC/CL/CD/HS/P100 > SD/HC/CL/CD/HS/P100 > OV/SD/HC/CL/HF/HS/P100 > OV/SD/HC/CL/HF/HS/P100 > AM/MA/P100 > OV/FM/P100 >																X X X X X X X X X X X X X X X X X X X X X X X X	X X X X X X	X				X X X X X X X X																								ABC ABC ABC ABC ABC ABC	CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP CHJLMNOP CHJKLMNOP
84A-6929 P100/SA/CF X I I I I I I I I I I I I I I I I I I	84A-6604 84A-6472 84A-6605 84A-6473 84A-6606 84A-6474 84A-6885	OV/FM/P100 > OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100 > OV/CL/CD/HC/AM/MA/SD/HF/HS/FM/P100 > MV/CL/P100 > MV/CL/P100 > SD/MV/CL/P100 > P100/SA/CF >																X X X X X X X X X X X X X X X X X X X X X X X X X X X X	X X X X X X	X X X X X X X X				X X X						X	X X				~						_							ABC ABC ABC ABC ABC ABC ABC	CHJKLMNOP CHJKLMNOP CHJKLMNOP CHJLMNOPS CHJLMNOPS CHJLMNOPS DEGJLMNOPS

1. PROTECTION P100 - Particulate Filter (99.97% filter efficiency level) effective against all particulate aerosols.

OV - Organic vapor SD - Sulfur dioxide

- HC Hydrogen chloride CL Chlorine
- CD Chlorine dioxide
- HF Hydrogen fluoride
- HS Hydrogen sulfide
- AM Ammonia
- MA Methylamine
- FM Formaldehyde
- MV Mercury vapor
- SA Supplied-Air
- CF Continuous flow
- PD Pressure demand

2. CAUTIONS AND LIMITATIONS

A - Not for use in atmospheres containing less than 19.5 percent oxygen.
 B - Not for use in atmospheres immediately dangerous to life or health.

C - Do not exceed maximum use concentrations established by regulatory standards.

D - Air-line respirators can be used only when the respirators are supplied with respirable air meeting the requirements of CGA G-7.1 Grade D or higher quality.

E - Use only the pressure ranges and hose lengths specified in the User's Instructions.

G - If airflow is cut off, switch to filter and/or cartridge or canister and immediately exit to clean air.

H - Follow established cartridge and canister change schedules or observe ESLI to ensure that cartridge and canisters are replaced before breakthrough occurs.

J - Failure to properly use and maintain this product could result in injury or death. K - The Occupational Safety and Health Administration regulations require gas-proof goggles to be worn with this respirator when used against formaldehyde.

L - Follow the manufacturer's User's Instructions for changing cartridges, canister and/or filters. M - All approved respirators shall be selected, fitted, used, and maintained in accordance with MSHA, OSHA, and other applicable regulations.

N - Never substitute, modify, add, or omit parts. Use only exact replacement parts in the configuration as specified by the manufacturer.

O - Refer to User's Instructions, and/or maintenance manuals for information on use and maintenance of these respirators.

P - NIOSH does not evaluate respirators for use as surgical masks.

S - Special or critical User's Instructions and/or specific use limitations may apply. Refer to User's Instructions before donning.

HS(esc) - Hydrogen sulfide (escape only)