


Speedglas Welding Safety

3M<sup>™</sup> Speedglas<sup>™</sup> Welding Safety Catalog 2018

# Do your best with our best welding helmets



One of the most important lessons we have learned over the last 35 years is that no two welders are the same.

# How to find your customized welding helmet combination

We have compiled—into this one, easy-to-reference catalog—much of the information you'll need to select specific welding safety products and/or entire welding PPE systems.

From the choices below, pick your key selecting factor and then go directly to that chapter. Or try our main <u>selection guide</u> on page 24.



### Your responsibility—our solutions...

Typically, professional welders know about the hazards to their eyes and faces. But other hazards—like welding fumes—are sometimes not so well known.

It is the responsibility of the employer to identify any hazards in a work environment, and to provide the workers with adequate protection.

Hazards must be adequately explained. Then ideally the choice of protective equipment can be made after a joint consultation between employers and employees.



#### 1. Identify the hazards

Make a list of all the hazards in your welding environment (radiation, sparks, fumes, noise, trip hazards, falling objects, etc).



#### 2. Assess the risk levels

By evaluating every hazard, you can prioritize their mitigation. See more details in each section of this catalog. If there are any doubts or ambiguities, always consult a professional health and safety engineer.



#### 3. Select the right type of equipment

Determine your protection based on equipment type (e.g., eye, face, head, hearing), the level of protection needed to work in a specific application, and your users' preferences. Personal preferences - a key to user acceptance - covers issues including comfort, style, and ease of maintenance.



#### 4. Training, motivation and maintenance

For maximum benefit from any piece of PPE, it pays to focus on user acceptance and proper use. 3M can help:

On-site training by 3M personel or a visit from our Safety Roadshow.
 We'll show you equipment options based on your needs.



#### I need to weld with greater clarity

Truer colors and contrasts with 3M™ Speedglas™ Natural Color Technology: see page 14



#### I want to see around me

We recommend our welding helmets with side windows that widen your field of vision when welding: see page 26



### I want to breathe fresh air

Our powered respirators are a favorite among many welders: see page 44



#### l do precise *grinding*

Check out our welding helmets with flip-up visors, they have a curved, clear protective visor underneath the welding filter: see page 31–33




#### I like lightweight welding helmets

Great! Try our most lightweight auto-darkening welding helmet: Speedglas SL, see page 36

### Your eyes

How to beat the statistics	
The science behind 3M auto-darkening technology	
Pay-off in productivity and performance	10
Selector 1 - decision tree for welding filters	1:
3M <sup>™</sup> Speedglas <sup>™</sup> Natural Color Technology	14
3M <sup>™</sup> Speedglas <sup>™</sup> Auto-Darkening Filters	10
3M <sup>™</sup> Evewear - selection for welding helmet users	18



### 90% of injuries preventable with proper protection:

More than 90% of serious eye injuries at work can be prevented using appropriate protective eyewear.

1/4
of all welding injuries is of the eye



Eye injuries account for one quarter of all welding injuries, making them by far the most common injury for

#### How to beat the statistics

Welding processes typically generate hazardous ultraviolet/ infrared radiation and (intense) visible light that have the potential to cause permanent eye damage. Physical eye hazards include welding spatter and grinding particles.

#### **Controlling exposure**

A well-designed welding helmet and filter has a positive influence on the protection of your face and eyes from heat, spatter and radiation.

Put simply, auto-darkening welding filters allow welders to keep their welding helmet in place much more often than passive welding filters.

If you can see well, the motivation to constantly lift your shield is significantly reduced, meaning:

- You may reduce the likelihood of exposure to harmful UV/IR radiation by accidentally striking an arc. Or being exposed to the arcs of nearby welders.
- You may reduce the potential for foreign body eye injuries from grinding swarf or weld spatter.

# When the helmet is worn properly, the UV/IR bandpass filter is always in place and will provide protection from hazardous light radiation. This protection is maintained throughout the entire welding process.

### Improving upon what the welder sees

Your goal is to weld consistently great welds. Our goal is to provide you with eye and face protection and also improved optics for better clarity.

"Because we make many of our own welding filter components, we can readily test and transfer new technologies," says Kristina Magnusson, Senior Optics Specialists at the 3M Welding Center of Excellence. "And, of course, this allows better control over the entire manufacturing process."

Kristina is one of the Center's four full-time optics specialists. Her responsibilities include liquid crystal cells, polarizers, and interference (UV/IR) filters. She also leads an international ISO task group of experts focused on eye and face protection standards for auto-darkening welding filters.

Like many of her co-workers, Kristina is a long-time employee. "I had just got my master's degree in engineering physics with a focus on optics when I was recruited to develop test instruments to measure the light diffusion of Speedglas welding filters. I've been here ever since.



"Of course, safety is the prime consideration when it comes to welding PPE. But the 3M optics team aims to help welders even more by continuously improving the optical experience of our welding filters. "We're constantly exploring new optical technologies that we can leverage to the welder's advantage."

#### How auto-darkening filters work



#### **Before:**

With the helmet in the safe down position, you have a clear view through the welding filter. Both of your hands are free and the electrode can be precisely positioned.



#### **During:**

Within a millisecond of the arc strike (for 3M™ Speedglas™ Welding Filters, see page 13), the filter has switched to the dark state.



#### After:

The filter automatically returns to the clear state after welding is complete, allowing your immediate inspection of the weld pool, as well as preparation for the next weld.


# What other equipment pays for itself in two months?

Not only can you weld faster when you can see more clear, but your entire movement around your workpiece can become more efficient when you're not constantly having to raise and lower your shield.

We've studied welders and their increased efficiency when using our auto-darkening filters (ADFs) for almost four decades:

- The shorter the weld, the greater the productivity increase. Not surprising, applications requiring lots of tack welds have the most to gain.
- Where the final appearance of the weld is critical—for example, on high-value items reduction in scrap alone (e.g., from bad starts) can quickly pay for our helmets.
- Since most welders do a combination of tack and longer welds, we use an estimate of 15% gain in productivity. Of course, results may vary depending on your specific operation.

So, for example, if you're paying a welder \$20 per hour, a 15% improvement in productivity will pay for a \$450 helmet in about two months and result in a year-end increase in savings (new profits) of \$4500 when compared to continuing to use passive filters. Note: USD amounts are approximate and may vary.



\$28,280

Average cost of injuries to the face, including disabling and non-disabling eye injuries.<sup>1)</sup>

20,300

Lost work days in 2012<sup>1)</sup>

### Ask yourself

Are you doing everything possible to maximize the amount of time your welders have their shield in the safe, down position?



# A sample decision tree when selecting a welding filter

- Would you benefit from seeing more natural colors and contrasts?

  The 3M™ Speedglas™ Auto-darkening Filters 9100XXi and 9002NC both allow you to more readily recognize colors. The light state is still shade 3, but the filter appears lighter, more detailed, and better able to view contours. More details on page 14–15.
- Do you occasionally change shade numbers?

  If yes, you have plenty of models to pick from: all of our auto-darkening filters have variable (selectable) dark shades, as shown in the table on page 13.
- What does your welding process require from your filter?
  This is a key decision factor. Using the table on page 13, pick a model that does well in the processes you use frequently.

You might want to also consider your needs for specific dark shade levels, light-to-dark switching sensitivity, and dark-to-light delay options which are features that vary from model to model.

- How important is the size of the welding filter's viewing area?

  For many welders, the ability to see more of their workpiece without moving their helmet or head is very important. For these "big picture" people, the 9100XX or 9100XXi models will be most appropriate.
- Do you do a lot of tack welding?

  Then our tack welding comfort mode may be for you. The comfort mode setting may help reduce eye fatigue caused by your eye constantly adjusting to differing light levels during tack welding. It's available on 9100XX, 9100X and 9100V filters.

#### Recommended shade numbers according to ANSI Z49.1:2012

Welding process		Current in amperes A																				
	1.5	6	10	20	30	40	60	80	100	125	150	160	200	225	250 3	00 35	0 400	450	500	700	800	900 1000
Shielded Metal Arc									10				12			1	4					
Gas Metal Arc Welding									11				12			14						
Gas Tungsten Arc Welding			10	0				12							14							
Air Carbon Arc Cutting										12											14	
Plasma Arc Welding		6–8				10							12						14			
Plasma Arc Cutting		4		5	5	6	8				(	9				12			14			
Carbon Arc Welding													14									
	1.5	6	10	15	30	40	60	80	100	125	150	160	200	225	250 3	00 35	0 400	450	500	700	800	900 1000

The table recommends best dark shade of welding filter for various working applications.

According to the conditions of use, the next greater or the next smaller scale number can be used.

#### **3M™ Speedglas™ Auto-Darkening Filters**

### Selector table

				Best <sup>1)</sup>	Better¹)	Good <sup>1)</sup>	×Not Rec	ommended <sup>1)</sup>
Specification	9100XXi	9100XX	9100X	9100V	SL	9002NC	100V	10V
MMAW (electrode)	•	•	•	•	•	•	•	•
MIG/MAG	•	• •		•	•	•	•	•
TIG (>20A)	•	•	•	•	•	•	•	•
TIG (1A-20A)	•	•	•	•	•	•	×	×
Plasma (welding and cutting)	•	•	•	•	•	•	×	×
Risk for hidden arc	•	•	•	•	•	•	×	×
Tack welding	•	•	•	•	•	•	•	•
Grinding	•	•	•	•	×	•	•	•
3M <sup>™</sup> Speedglas <sup>™</sup> Natural Color Technology	Yes		N	lo .		Yes	N	lo
Switching time, dark-light	40-800 ms		40-1 300 ms		60-250 ms	60-400 ms	40-250 ms	60-250 ms
Switching time, light -dark				0.1 ms	(+23° C)			
Dark state		Shade 5	, 8, 9–13			Shade	8–12	
Light state				Sha	de 3			
UV/IR Protection (permanent)		Shac	de 13			Shade 12		Shade 13
Viewing area, approx.	2.8") (73×10	( 4.2" 17 mm)	2.1 "x 4.2" (54×107 mm)	1.8" x 3.7" (45×93 mm)	1.68" x 3.57" (43×91 mm)	2.13" x 4.09" (54×107 mm)	1.73" x (44×9	3.66" 3 mm)
External grinding mode control	Yes <sup>2)</sup>				No			
Auto ON	Yes		No		Yes		No	
Solar cell	N	0	Y	es		N	0	
Battery lifetime (hours)	1800	2 000	2 500	2 800	1500	2 000	15	00
Number of sensors (arc detection)		3 2						
Classification (perEN 379)		1/1/	1/2		1/1/1/2	1/1/1/2	1/2/2/2	1/2/2/2
Approval (welding filter)		ANSI Z8	7.1 - 2010		ANSI Z87.1 - 2003	ANSI Z87.1 - 2015	ANSI Z87.1 - 2003	ANSI Z87.1 - 2010

1) The ratings (best - better - good - not recommended) above refer to the products listed in this chart and should be seen as general recommendations based on differences in product comfort features and configuration options when using these selected Speedglas welding helmet series.

2) When used with the front cover 9100XXi and the 3M™ Speedglas™ Welding Helmets 9100, 9100-QR or 9100-Air, see page 28.



# Still seeing green?

Imagine what more realistic-looking colors and details could do for you:

- Provide better control of your weld puddle with a view that appears lighter, brighter, and more realistic.
- Help you focus on your welding set-up, welding technique, and inspection of just-completed welds.
- Give you a clearer view of colored welding machine controls—even with your helmet in the safe, down position.

See the difference!









66

The view seems lighter and less green—I can see colors far better! Even in the dark state, I see contours better.

Veteran Welder

"





Great clarity before, during and after welding when using the 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Filters 9100XXi or 9002NC. Such clarity can be great for seeing the nuances of curved joints.

### Your choice of autodarkening filters (ADF)

The 3M™ Speedglas™ Welding Filter Series 9100 continues our tradition of outstanding optical quality, including uniform shading and minimal distortion across the entire filter viewing area.

By selecting just the right setting for each task, you can reduce eye strain and improve the quality of every weld.





#### 3M™ Speedglas™ Auto-**Darkening Filter 9100XXi:**

- See your welds in a new light, with more contrast and natural-looking colors.
- Grab and go welding with Auto-ON.
- 2.8 × 4.2 in. viewing area.
- Dark shades 5, 8, and 9 through 13.
- · Delay settings allow the welder to extend the dark state for when the weld pool is still cooling.
- For all 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet Series 9100. See page 26-33.
- When used with the special 9100XXi Silver Front Panel and the Speedglas Welding Helmets 9100, 9100-Air and 9100-QR, you'll have access to the external control for both grinding and the memory modes. More details on page 29.





#### 3M™ Speedglas™ Auto-Darkening Filter 9100XX

- 2.8 × 4.2 in. viewing area.
- Dark shades 5, 8, and 9 through 13.
- Any shade can be "locked-in".
- The tack welding comfort mode may help reduce eye fatigue resulting from the eye constantly adjusting to differing light levels during tack welding. Using an intermediate light
- The delay function allows the welder to set the recovery delay of the welding filter from dark to light according to welding method and current.
- For all 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet Series 9100. More information on page 26-33.



#### 3M<sup>™</sup> Speedglas<sup>™</sup> Auto-Darkening Filter 9100X

- 2.1 × 4.2 in. viewing area.
- Dark shades 5, 8, and 9 through 13.
- Any shade can be "locked-in."
- The tack welding comfort mode may help reduce eye fatigue resulting from the eye constantly adjusting to differing light levels during tack welding. Using an intermediate light
- The delay function allows the welder to set the recovery delay of the welding filter from dark to light according to welding method and current.
- For all 3M™ Speedglas™ Welding Helmet Series 9100. More information on page 26–33.



#### 3M™ Speedglas™ Auto-Darkening Filter 9100V

- 1.8 × 3.7 in. viewing area.
- Dark shades 5, 8, and 9 through 13.
- Any shade can be "locked-in."
- The tack welding comfort mode may help reduce eye fatigue resulting from the eye constantly adjusting to differing light levels during tack welding. Using an intermediate light
- The delay function allows the welder to set the recovery delay of the welding filter from dark to light according to welding method and current.
- For all 3M™ Speedglas™ Welding Helmet Series 9100. More information on page 26-33.

#### 3M<sup>™</sup> Speedglas<sup>™</sup> **Auto-Darkening Filter 9002NC**


See your welds in a new light, with more contrast and natural-looking colors.

- 2.1 × 4.2 in. viewing area.
- Dark shades 8 through 12.
- For 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet series 9002NC" compatible with the old 9000 series welding helmets, more information on page 34-35.



#### 3M™ Speedglas™ **Auto-Darkening Filter SL**

Our most lightweight auto-darkening filter.



- Dark shades 8 through 12.
- For 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet SL, more information on page 36-37.



#### 3M<sup>™</sup> Speedglas<sup>™</sup> **Auto-Darkening Filter 100V**

- 1.7 × 3.7 in. viewing area.
- Dark shades 8 through 12.
- For 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet Series 100 (incl 100-QR), more information on page 38.



#### 3M™ Auto-Darkening Filter 10V

- 1.7 × 3.7 in. viewing area.
- Dark shades 8-12.
- For 3M<sup>™</sup> Welding Helmet 10V and 10QR, more information on page 39.



All our auto-darkening welding filters conform to ANSI Z87 (American National Standard for Occupational and Educational Personal Eye and Face Protection Devices) as well as other national standards in Europe, Canada and Australia—to name a few. Valid standard, optical classification and shade range are marked on the welding filter. Always read and follow all User Instructions.

### Do they really fit?

#### Making a measured evaluation of eyewear fit

Everyone's face and head are different—so how is one model of eyewear going to fit everybody? You know the problem. Ill-fitting safety glasses cause pressure and pain in some very vulnerable areas: your temples, your ears... even the bridge of your nose. Discomfort and lack of style are often major reasons for not wearing safety eyewear.

To make a meaningful, measured determination of eyewear fit and security on each of your employees, we've developed a 6-step method<sup>1)</sup>.

The 3M™ Eyewear Fit System uses coverage and gap gauge tools to assess four key elements of protective eyewear fit:




#### **View**

Assessment to ensure the wearer can see in all directions of eye rotation without major obstruction to the field of view that would interfere with the ability to perform work tasks.

#### 3

#### Security

Assessment to ensure the eyewear stays in place on the wearer's head and does not fall off with head movement.



#### (2


#### Coverage

The coverage gauge assesses how well the safety eyewear covers the soft tissue area around the eyes.

#### 4

#### Gaps

The gap gauges help to identify excessive gaps between the eyewear and the face. Large gaps can provide a clear path for flying debris.




1) The full 6 step method is unique to 3M and is available free of charge (subject to terms and conditions, see website for details).

20


3M™ Solus™ 1000 Series Spectacles

# A fogged lens can be frustrating and dangerous

Enjoy reliable, clearer sight longer with Scotchgard<sup>™</sup> Anti-Fog Coating. Now available on 3M<sup>™</sup> Solus<sup>™</sup> 1000 Series safety eyewear in a range of lens colours: clear, grey or amber. All glasses come with polycarbonate lenses, which absorb 99.9% of UV rays.




#### 3M<sup>™</sup> Scotchgard<sup>™</sup> Anti-Fog Coating. Long-lasting clarity.



**3M™ SecureFit™ 600 Series Protective Eyewear** 

## Premium quality you can see

The quality, durability and versatility of the 3M™ SecureFit™ 600 Protective Eyewear Series bring higher performance to workplace needs, with a variety of features that include lens options such as Scotchgard™ Anti-fog Coating, lens colors, polarization and reader options.



#### **Selected 3M<sup>™</sup> Protective Eyewear for Welders**

Part No	Lens Type	Coating	Description
SF601SGAF	PC Clear	Scotchgard™ Anti-fog	SecureFit 600 series eyewear with clear lens.
SF601SGAF-FM	PC Clear with Foam Gasket	Scotchgard™ Anti-fog	SecureFit 600 series eyewear with clear lens and removable foam-lined gasket.
SF617AS	PC Amber Low IR	Anti-scratch	SecureFit 600 series eyewear with amber lens.
SF630AS	PC Shade 3.0	Anti-scratch	SecureFit 600 series eyewear with shade 3.0 lens.
SF650AS	PC Shade 5.0	Anti-scratch	SecureFit 600 series eyewear with shade 5.0 lens.
SF600FI	Replacement Foam Gasket	-	For SecureFit 600 series eyewear
S1101SGAF	PC Clear	Scotchgard™ Anti-fog	Solus 1000 Series, blue/black eyewear with clear lens.
S1101SGAF-KT	PC Clear with Foam Gasket	Scotchgard <sup>™</sup> Anti-fog	KIT: Solus 1000 Series, blue/black eyewear with clear lens, removable foam-lined gasket and strap.
S1103SGAF	PC Amber	Scotchgard™ Anti-fog	Solus 1000 Series, blue/black eyewear with amber lens.

Always read and follow all User Instructions

# Your eyes, face and head

#### Content

lect	or 2 - helmets sorted by welder's overall needs		24
	Premium welding helmets with/without respirator or hard hat (no 3M™ Speedglas™ Welding Helmets 9100, 9100-Air and 9100-Q		28
	Flip-up welding helmets with/without respirator: 3M™ Speedglas™ Welding Helmets 9100 FX, 9100 FX-Air		30
	Multiple levels of protection (head, eye, face, respiratory, hearing 3M™ Speedglas™ Welding Helmet 9100 MP	):	32
	A legend reborn with more natural color :  3M™ Speedglas™ Welding Helmet 9002NC		34
	When your priority is super light: 3M™ Speedglas™ Welding Helmet SL		36
	Helmets in masterful graphic designs: 3M <sup>™</sup> Speedglas <sup>™</sup> Welding Helmet Series 100 and 100-QR		38
	Basic performance in robust design: 3M™ Welding Helmet 10V		39
lect	or 3 - refine your selection by helmet benefits		42
lect	or 4 - helmets for powered and supplied air systems		43

### There is no one perfect welding helmet

We have populated our helmet matrix with carefully considered design blends of protection, features, personal preferences, and performance to address many common application needs.

But for every helmet system we design, we have four driving factors:



#### Reliability

We know harsh welding environments: We build our products to thrive in them. From creating reliable arc sensing/ shade switching to selecting highly durable materials to designing for long-lasting mechanical operation.

#### Comfort

Comfort means a helmet that vents exhaled air. It means a headband that avoids scientifically determined pressure points around your head. And how a helmet provides eye and face protection while being comfortable for a full shift.



#### **Protection**

UV/IR radiation.
High speed grinding particles. Falling objects. Respiratory hazards. List your workplace hazards—then find the right Speedglas helmet, accessories, and respiratory protection. Have a unique workplace hazard? Contact your local distributor for even more 3M solutions.


#### View


Every helmet design detail can affect your view. That's why we provide highperformance autodarkening welding filters, our side windows lenses, and large, protective clear visors. Each of these, and many more, helmet design elements maximize your ability to see.



#### What do you need?

#### Full-featured helmet with the maximum number of options





26 27

When you need coverage, control, and comfort:


### 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet Series 9100



#### High-performing people need high-performing products

The 3M™ Speedglas™ Welding Helmet Series 9100 includes six welding helmet models offering many options, including flip-up welding shields, safety helmets, and respiratory systems.

If you haven't experienced these innovations in welding protection, call your local 3M distributor for a hands-on demonstration.



#### **Peripherial vision**

The first time a welder puts on a Speedglas welding helmet with side windows you can see his startled reaction. Previously hidden peripherial hazards (beams, obstacles, other workers) are now easier to see through the two, shade 5 side filters.

#### Tailor to fit your personal preferences

With the 9100 headband, we've carefully avoided sensitive areas of the head while designing self-adjusting twin pads for the forehead band. By better contouring it around your head, our headband doesn't need to be overly tight to be comfortably secure.

#### **Ergonomic fit**

Adjust the shield's distance to your face. Fits head sizes S-M-L, 6.25" to 8" (50-64 cm) approx.

#### Stability

Ratchet for precise tightening.

#### Adapt to your position

Adjust the helmet tiltangle while wearing the helmet on your head.



Self-adjusting "twin pads" contour to your head.

#### Low riding comfort

Adjust the helmet's parking position (left side) and friction (right side). Further details below.

We designed the 9100 helmet to "nest" down low, close to the headband, when raised. So you don't need to tighten the headband as much.

The helmet's smooth up-and-down pivot action can be locked in the up position—a light pull lowers the helmet back down again.

#### DROPS AS YOU LIKE

Drop-friction is adjusted on the wearer's right hand side:

Turn the right-hand knob clockwise to increase (or counterclockwise to decrease) the effort needed to nod down the shield.



#### STABILITY WHEN RAISED

Helmet parking grip is adjusted on the wearers left hand side:

Turn the left-hand knob clockwise to increase (or counterclockwise to decrease) how tightly the shield is held in the raised "parked" position.

Always read and follow all User Instructions.



3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmets 9100, 9100-Air and 9100-QR

### High-performance and comfort





- 1) Only in combination with 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Filter 9100XXi.
- Hard hat adaptor available, (Part No 06-0014-00NR).





Protecting your eyes and face from radiation, heat and sparks—while providing a precise view of your work—makes your Speedglas welding helmet 9100 one of your most important welding tools.

All of these benefits can be used with powered or supplied air respiratory protection in combination with the Speedglas welding helmet 9100-Air.

If your work situation requires head protection, test out our Speedglas welding helmet 9100-QR. It quickly attaches to many of the industry's most popular hard hats, including the 3M™ Hard hat H-701.



More natural colors and contrasts

The Speedglas welding filter 9100XXi helps you see your welds in a new light, providing more contrast and natural-

looking colors.

**3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmets** 9100 FX and 9100 FX-Air

### Flip up to wider views





- 1) Only in combination with 3M<sup>™</sup> Speedglas™ Welding Filter 9100XXi.
- 2) Hard hat adaptor available (Part No 06-0614-00NR).







Wider field of view with flip-up front—a combination welding helmet and protective visor.


A quick lift of the front and you get a big, (approx. 8"x 4.25") clear view—excellent for precision grinding in low-light conditions.

And if you use the 9100 FX-Air model, the clear view from the curved visor lets you keep your respiratory protection in place at all times.

3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet 9100MP

# Multiple levels of protection





with 3M™ Speedglas™ Welding Filter 9100XXi.



Have you tried multi-protection systems where some component seemed to clash with the other components?

That's why we built our 3M™ Speedglas™ Systems 9100 MP (multi-protection) just for welders.

You can now work in a highly integrated, comfortable, protective envelope, with big, wide views as you weld, prep and grind.

3M™ Speedglas™ Welding Helmet 9002NC

### A legend reborn

You asked, and we listened. For over 20 years, the 3M™ Speedglas™ Welding Helmet 9000 set the standard for rugged, dependable protection. Now we've incorporated the best features—giving a new generation of welders excellent performance at a price that won't break the bank.

This helmet incorporates 3M Speedglas' newest natural color technology. Advanced autodarkening optics are easily adjusted to meet your working conditions for a lighter, brighter and more detailed view of your welds. And a lighter weight, slim profile means less constriction in tight spaces.




Features	9002N
Approval ANSI Z87.1 - 2015	<b>~</b>
Side windows	
Auto-ON	
Exhaust vents	~
Flip-up	
Graphics option	
Hard hat	<b>✓</b> 10
Natural Color Technology	>
Powered Air	
Supplied Air	

 Hard hat adaptor available (Part No 07-0014-00NR).



#### Freedom of movement

Shield width



The slim profile offers increased freedom of movement in tight places.

Coverage





#### Pick your preference

The 9002NC helmet (left) is slimmer and not as deep as a 9100 helmet (right), making it more maneuverable and lighter in weight. On the other hand, the deeper and wider 9100 series covers more of your ears, neck, and sides of your head.



3M™ Speedglas™ Welding Helmet SL

# Light, narrow and fast



Features 
Approval
ANSI 287-2003 

Side windows

Auto-ON 

Exhaust vents

Flip-up

Graphics option

Hard hat

Natural Color
Technology

Powered Air

Supplied Air

Did you know that some lightweight welding helmets can actually absorb moisture and become heavier over time? We took care to avoid that problem by making our SL (super light) helmet from strong, non-absorbent materials (also applicable for the 9100 series helmets).

We also designed a special auto-darkening filter to make both the ADF and the helmet weight a mere 13 oz—25% lighter than any other Speedglas model.

3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet Series 100 and 100-QR

# Weld with personality



Features	100	100-QR
Approval ANSI Z87-2003	<b>✓</b>	~
Side windows		
Auto-ON		
Exhaust vents		
Flip-up		
Graphics option	<b>✓</b>	
Hard hat	<b>✓</b> 1)	<b>✓</b>
Natural Color Technology		
Powered Air		
Supplied Air		

Hard hat adaptor available (Part No 07-0014-00NR).

Get your career off to a great start with high-performance eye and face protection!

Now with a new option for head protection—the 3M™ Speedglas™ Welding Helmet 100-QR (quick release).

100-QR with hard hat 3M™ Welding Helmet 10V

### Basic functions in a robust design



Features

Approval
ANSI Z87.1 - 2010

Side windows

Auto-ON

Exhaust vents

Flip-up

Graphics option

Hard hat

Natural Color
Technology

Powered Air

Supplied Air

1) Hard hat adaptor available (Part No 07-0014-00NR).

Designed for all-round MIG/MAG and MMAW (electrode or "stick") welding, with user selectable dark shades of 10, 11 or 12.

#### Want to stand out?

Make an impactful statement with one of our powerful, distinctive graphic designs. Find them all on page 76.

#### Variable shades for flexibility

Five adjustable dark shades 8–12. And three sensitivity settings for customized light-to-dark switching, lock-in shade 3 light state.



#### Confident protection

Robust, industrial helmet design.
Complies to the standard
ANSI Z87.1 - 2010.

#### Performance made affordable

Auto-darkening filter performance at a price that won't break the bank.



40 41

### We got you covered

Every welder is different, and each day your tasks can change. As the owner of a 3M™ Speedglas™ Welding Helmet, you have a variety of accessories available to help you maximize your protection and comfort.


Plus, we now offer a new generation of additional coverage products made in flame-retardant textiles for protection against molten metal, sparks and flames.













#### Quick guide to help extend your protection

3M™ Speedglas™ Welding Helmet	9002NC	100	SL	9100 + 9100-Air	9100FX + 9100 FX-Air	9100-QR 100-QR 10V	9100 MP		
Head protection (Part No)	1	6-0099-30		06-0500-51	06-0700-82 (large) 06-0700-81 (small)	-	27-0099-84		
Material	Cotto	on / Para-ara	mid	Cotton / Para-aramid	Cotton / Para-aramid	-	Reflective		
Neck protection (Part No)	02-0690-001)			06	-0500-52	18-0099-68	27-0099-85 27-0099-87		
Material	Cotton / Para-aramid		Cotton	/ Para-aramid	Leather	Cotton/ Para-aramid			
Hood (Part No)			06	-0700-83		-	-		
Material			Cotton	/ Para-aramid		-	-		
Breathing tube cover (Part No)		-		SG-15		-	SG-15		
Material		-		Flam	Flame-retardant		Flame-retardant		Flame-retardant

1) Alternative neck protection available in leather (part no 18-0099-68).

# Time to upgrade your visibility?



#### Getting too close to your arc?

Start with the easiest solution first: replace your filter's outer protection plates more frequently!

If you still can't see the detail you need, try one of our magnifying lenses. They come in x1.5, x2.0, x2.5, and x3.0 strengths. For details, see the Accessories and Spare Parts section for each helmet.



#### Consumables to get you started

Starter kit of sweatband, inner and outer protection plates to your 3M™ Speedglas™ Welding Helmet Series 9100. For ordering information, see parts list section for each helmet type.

System	Component	Typically replaced	Notes
Welding filters	Outer protection plate	Once a week	Replace anytime the plate becomes deeply pitted, scratched or too dirty to clean with soft cloth or lens paper
Welding filters	Inner cover plate	Once a month	Regularly clean with a soft cloth and replace if any pits or scratches occur.
Welding helmets	Visor plate	Every two weeks	Replace more often if visibility is reduced.
Welding helmets	Sweatband	Once a month	Replace more often if sweatband becomes unhygienic.
Welding helmets with respirator	Face seal	At least every 2 months	Replace earlier in dirty environments or whenever the seal becomes unhygienic.
Welding helmets with respirator	Breathing tube	If damaged, deformed or leaking any air	To extend the life of breathing tube, use a tube cover or a heavy-duty rubber breathing tube.

Important information. Note that higherthan-normal levels of pollutants, heat, and sparks will require more frequent replacements of components. Chart assumes minimum 4 hours usage per day. Ordering information for each series of welding helmet can be found in the Parts Directory, page 66.

Information summary for quick reference only; always read and follow User Instructions.



42 | Selector 3 Selector 4 | 43

#### Refine your helmet selection based on your preferences















				_				
Specification 3M Welding helmets (non-air)	Speedglas 9100	Speedglas 9100-QR	Speedglas 9100 FX	Speedglas 9002NC	Speedglas SL	Speedglas 100	Speedglas 100-QR	3M 10V
Eye and Face Protection (Approval) Welding helmet, welding filter and protection plates	A	NSI Z87.1-20	10	ANSI Z87.1 -2015	ANSI Z87.1 -2003	ANSI Z87.1 -2010	ANSI Z87.1 -2010	ANSI Z87.1 -2010
Head protection (Approval) ANSI Z89.1-2009 Type 1		Class C, G, E <sup>2)</sup>					Class C, G, E <sup>2)</sup>	
Respiratory protection <sup>1)</sup>	All helmets are compatible with 3M disposable or resusable respirators; see page 54-57.  See next page for helmets available with powered and supplied air respiratory protection.							
Hearing protection—optional (see page 63)	Earmuffs Earplugs	Earmuffs Earplugs	Earmuffs Earplugs	Earplugs	Earplugs	Earplugs	Earplugs	Earplugs
1 Exhaust vents	YES	YES	YES	YES	-	-	-	-
2 Side windows	Optional	YES	YES	_	-	-	_	-
3 High-comfort headband 9100	YES	-	YES	YES	YES	YES	-	-
4 Flip-up with clear visor	_	-	YES	_	-	-	_	-
Graphics option	-	-	-	-	-	YES	-	-
Auto-darkening filter options (see page 16-17)	9100V, 9100X, 9100XX, 9100XXi	9100V, 9100X, 9100XX, 9100XXi	9100V, 9100X, 9100XX, 9100XXi	9002NC	SL	100-V	100-V	10V

1) This overview shows only our helmets without air delivery connection. Helmets for powered or supplied air respirator systems see page 43.

2) With 3M™ Hard hat H-701.



1 Exahaust vents exhaled air is channeled out via side vents.



2 Side windows shade 5 filters that widen your field of vision.



3 High-comfort Speedglas headband 9100 with smooth ratchet for precise tightening.



4 Big, curved (approx. 8"x 4.25") clear protective visor, increasing your peripherial vision.









Specification 3M Welding helmet systems (air)	Speedglas 9100 FX-Air	Speedglas 9100-Air	Speedglas 9100 MP	Speedglas L-705SG/ L-905SG
Eye and Face Protection (Approval) Welding helmet, welding filter and protection plates	ANSI Z87.1-2010	ANSI Z87.1-2010	ANSI Z87.1-2010	ANSI Z87.1-2003
Head protection (Approval)	-	-	ANSI Z89.1-2009 Type 1, Class G	ANSI Z89.1-2003 Type II, Class G
Respiratory protection (Approval) <sup>3)</sup> Adflo Powered Air Respirator Fresh-air III Supplied Air Regulator	APF 25 APF 25	APF 25 APF 25	APF 25 APF 25	APF 25 APF 1000 <sup>3)</sup>
Hearing protection—optional (see page 63)	Earmuffs Earplugs	Earmuffs Earplugs	Earmuffs Earplugs	Earmuffs Earplugs
2 Side windows	YES	YES	YES	NO
3 High-comfort headband 9100	YES	YES	-	-
4 Flip-up with clear visor	YES	-	YES	YES
Auto-darkening filter options (see page 16-17)	9100V, 9100X, 9100XX, 9100XXi	9100V, 9100X, 9100XX, 9100XXi	9100V, 9100X, 9100XX, 9100XXi	9100V, 9100X, 9100XX, 9100XXi

3) APF 1000 = L-905SG when used in conjunction with Adflo, TR-300, TR-600, GVP, and Supplied Air.







Specification 3M <sup>™</sup> Faceshields and Helmets (air)	Versaflo M-207	Versaflo M-307	Versaflo M-407
Eye and Face Protection (Approval) Visor plate	ANSI Z87.1-2010	ANSI Z87.1-2010	ANSI Z87.1-2010
Head protection (Approval)	Bumpcap	ANSI Z89.1-2009 Type 1 Class G	ANSI Z89.1-2009 Type 1 Class G
Respiratory protection (Approval) Adflo Powered Air Respirator Fresh-air III Supplied Air Regulator	APF 25 APF 25	APF 25 APF 25	APF 1000 <sup>4)</sup> APF 1000 <sup>4)</sup>
Hearing protection—optional (see page 63)	Earmuffs Earplugs	Earmuffs Earplugs	Earmuffs Earplugs
Flame-retardant shroud	YES	YES	YES
Type of protective visor	Clear-coated polycarbonate	Clear-coated polycarbonate	Clear-coated polycarbonate

4) APF 1000 = M-407 when used in conjunction with Adflo, TR-300, TR-600, GVP, and Supplied Air. See 3M Technical Data Bulletin 175 for more details.

Always read and follow all User Instructions.


# Your respiratory system

#### Content

Welding fume hazards	4:
Reducing welding fumes & exposure	40
General guide to respiratory protection for welders	4
3M <sup>™</sup> Adflo <sup>™</sup> Powered Air Respirators	48
3M <sup>™</sup> Speedglas <sup>™</sup> Fresh-air III Supplied Air Regulators	5:
3M <sup>™</sup> Reusable Respirators	54
3M <sup>™</sup> Disposable Welding Respirators	50

# Health effects of welding fumes

The respiratory hazards of metalworking are real. Welding fumes swirling around in your work environment can potentially result in health-related issues. Some exposure limits for welding fumes are set by regulations, and others are advisory. These limits aren't always the same.



#### When good enough isn't enough...

To help reduce the risk of adverse health effects caused by exposures to airborne materials such as manganese, the United States Occupational Safety and Health Administration (OSHA) has established permissible exposure limits (PELs) which are law. In addition, the American Conference of Governmental Industrial Hygienists (ACGIH) sets threshold limit values (TLVs) which are airborne exposure limit guidelines.

#### **PEL 5.0 mg/m<sup>3</sup>**

Current Federal OSHA PEL for manganese compounds, including manganese fume, is 5 milligram per cubic meter of air.<sup>1)</sup>



#### **TLV 0.02 mg/m<sup>3</sup>**

Since 2013 ACGIH Threshold Limit Value for Manganese exposure is 0.02 milligram per cubic meter of air.<sup>1)</sup> 46 47

### Reducing welding fumes & exposure

Welding creates a mixture of respirable gases and/ or fumes (particles). To address these hazards and risks, it is best practice to use a hierarchy of controls. The idea is that the highest priority items on the hierarchy not only do the most to reduce fumes and worker exposure, but that they also put the least burden of responsibility on the welder. However, every welding fume control has its limitations; here are some examples:

1

Modify or substitute your welding process to other processes that generate less fumes and/or reduce exposure to airborne contaminants.

Control Limitations:
Substitutions may
not be possible.
For example, when
the end-product
requires stainless steel

(chromium).

2

Engineering controls include actions such as modifying enclosures around the welder, or the general ventilation of the workshop, or local exhaust controls.

Control Limitations: Ventilation can be difficult to achieve due to conflicting needs, for instance heating/ cooling or shielding gases. 3

Work practices include having the welder keep their head out of the plume.

Control Limitations: Space-restricted workpieces or the welding situation may not allow alternative placement of the welder's head. 4

Personal respiratory protection. If steps 1 through 3 do not eliminate the respiratory hazards, respiratory protection for the welder can provide protection and comfort.

Control Limitations:
Companies must
establish a respiratory
protection program in
accordance with 29 CFR
1910.134 that includes
selection of respirators
and their filters, training
and maintenance.

# Inadequate respiratory protection is the 4th most frequently cited workplace violation.¹) 1) Top 10 Most Frequently Cited Standards, OSHA, U.S. Department of Labor, for 2015. Always read and follow all User Instructions.

### Which style of respirator best suits you?

The following is an overview of the four general types of 3M respiratory protection found in this catalog. In addition to your application's specific filtration requirements, your selection process

may include factors such as equipment style/configuration, personal preference/comfort, and maintenance considerations.



APF = Assigned Protection Factor.

Always read and follow all User Instructions.

#### 3M™ Adflo™ Powered Air Respirator

- APF¹) of up to 1000 based on headtop configuration.
- Can be used specifically for particle filtration (only), or for the filtration of both particulates and gases, depending on filter selection.
- Four welding helmet and three protective visor configurations to pick from.
- Provides a constant nominal airflow rate of 205 lpm.
- The respirator's slim turbo design allows highly mobile use.

#### 3M<sup>™</sup> Speedglas<sup>™</sup> Fresh-air III Supplied Air Regulators

- APF<sup>1)</sup> of up to 1000 based on headtop configuration.
- Can be used to protect against substances including particle or gas/vapor.
- Four welding helmet and three protective visor configurations to pick from.
- Belt-mounted regulator with user control over airflow: from 170 lpm to 424 lpm.
- Requires Grade D breathable air, filter and regulator panel, and approved 3M supplied air hoses.

#### **3M™ Reusable Respirators**

- APF<sup>1)</sup> for half facepiece reusable respirators is 10.
- Helps provide respiratory protection against a variety of gases, vapors, and particulate hazards when used with 3M cartridges and filters according to NIOSH approvals.
- Available resilient silicone faceseal styles provide comfort, durability, and stability
- Low profile designs enable fit under all 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet Series 9100.

#### **3M<sup>™</sup> Disposable Welding Respirators**

- APF¹) 10.
- Lightweight and comfortable.
- No maintenance—disposable.
- Fits under virtually any welding helmet.
- Adjustable noseclips to help provide a custom seal.



#### Move around

The slim profile of the turbo design makes it easier to go into tight spaces. The robust 3M™ Adflo™ Powered Air Respirator provides all of the features you would expect in a premium system, including easy-to-use functionality.

#### Go higher

At higher altitudes, air is less dense. To compensate, we offer the 3M™ Adflo™ High Altitude Powered Air Respirator.



Suitable for up to approx. 10,000 ft (3000 meters) above sea level and up to approx. 5,000 ft (1500 meters) when using the OV/AG cartridge.



**3M™ Adflo™ Powered Air Respirator** 

# Your own filtered atmosphere... ...mobile and adaptable



Is there a way to both increase your respiratory protection against harmful welding fumes while increasing the comfort around your face and head? Tackle workplace hazards with a respiratory protection solution workers will want to wear.

As one of the most popular respirators of its kind in the world, the 3M<sup>™</sup> Adflo<sup>™</sup> Powered Air Respirator is designed to provide welders a constant nominal airflow rate of 205 liters per minute, regardless of the battery's charge or the particle loading of the filter.

#### Green for go

As soon as you turn on your Adflo powered air respirator, a display indicates the status of the filter. Green light means that the unit is working normally. Red light indicates that the filter is clogging up.

1. Particulate filter is new

2. Three green indicator lights come on as the filter begins to clog



### 3. Three green and one red light: expect a shorter battery runtime. Particulate filter

expect a shorter battery runtime. Particulate filter replacement is recommended.



#### two red lights: the particulate filter is clogged and must be replaced.

4. Three green and




50

#### An adaptable system

With the right type of filter, the Adflo respirator helps reduce your exposure against both particles and gases—all in one system. And you can selectively replace either the particle or the OV/AG cartridge as needed: you don't need to change both filters at the same time.

- A Filter cover: holds the different available Adflo filters.
- B Spark arrestor.
- C Prefilter: increases the service life of the particulate filter.
- **D HE particulate filter:** high efficiency particulate filtration.
- **E OV/AG cartridge:** filters certain organic vapors and acid gases; sold separately.
- **F** Odor filter: removes unpleasant smells (not needed if a OV/AG cartridge is installed); sold separately.
- **G** Li-ion battery: charges to 80% capacity in approx. 3 hours and to 100% capacity in approx. 6.5 hours, depending on its residual charge. Approximate operating time up to 12 hours with a new particle filter and new, fully charged battery.
- H Brushless motor: with an average life three times longer than conventional motors.
- I **Filter indicator:** indicates the status of the HE particulate filter.
- J Airflow: Provides a constant nominal airflow rate of 205 lpm.
- K Breathing tube: different options available.
- L Airflow: for your maximum comfort, a diffuser evenly distributes filtered air throughout the entire breathing zone of the helmet. Plus, the intelligent turbo unit keeps the airflow rate at a constant, preset level.
- M Soft, flexible face seal (removed here for clarity): creates a positive pressure environment within the helmet, keeping the surrounding pollutants at bay.



### Increase your comfort





For additional back support, you might like to try the backpack BPK-01 when using the Adflo respirator.

For maximum safety and performance, make it a regular habit to check and change the following items at the intervals recommended below.

Adflo component	Typically replaced <sup>1)</sup>	Notes
Prefilter	Once a week	Regular replacement of the prefilter extends the life of the HE particulate filter, saving money while also increasing the battery run-time.
HE particulate filter	At least every month	Do daily checks with air flow indicator and replace when airflow indicator falls below the minimum flow line.
OV/AG cartridge	According to regulations at your work place	Smell and taste is not recommended as a measure of change.
Odor filter	Any time you smell unpleasant odours	Note: odor filter is not required if a OV/AG cartridge is used.
Spark arrestor	As needed	Replace if deformed and no longer fitting well.

1) Important information. Note that higher-than-normal levels of pollutants, heat, and sparks will require more frequent replacement of components. Chart assumes minimum 4 hours usage per day. Ordering information for each series of welding helmet can be found in the Parts Directory page 66.

System overview: page 80 Ordering & part info: page 82–83 Always read and follow all User Instructions.

3M<sup>™</sup> Speedglas<sup>™</sup> Fresh-air III **Supplied Air Regulators** 

# Light on your belt and maximum airflow



V-200 Air Heating





Temperature

The lightweight, belt-mounted regulator allows you to regulate the airflow from a supplied air source. A cost-effective way to provide a high level of respiratory protection - no filters, cartridges, or batteries to maintain. They can operate on pressures ranging from 60-90 psig, depending on hose length.

Two alternative regulators to either cool (V-100) or heat (V-200) the airflow entering the headgear by as much as 50°F (28°C). These regulators are excellent choices for workers exposed to uncomfortable temperature ranges.




#### Convenient Quick Latch Drop-Down Mechanism

- Easy on and off as you move in and out of contaminated areas.
- No need to remove hard hats or faceshields when lowering and raising the respirator.









**Quick Latch closed** 

Pull up on latch

Quick Latch open

atch open Pull down on latch

**To open Quick Latch:** Grasp the latch at chin level and pull up. **To close Quick Latch:** Grasp the facepiece with your thumb on the bottom of the facepiece and your first two fingers on top of the latch. Place the facepiece over your nose and mouth while pushing down on the latch.

3M<sup>™</sup> Rugged Comfort Half Facepiece Reusable Respirators and Filters

### An easy choice for a tough world

When shifts are long and conditions are challenging, your workers will appreciate the 3M™ Rugged Comfort Half Facepiece Reusable Respirator 6500 Series. With 3M's Quick Latch drop-down mechanism and Cool Flow™ Valve, respirators are easy-on and easy-off for comfortable protection.



- Our lightest silicone facepiece keeps it shape, even in high-heat environments.
- Low-profile, wide field-of-view design.
- Easy on and off with our convenient Quick Latch (QL) Drop-Down Mechanism.
- Easier breathing with 3M<sup>™</sup> CoolFlow<sup>™</sup> Exhalation Valve.
- Adjustable head harness assembly.
- Compatible with all 3M bayonet-style cartridges and filters.

3M™ Reusable R	espirators	Model (Size)	Description	Assigned Protection Factor
6500 Facepieces		6501 (S) 6502 (M) 6503 (L)	3M™ Rugged Comfort Half Facepiece Reusable Respirator.	APF 10
6500QL Facepieces		6501QL (S) 6502QL (M) 6503QL (L)	3M™ Rugged Comfort Quick Latch Half Facepiece Reusable Respirator	APF 10
2297 Filters	100 2262 1001 1002 W	2297"	3M <sup>™</sup> Advanced Particulate Filter 2297, P100 Respiratory Protection, with Nuisance Level Organic Vapor Relief <sup>®</sup>	

<sup>1) 3</sup>M recommended for ozone protection up to 10x OSHA PEL (not NIOSH approved for ozone). Nuisance levels are less than OSHA PEL or applicable government occupational exposure limits, whichever is lower.

Since everyone's head size and shape is different, we recommend that you work with your 3M™ distributor to find the respirator models that are most compatible with your welding helmet(s). The filter option reference is for particle filtration. 3M reusable respirators can be combined with many other types of filters and cartridges for protection against particulates, vapors and/or gases.



**3M™** Disposable Filtering Facepiece Respirators

# Light, convenient and comfortable protection



Looking for lightweight, effective and comfortable respiratory protection against dusts, mists, and metal fumes?

Respirators can't give workers full protection unless they are selected and worn correctly during all exposure times. That's why 3M™ Disposable Filtering Facepiece Respirators include features and technology that enhance user comfort and can help increase wear times.

Incorporates layers, designed to be flame resistant as demonstrated per ASTM D2859-96. (Not a substitute for a faceshield.)

3M <sup>™</sup> Disposable Filtering Facepiece F	Respirator Model	Description	Assigned Protection Factor		
N95 Respirator	8515	Particulate welding respirator.	APF 10		
N95 Respirator	8212	Particulate welding respirator with faceseal.	APF 10		
N95 Respirator	8214	Particulate welding respirator with faceseal and nuisance level organic vapor relief. <sup>1)</sup>	APF 10		

 <sup>3</sup>M recommended for ozone protection up to 10x OSHA PEL (not NIOSH approved for ozone).
 Nuisance levels are less than OSHA PEL or applicable government occupational exposure limits, whichever is lower.

### Your ears

#### Content

The challenge of hearing protection for welders	59
Strategies for moving towards 100% usage	60
3M™ PELTOR™ Level Dependent Earplug LEP-100	6
Earmuffs that attach to hard hats	62
Selector 5 - hearing protection for welders (earmuffs & earplugs)	63

### The challenge of hearing protection for welders



Gives the expected protection.



Reduces protection.




Significantly reduces protection.

### Minutes of carelessness per day significantly reduces the effect of hearing protection

That's right: if you're in a harmfully loud workplace—at or above 85 decibels—then not having your hearing protection in place just 10% of the time offers you significantly less protection. Noise-induced hearing loss (NIHL) is caused by the damage and eventual death of the the sensory cells in you ears, called 'hair cells'. Unlike some other cells, human ear hair cells never grow back.<sup>1)</sup>

#### Too loud may be less loud than you think

Think of all of the noises that surround you at your welding shop. Your tools, of course. But also the sudden, short, yet very loud noises: metal falling onto metal or hammers banging metal into place. Those sudden noisy spikes, at or above 85 decibels, could be damaging your hearing unless your hearing protection is always in place.



# Moving towards 100% usage

### Select hearing protection that your workers want to wear

This is an important step in moving towards 100% usage. But, 100% usage isn't the only answer. You need it if you're exposed above 85dB, but wearing protection below that or wearing more protection than is needed, could have an impact on your ability to hear surrounding sounds.

#### **Create a Hearing Conservation Program**

Employers who have workers in areas with 8 hour TWA noise exposures of 85 dBA and higher must provide an OSHA Hearing Conservation Program that includes:

- 1. Noise monitoring
- 2. Engineering and administrative controls
- 3. Annual hearing testing
- 4. Providing hearing protectors
- 5. Annual training
- 6. Record keeping
- 7. Evaluate program effectiveness

The following pages offer Hearing Protection Equipment (HPE) options to consider for your needs and preferences.

### OSHA Regulations

OSHA
Limits
OSHA's permissible exposure limit is 90
decibels (dBA)—time-weighted average
(TWA) over eight hours—for workers with
no previous work-related hearing loss.

OSHA Requirements According to OSHA, workers exposed above 90 dB(A) 8 hour time weighted average must wear hearing protection.

Repeated exposure to loud sounds, greater than 85 dBA, can cause permanent hearing loss and tinnitus.

Other health effects related to noise can include stress, anxiety, hypertension, sleep disturbance and fatigue.

37.5 Million

Americans Experience Hearing Loss.<sup>1)</sup>

#1 Reported
Manufacturing
Health Issue.2)

1) According to the National Institutes of Health, 37.5 million (15%) Americans age 18 and older report some degree of hearing loss, and it is estimated that 26 million Americans between the ages of 20 and 69 have a hearing loss due to noise exposure.

2) The Bureau of Labor Statistics (BLS) has reported that for people working in the Manufacturing Sector, occupational hearing loss is the most commonly recorded occupational health issue. Since 2004, nearly 258,500 workers have suffered significant, permanent hearing loss.

**3M™ PELTOR™ Level Dependent Earplug LEP-100** 

### Stay aware and communicate

How can you protect your hearing but still communicate in workplaces with loud noises? The 3M™ PELTOR™ LEP-100 amplifies weak sounds (like voices) when noise levels are low while attenuating loud noises while attenuating loud noises—even sudden loud noises.

#### Added convenience

Replaceable eartips are available in small, medium, and large sizes and two different designs to accommodate most user's ear canals:

- UltraFit<sup>™</sup> Eartips, NRR of 25 dB<sup>1)</sup>
- Skull screw tips 32 dB<sup>1)</sup>

#### Rain or wind

Water resistant microphone port also helps minimize wind noise.

#### Easy operation

Intuitive one-button operation turns the unit on and off, and selects volume settings.

#### Long usage time

The rechargeable Li-ion battery provides up to 16 hours of continuous operation.

1) 3M strongly recommends fit testing of hearing protectors. Research suggests that many users will receive less noise reduction than indicated by the NRR due to variation in hearing protector fit, fitting skill and motivation of the user. If the NRR is used to estimate typical workplace protection, 3M recommends that the NRR be reduced by 50% or in accordance with applicable regulations.





62 Selector 5 | 63



#### 3M™ PELTOR™ **Earmuffs X-Series**

#### No compromises

Ear cups have a streamlined design that doesn't



#### Comfortable

Lightweight dual molded cups. 3M strongly recommends fit testing of hearing protectors

Specifications and ordering info: page 63.

#### Stylish and reliable

**Helmet mounted** 

Integrated design

New ear cushion foam technology for an effective acoustic seal and reliable protection



#### Hearing protection for welders

A selection of 3M™ Earmuffs and Earplugs<sup>1)</sup>



















3M™ PELTOR™ Earmuffs and Level Dependent Earplug	H505B	M-985 Earmuffs	X1 Earmuffs	X1 Earmuffs	X2 Earmuffs	X3 Earmuffs	X4 Earmuffs	X5 Earmuffs	LEP-100
Design	Neckband	Helmet mounted	Neckband	Helmet mounted	Helmet mounted	Helmet mounted	Slim, fluorescent, helmet mounted	Helmet mounted	Level dependent earplug
NNR <sup>2)</sup>	17dB	24dB	21dB	21dB	24dB	25dB	25dB	31dB	25dB / 32dB
Part No	H505B	M-985	X1B	X1P5E	X2P5E	X3P5E	X4P5E	X5P5E	LEP-100
With 3M <sup>™</sup> Welding Helmet									
Speedglas 9100	•		•						•
Speedglas 9100 Air	•		•						•
Speedglas 9100-QR				•	•	•	•	•	•
Speedglas 9100 FX	•		•						•
Speedglas 9100 FX-Air									•
Speedglas 9100 MP		•							•
Speedglas 9002NC	•		•						•
Speedglas 100	•		•						•
Speedglas 100-QR									•
3M 10V									•
Versaflo M-series		•							•

1) 3M strongly recommends fit testing of hearing protectors. These recommendations are general and are based on usage with 3M™ Welding Helmets.















3M™ Earplug³)	E-A-R <sup>™</sup> Classic <sup>™</sup>	E-A-Rsoft <sup>™</sup> Yellow Neons <sup>™</sup>	E-A-Rflex <sup>™</sup>	E-A-R <sup>™</sup> Ultrafit	E-A-R <sup>™</sup> Ultrafit 27 <sup>™</sup>	E-A-R <sup>™</sup> Skull Skrews <sup>™</sup>
Design	Classic earplugs with proprietary foams.	Slowly expanding, polyurethane foam material.	Banded, wear Behind-the-Head	Reusable, premolded earplugs.	Resusable, premolded earplugs	Push-To-Fit Earplugs
NNR 2)	29dB	33dB	28 dB	25dB	27dB	32dB
Part No	310-1001	311-1250	320-1000	340-4004	340-8002	P1301

- 2) 3M strongly recommends fit testing of hearing protectors. Research suggests that many users will receive less noise reduction than indicated by the NRR due to variation in earmuff fit, earmuff fitting skill and motivation of the user. If the NRR is used to estimate typical workplace protection, 3M recommends that the NRR be reduced by 50%
- 3) The 3M™ E-A-R™ Hearing Protection listed here were selected for use in a typical welding environment. For additional 3M hearing protection selections,

**3M<sup>™</sup> DBI-SALA<sup>®</sup> Delta<sup>™</sup> Harnesses** 



# Fall Protection for High Heat Environments





Fire and sparks are a major concern in jobs such as welding, cutting and other high temperature applications. Keeping safe requires special materials to resist these hazards.

### 1105475 3M™ DBI-SALA® Delta™ Harness for Hot Work Use

Vest-style, with Nomex®/Kevlar® fibre web, back D-ring, with conductivity reducing anti spark hardware, pass-through buckle leg straps, loops for belt (Universal Size). Maximum 700° Fahrenheit char temperature. 310 lbs. (140 Kg) capacity.



### 3M<sup>™</sup> DBI-SALA<sup>®</sup> Nano-Lok<sup>™</sup> for Hot Work Use Self-Retracting Lifelines (SRL)

This unique SRL is reinforced with Kevlar® fiber to withstand sparks, weld splatter and other heat exposure.

- 6 ft. (1.8 m) working length
- Universal hot work icon to quickly and easily identify hot work products.
- Equipped with RFID.

### Parts Directory

#### Content

Selec	tor 6 - find the right protection plate to your welding filter	67
	3M™ Speedglas™ Welding Helmet 9100	68
	3M <sup>™</sup> Speedglas <sup>™</sup> Welding Helmet 9100 FX	70
	3M™ Speedglas™ Welding Helmet 9100-QR	72
	3M™ Speedglas™ Welding Helmet 9002NC	74
	3M <sup>™</sup> Speedglas <sup>™</sup> Welding Helmet SL	75
	3M™ Speedglas™ Welding Helmet 100/100-QR	76
	Spare parts for older 3M™ Speedglas™ Welding Helmets (non-air)	79
Selec	etor 7 - powered and supplied air system overview	80
Upgra	ade to the latest welding helmet systems	81
	3M™ Adflo™ Powered Air Respirator	82
	3M <sup>™</sup> Speedglas <sup>™</sup> Fresh-air III Supplied Air Regulators	84
	3M <sup>™</sup> Supplied Air Hoses and Panels	84
	3M™ Speedglas™ Welding Helmet 9100-Air	86
	3M <sup>™</sup> Speedglas <sup>™</sup> Welding Helmet 9100 FX-Air	88
	3M <sup>™</sup> Speedglas <sup>™</sup> Welding Helmet 9100 MP	90
Spare	parts for older 3M™ Speedglas™ Welding Helmets (for respirator syste	ms) 94
	3M <sup>™</sup> Hard hat H-701	95
	3M <sup>™</sup> Versaflo <sup>™</sup> M-Series Headtops	96
Produ	ıct index	98



As the outer protection plate becomes deeply pitted, scratched or too dirty to clean with soft cloth, it's probably time to replace it. Ensure you order the right plate for your filter:

Oute	Outer protection plate		For welding filter model					
Part No	Description	9100V	9100X	9100XX	9100XXi	9002NC	SL	100 Series
04-0270-01	Standard					•		
04-0270-03	Scratch resistant					•		
04-0270-04	Heat resistant					•		
06-0200-51	Standard	•	•	•	•			
06-0200-52	Scratch resistant	•	•	•	•			
06-0200-53	Heat resistant	•	•	•	•			
05-0250-00	Standard						•	
05-0250-01	Scratch resistant						•	
07-0200-51	Standard							•
07-0200-52	Scratch resistant							•
07-0200-53	Heat resistant							•

The table shows our current program of welding filters, if you have an older helmet model check page 79 for consumables.

Regularly clean the inner cover plate with a soft cloth and replace if any pits or scratches occur. Ensure you order the right plate for your filter:

Inner cover plate			For welding filter model						
Part No	Description	LxH	9100V	9100X	9100XX	9100XXi	9002NC	SL	100V
04-0290-00	Clear	3.6"x1.7"						•	•
04-0280-00	Clear	4.1"x2.1"					•		
04-0280-01	+1 Shade	4.1"x2.1"					•		
04-0280-02	+2 Shade	4.1"x2.1"					•		
06-0200-10	Clear	4.6"x1.97"	•						
06-0200-20	Clear	4.6"x2.4"		•					
06-0200-30	Clear	4.6"x3"			•	•			

The table shows our current program of welding filters, if you have an older helmet model check page 79 for consumables.


68 69

#### 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet 9100















06-0000-10 06-0000-20 06-00

#### Helmets with side windows – auto-darkening filter

auto aurkon	mg mici
Part No	Description
06-0100-10SW	With Speedglas welding filte 9100X (1.8"x3.7".).
06-0100-20SW	With Speedglas welding filte 9100X (2.1"x 4.2".).
06-0100-30SW	With Speedglas welding filte 9100XX (2.8"x4.2").
06-0100-30iSW	With Speedglas filter kit 9100XXi, incl welding filter and front cover 9100XXi (2.8"x4.2").

#### Helmets without welding filter

Part No	Description	Part No
06-0300-51	Welding helmet 9100 without side windows, with headband and silver front.	06-0000
06-0300-51SW	Welding helmet 9100 with side windows, headband and front cover.	06-0000
	nonceover.	06-0000
		06-0000

#### Welding filters

Part No	Description	
06-0000-10	Auto-darkening filter 9100V, variable shade 5, 8, 9–13 (1.8"x3.7").	
06-0000-20	Auto-darkening filter 9100X, variable shade 5, 8, 9–13 (2.1"x 4.2").	
06-0000-30	Auto-darkening filter 9100XX, variable shade 5, 8, 9–13 (2.8"x4.2").	
06-0000-30i	Auto-darkening filter 9100XXi variable shade 5, 8, 9–13 (2.8"x4.2").	

#### 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Filter Kit 9100XXi


Our top-of-the-line welding filter with improved optics and a special designed front cover with external controls for grinding and memory modes. This complete kit (front cover and welding filter) is compatible with Speedglas welding helmet models 9100, 9100-Air and 9100-QR.


Read more about the new 9100XXi welding filter on page 16.



Part No:
06-0000-30i-KIT Welding filter and front cover 9100XXi

#### Spare parts & accessories for 3M™ Speedglas™ Welding Helmet 9100





06-0200-10

06-0200-20

06-0200-30

06-0000-10


06-0000-20

06-0000-30

06-0000-30i

06-0200-51

06-0200-52







0500-51



06-0700-83



3 06-0500-52



04-0023-022)



23-02<sup>2)</sup> 06-0014-00NR

Part No	Description	Part No	Description	Part No	Description
04-0023-02	3M™ Hard hat H701, white	06-0200-51	Outer protection plate,	06-0300-55	Heat-reflecting front cover 9100
	(unvented).		10/case.	06-0300-55i	Heat-reflecting front cover
04-0320-00	Battery, 2/case.	06-0200-51B	Outer protection plate,		9100XXi.
04-0400-55	Battery holder, 2/case.		50/case.	06-0400-51	Headband with assembly parts.
06-0000-10	Speedglas welding filter 9100V.	06-0200-52	Outer protection plate scratch	06-0400-52	Pivot mechanism, left and right.
06-0000-20	Speedglas welding filter 9100X.		resistant, 10/case.	06-0400-53	Headband front part.
06-0000-30	Speedglas welding filter	06-0200-52B	Outer protection plate scratch	06-0400-54	Headband back part.
	9100XX.		resistant, 50/case.	06-0500-51	Head protection.
06-0000-30i	Speedglas welding filter	06-0200-53	Outer protection plate heat	06-0500-52	Neck protection.
	9100XXi.		resistant, 10/case.	06-0500-531)	Side windows cover plate,
06-0000-30i-KIT	Speedglas welding filter kit	06-0200-53B	Outer protection plate heat		2 pairs.
	9100XXi (incl front cover and		resistant, 50/case.	06-0500-56	Magnifying lens 1.5.
	welding filter).	06-0200-54	Comfort sweatband, 3/case.	06-0500-57	Magnifying lens 2.0.
06-0014-00NR	Hard hat adapter 9100, with		standard, 10/case.	06-0500-58	Magnifying lens 2.5.
	assembly parts.	06-0300-51	Welding helmet without side	06-0500-59	Magnifying lens 3.0.
06-0200-10	Inner cover plate for 9100V		windows, with headband.	06-0700-83	Hood.
	filter, 5/case. Plate marking	06-0300-51SW	Welding helmet with side		
	117×50.		windows and headband, with		
06-0200-20	Inner cover plate for 9100X		front cover 9100.		
00 0100 10	filter, 5/case. Plate marking	06-0300-52	Welding helmet without side		
	117×61.		windows, without headband,		
06-0200-30	Inner cover plate for 9100XX/		with front cover 9100.		
00 0200 00	9100XXi filters, 5/case. Plate	06-0300-52SW	Welding helmet with side		
	marking 117×77.	00 0000 02011	windows, without headband,		
	marking marr.		with front cover.		
			WIGH HOME COVCI.		

<sup>1)</sup> Please use Part No 06-0300-52SW when new side windows are required.

06-0000-30i

06-0300-55i

06-0000-30i-KIT

04-0400-55 04-0320-00

<sup>2)</sup> Many alternative colors available, see page 95

71

#### 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet 9100 FX



Helmets with side windows - and auto-darkening filter Part No 06-0600-10SW

With Speedglas welding filter 9100X (1.8"x3.7".). 06-0600-20SW With Speedglas welding filter 9100X (2.1"x 4.2".). With Speedglas welding filter 9100XX (2.8"x4.2"). 06-0600-30SW

Helmet without welding filter Part No 06-0600-00SW Welding helmet 9100 FX with side windows, headband and

front cover.










06-0000-20

#### Alternative 3M<sup>™</sup> Speedglas<sup>™</sup> **Welding Filters**


Part No	Description
06-0000-10	Auto-darkening filter 9100V, variable shade 5, 8, 9–13 (1.8"x3.7").
06-0000-20	Auto-darkening filter 9100X, variable shade 5, 8, 9–13 (2.1"x4.2").
06-0000-30	Auto-darkening filter 9100XX, variable shade 5, 8, 9–13 (2.8"x4.2").
06-0000-30i	Auto-darkening filter 9100XXi variable shade 5, 8, 9–13



#### Spare parts & accessories for 3M™ Speedglas™ Welding Helmet 9100 FX



06-0600-00SW









06-0700-83

06-0700-82

Part No	Description	Part No	Description	Part No	Description
04-0023-02	3M <sup>™</sup> Hard hat H701, white (unvented).	06-0200-52	Outer protection plate scratch resistant, 10/case.	06-0600-00SW	Welding helmet, without welding filter, with headband.
04-0320-00	Battery CR2032 Lithium 3V, 2/case.	06-0200-52B	Outer protection plate scratch resistant, 50/case.	06-0614-00NR	Hard hat adapter 9100FX, with assembly parts.
04-0400-55 06-0000-P11	Battery holder, 2/case. Speedglas passive welding filter	06-0200-53	Outer protection plate heat resistant, 10/case.	06-0700-54 06-0700-81	Visor plate anti-fog, 5/case. Head protection (small).
06-0000-10	kit 9100 (shade 11). Speedglas welding filter 9100V.	06-0200-53B	Outer protection plate heat resistant, 50/case.	06-0700-82 06-0700-83	Head protection (large). Hood, black/grey.
06-0000-20 06-0000-30	Speedglas welding filter 9100X. Speedglas welding filter 9100XX.	06-0200-10	Inner cover plate for 9100V filter, 5/case. Plate marking	06-0700-73	Side windows cover plate, 2 pairs.
06-0000-30i 06-0200-20	Speedglas welding filter 9100XXi. Inner cover plate for 9100X	06-0200-54	117×50. Comfort sweatband, 3/case.	06-0700-63 06-0700-64	Front panel, crome. Wide-view clear grinding visor
	filter,	06-0400-51 06-0400-52	Headband with assembly parts.		frame, black.
06-0200-30	5/case. Plate marking 117×61. Inner cover plate for 9100XX/ 9100XXi filters, 5/case. Plate marking 117×77.	06-0400-52 06-0400-53 06-0400-54 06-0500-52	Pivot mechanism, left and right. Headband front part. Headband back part. Neck protection, black.	06-0700-72SW	Welding helmet, without welding filter, without headband.
06-0200-51	Outer protection plate,	06-0500-56 06-0500-57	Magnifying lens 1.5. Magnifying lens 2.0.		
06-0200-51B	Outer protection plate, 50/case.	06-0500-58 06-0500-59	Magnifying lens 2.5. Magnifying lens 3.0.		

Always read and follow all User Instructions. Always read and follow all User Instructions.

## 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet 9100-QR



#### Welding helmets - with 3M™ Hard hat H-701

Part No	Description
06-0100-10QR	With Speedglas welding filter 9100X, with rail and hard hat (1.8"x3.7").
06-0100-20QR	With Speedglas welding filter 9100X, with rail and hard hat (2.1"x4.2").
06-0100-30QR	With Speedglas welding filter 9100XX (2.8"x4.2").



With QR rail, without hard hat,

without welding filter.

#### Welding helmets - without hard hat Part No Description

06-0300-54QR



06-0000-30i







06-0000-10

#### Alternative 3M<sup>™</sup> Speedglas<sup>™</sup> **Welding Filters**

Part No	Description
06-0000-10	Auto-darkening filter 9100V, variable shade 5, 8, 9–13 (1.8"x3.7").
06-0000-20	Auto-darkening filter 9100X, variable shade 5, 8, 9–13 (2.1"x4.2").
06-0000-30	Auto-darkening filter 9100XX, variable shade 5, 8, 9–13 (2.8"x4.2").
06-0000-30i	Auto-darkening filter 9100XXi variable shade 5, 8, 9–13









06-0116-00QR



06-0000-30i 06-0300-55i



00

04-0320-00

06-0200-51

06-0200-52 06-0200-53

06-0000-10 06-0000-20 06-0000-30 06-0000-30i

06-0200-10 06-0200-20 06-0200-30

06-0500-56 06-0500-57 06-0500-58 06-0500-59



#### Distance bar

To avoid scratches on the larger welding filters (9100X, 9100XX, 9100XXi) when raising the welding helmet, we recommend using this distance bar (included when you buy a complete helmet with these welding filters). Also sold as spare part.

Part No 06-0119-00QR





#### Earmuff bar

When using earmuffs, we recommend you to install this earmuff bar to widen the 9100-QR welding helmet.

Sold as separate accessory. Part No 06-0118-00QR

Part No	Description	Part No	Description	Part No	Description
04-0023-021)	3M <sup>™</sup> Hard hat H-701R, white (unvented).	06-0200-51B	Outer protection plate, 50/case.	X1P5E	3M™ Peltor™ Earmuffs X1 helmet attachment.
04-0320-00	Battery CR2032 Lithium 3V, 2/case.	06-0200-52	Outer protection plate scratch resistant, 10/case.	X2P5E	3M <sup>™</sup> Peltor <sup>™</sup> Earmuffs X2 helmet attachment.
04-0400-55	Battery holder for welding filter series 9100, 2/case.	06-0200-52B	Outer protection plate scratch resistant, 50/case.	X3P5E	3M <sup>™</sup> Peltor <sup>™</sup> EarMuffs X3 helmet attachment.
06-0000-10 06-0000-20	Speedglas welding filter 9100V. Speedglas welding filter 9100X.	06-0200-53	Outer protection plate heat resistant, 10/case.	X4P5E	3M™ Peltor™ Earmuffs X4 helmet attachment.
06-0000-30	Speedglas welding filter 9100XX.	06-0200-53B	Outer protection plate heat resistant, 50/case.	X5P5E	3M™ Peltor™ Earmuffs X5 helmet attachment.
06-0000-30i	Speedglas welding filter 9100XXi.	06-0300-52QR	Welding helmet 9100-QR without rail, without welding		
06-0000-30i-KIT	Speedglas welding filter kit 9100XXi (incl front cover and welding filter).	06-0300-54QR	filter, without hard hat. Welding helmet 9100-QR with rail, without welding filter,		
06-0014-00QR	Quick release rail for hard hat.		without hard hat.		
06-0114-00QR	Rubber friction pads for quick release rail.	06-0300-55 06-0300-55i	Heat-reflecting front cover 9100. Heat-reflecting front cover		
06-0116-00QR	Pivot cover plate kit for quick release welding helmets,	06-0500-56	9100XXi. Magnifying lens 1.5.		
06-0200-10	2/case. Inner cover plate for 9100V filter, 5/case. Plate marking 117×50.	06-0500-57 06-0500-58 06-0500-59	Magnifying lens 2.0. Magnifying lens 2.5. Magnifying lens 3.0.		
06-0200-20	Inner cover plate for 9100X filter, 5/case. Plate marking 117×61.	06-0119-00QR	Distance bar for welding filters 9100X, 9100XX and 9100XXi.		
06-0200-30	Inner cover plate for 9100XX/ 9100XXi filters, 5/case. Plate	06-0118-00QR	Earmuff bar for Speedglas welding helmet 9100-QR.		
06-0200-51	marking 117×77. Outer protection plate, 10/case.	18-0099-68	Ear and neck protection in leather.		

1) Many alternative colors available, see page 95

## 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet 9002NC



#### Helmet with auto-darkening filter Part No Description

04-0100-20NC

Welding helmet without side windows, with welding filter 9002NC, variable shade 8–12 (2.1"x4.2").




#### Welding filter (only)

Part No Description

04-0000-21NC

3M™ Speedglas™ Welding Filter 9002NC, variable shade 8-12 (2.1"x4.2").

#### Spare parts & accessories for 3M™ Speedglas™ Welding Helmet 9002NC



Part No	Description	Part No	Description	Part No	Description
02-0024-01	Sweatband, leather.	04-0280-01	Inner cover plate, +1 Shade,	06-0500-59	Magnifying lens 3.0.
02-0024-00	Sweatband, cotton fleece with		5/case.	06-0700-83	Hood.
	padding.	04-0280-02	Inner cover plate, +2 Shades,	07-0024-02	Sweatband, fleece, 2/case.
02-0690-00	Neck protection.		5/case.	07-0014-00NR	Hard hat adapter with assembly
04-0000-21NC	Speedglas welding filter	04-0320-00	Battery CR2032 Lithium 3V,		parts, without hard hat (not
	9002NC, shade 8-12.		2/case.		shown).
04-0023-02	3M™ Hard hat H701,	04-0380-00	Battery cover, 2/case.	16-0099-30	Head protection.
	white (unvented).	04-0112-00NC	Welding Helmet 9000 without	18-0099-68	Ear and neck protection in
04-0270-01	Outer protection plate, standard,		ADF welding filter.		leather.
	10/case.	04-0212-02NC	Front cover		
04-0270-03	Outer protection plate, scratch	05-0655-00	Headband with assembly parts.		
	resistant, 10/case.	05-0660-00	Assembly parts for headband.		
04-0270-04	Outer protection plate, heat	06-0500-56	Magnifying lens 1.5.		
	resistant, 10/case.	06-0500-57	Magnifying lens 2.0.		
04-0280-00	Inner cover plate 5/case.	06-0500-58	Magnifying lens 2.5.		

## 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet SL



#### Helmet with auto-darkening filter

Part No

Description

05-0013-41 Welding helmet SL with

welding filter, variable shade 8-12 (1.7"x3.7").



#### Welding filter (only)


Part No Description

05-0000-41

3M<sup>™</sup>Speedglas<sup>™</sup> Welding Filter SL, variable shade 8-12 (1.7"x3.7").

75

#### Spare parts & accessories for 3M™ Speedglas™ Welding Helmet SL



Part No	Description	Part No	Description	Part No	Description
18-0099-68	Ear and neck protection in	06-0500-59	Magnifying lens 3.0.	05-0695-00	Spatter protector
	leather (3 parts).	05-0680-00	Holder for magnifying lens.	05-0250-00	Outer protection plate, standard
07-0024-02	Sweatband, fleece, 2/case.	04-0320-00	Battery CR2032 Lithium 3V,		5/case. Plate marking 030226.
02-0024-01	Sweatband, leather.		2/case.	05-0250-01	Outer protection plate, scratch
02-0024-00	Sweatband, cotton fleece with	04-0290-00	Inner cover plate 5/case.		resistant, 5/case. Plate marking
	padding.		Plate marking 42 02 00.		030248.
02-0690-00	Neck protection.	05-0000-41	Speedglas welding filter SL.	05-0370-00	Battery cover.
06-0700-83	Hood black/grey.	05-0013-00	Welding helmet, without		, , , , , , , , , , , , , , , , , , , ,
06-0500-56	Magnifying lens 1.5.		headband.		
06-0500-57	Magnifying lens 2.0.	05-0655-00	Headband with assembly parts.		
06-0500-58	Magnifying lens 2.5.	05-0660-00	Assembly parts for headband.		

## 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet Series 100/100-QR



3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet 100 (black)

Part No

Description

07-0012-31BL

07-0012-00BL

With Speedglas welding filter 100V, variable shade 8-12 (1.7"x3.7"). Without welding filter, without headband.



3M™ Speedglas™ Welding Helmet 100-QR

Part No

Description

07-0114-00BLQR

Welding helmet 100-QR without welding filter, without hard hat, with QR

07-0012-31BLQR

Welding helmet 100-QR with 3M hard hat H-701R QR rail and welding filter 100-V (1.7"x3.7").







Auto-darkening filter

100S-10, single shade 10

07-0001--11

Alternative 3M™ Speedglas™ **Welding Filters** 

Part No Description

07-0001-10

07-0001-11

Auto-darkening filter 100S-11, single shade 11

(1.7"x3.7").

(1.7"x3.7"). 07-0001-31

Auto-darkening filter 100-V, variable shade

8-12 (1.7"x3.7").



Tribute

Part No Description

07-0012-31TB With filter 100V.



**Trojan Warrior helmet** Description Part No

07-0012-31TW

With filter 100V.





**Aces High helmet** 

Part No Description

07-0012-31AH With filter 100V.



Steel Rose helmet

Part No Description

07-0012-31SR

With filter 100V.



#### **Blaze helmet** Part No

07-0012-31BZ

Description

With filter 100V.

#### Spare parts & accessories for 3M™ Speedglas™ Welding Helmet Series 100/100-QR



07-0200-51

07-0200-52

07-0200-53



07-0001-31




04-0290-01

04-0290-02





07-0680-00





05-0370-00





18-0099-68



06-0700-83











05-0655-00

05-0660-00

06-0014-00QR

06-0114-00QR





07-0114-00BL-QR

07-0112-00BL-QR





Ear and neck protection in

leather.

Part No	Description	Part No	Description	Part No	Description
02-0024-00	Sweatband, cotton fleece with padding.	06-0116-00QR	Pivot cover plate kit for quick release welding helmets (QR),	07-0112-00BLQR	Welding helmet 100-QR withou rail, without filter, without hard
02-0024-01	Sweatband, leather.		2/case.		hat.
02-0690-00	Neck protection.	06-0500-56	Magnifying lens 1.5.	07-0114-00BLQR	Welding helmet 100-QR with
04-0023-021)	White 3M™ Hard hat H-701R	06-0500-57	Magnifying lens 2.0.		rail, without welding filter,
	(unvented), with ratchet	06-0500-58	Magnifying lens 2.5.		without hard hat.
	suspension.	06-0500-59	Magnifying lens 3.0.	07-0200-51	Outer protection plate, standar
04-0290-00	Inner cover plate, 5/case.	06-0700-83	Hood.		10/case.
	Plate marking 42 02 00.	07-0001-10	Speedglas welding filter 100S-	07-0200-52	Outer protection plate, scratch
04-0290-01	Inner cover plate, +1 shade,		10, single shade 10.		resistant, 10/case.
	5/case.	07-0001-11	Speedglas welding filter 100S-11,	07-0200-53	Outer protection plate, heat
04-0290-02	Inner cover plate, +2 shade,		single shade 11.		resistant, 10/case.
	5/case.	07-0001-31	Speedglas welding filter 100V,	07-0212-00SV	Front frame, silver.
04-0320-00	Battery CR2032 Lithium 3V,		variable shade 8–12.	07-0680-00	Holder for magnifier (older
	2/case.	07-0012-00BL	100 welding helmet black,		models of welding filters).
05-0370-00	Battery cover.		without filter, without headband.	16-0099-30	Head protection.

Hard hat adapter (loop),

Sweatband, fleece, 2/case.

with assembly parts.

07-0014-00NR

07-0024-02

1) Many alternative colors available, see page 95

release rail.

Headband with assembly parts.

Assembly parts for headband.

Quick release rail for hard hat.

Rubber friction pads for quick

## 3M<sup>™</sup> Welding Helmets 10V



3M™ Welding Helmet 10V Description


10 11 21 with welding filter 10V, variable shade 10-12 (1.7"x3.7").




3M™ Welding Filter 10V Description

Welding filter 10V, variable shade 10–12 (1.7"x3.7").

#### Spare parts & accessories for 3M™ Welding Helmets 10V





Part No	Description	Part No	Description
10 00 03 10 11 85	3M welding filter 10V, shade 10–12. Welding helmet 10V without	04-0320-00	Battery CR2032 Lithium 3V, 2/case.
12 60 00	headband, without welding filter. Outer protection plate.	04-0290-00	Inner cover plate 5/case. Plate marking 42 02 00.
16 50 05	Headband with assembly parts.	05-0370-00	Battery cover.
16 60 00 16 74 10	Assembly parts for headband. Sweatband.	18-0099-68	Ear and neck protection in leather (3 parts).

## **3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmets** FlexView / ProTop / Utility



#### Spare parts for 3M™ Speedglas™ Welding Helmets FlexView / ProTop / Utility



02-0024-00

02-0024-01

07-0024-02

Part No



18-0099-68

Description



Part No

06-0700-83


04-0320-00 04-0380-00

06-0500-56 06-0500-57 06-0500-58 06-0500-59

04-0290-00 04-0280-00 04-0290-01 04-0270-01 04-0280-01 04-0270-03 04-0290-02 04-0270-04 04-0280-02

04-0112-00NC

04-0212-02NC



	Part No	Description
).	06-0500-58 06-0500-59 06-0700-83 07-0024-02 16-0099-30 18-0099-68	Magnifying lens 2.5. Magnifying lens 3.0. Hood. Sweatband, fleece, 2/case. Head protection. Ear and neck protection in leather.

02-0024-00	Sweatband, cotton fleece with padding.	04-0280-02	Inner cover plate (2.1"x4.1"), +2 Shade, 5/case.	06-0500-58 06-0500-59	Magnifying lens 2.5. Magnifying lens 3.0.
02-0024-01	Sweatband, leather.	04-0290-00	Inner cover plate (1.7"x3.6")	06-0700-83	Hood.
02-0690-00	Neck protection.		5/case. Plate marking 42 02 00.	07-0024-02	Sweatband, fleece, 2/case
04-0112-00NC	Helmet without side windows,	04-0290-01	Inner cover plate (1.7"x3.6"),	16-0099-30	Head protection.
	without headband, without		+1 Shade for 9002D/9002V	18-0099-68	Ear and neck protection in
	welding filter.		filters, 5/case.		leather.
04-0212-02NC	Front cover.	04-0290-02	Inner cover plate (1.7"x3.6"),		
04-0216-00	Front cover FlexView, silver.		+2 Shade 5/case.		
04-0260-00	Protective visor plate FlexView,	04-0320-00	Battery CR2032 Lithium 3V,		
	10/case.		2/case.		
04-0270-01	Outer protection plate, standard,	04-0360-00	Holder for welding filter		
	10/case. Plate marking 42 01 50.		(FlexView).		
04-0270-03	Outer protection plate, scratch	04-0361-00	Middle helmet FlexView, black.		
	resistant, 10/case.	04-0380-00	Battery cover, 2/case.		
	Plate marking 42 01 00.	04-0460-00	Speedglas FlexView Conversion		
04-0270-04	Outer protection plate, heat		Kit.		
	resistant, 10/case. Plate marking	04-0550-00	FlexView locking wedge kit,		
	42 01 71 HEAT.		holder welding filter (not shown).		
04-0280-00	Inner cover plate (2.1"x4.1")	05-0655-00	Headband with assembly parts.		
	5/case. Plate marking 42 02 10.	05-0660-00	Assembly parts for headband.		
04-0280-01	Inner cover plate	06-0500-56	Magnifying lens 1.5.		
	(2.1"x4.1"), +1 Shade 5/case.	06-0500-57	Magnifying lens 2.0.		

Description

### Welding and grinding respiratory systems





- 1. Prefilter<sup>1)</sup>
- 2. HE particulate filter<sup>1)</sup>
- 3. Nuisance Odor Filter Not needed when you use OV/AG cartridge.
- 4. OV/AG cartridge<sup>4)</sup> 5. Backpack

More information about Adflo accessories see page 83.





### 3M™ Adflo™ Battery Charger Organizing Stand

The 6-position battery charger organizing stand for Adflo battery chargers provides the ability to charge six batteries at the same time, saving both time and hassle. Compatible with legacy NiMH batteries and the new Li-ion batteries. Flexible installation: either mount on wall or stand-alone. Part No: 35-0099-08N6 Batteries and chargers not included

1) Included as standard when you order a complete 3M™ Adflo™ PAPR System with welding helmet; must always be used.

2) For welders working at higher altitudes there is a special respirator version to adjust for changes in air density: 3M™ Adflo™ High Altitude Turbo.

3) The 3M™ Speedglas™ Breathing Tube SG-50W is required when used with 3M™ Adflo™ PAPR with HE filter and OV/AG cartridge and 3M™ Speedglas™ Welding Helmets 9100-Air , 9100MP or 3M™ Versaflo™ Helmet M-407. The SG-50W breathing tube is not NIOSH approved with 3M™ Supplied Air Valves V-Series.

4) OV/AG cartridge must always be used together with HE filter.



## Still using an older version of our welding respiratory helmets?

Did you know you can easily upgrade to our current premium welding helmets, without buying a new Adflo or Versaflo system? Our 9100 series helmets feature the QRS (Quick Release Swivel) type of breathing tube, which enables one-handed connection and release.

Below you will find ordering information to get a helmet kit, including welding filter and breathing tube. To help protect your new helmet system from scratches, we include a special Speedglas storage bag for free.




#### 3M™ Speedglas™ Welding Helmet 9100-Air Description

1 411110	Bescription
35-1101-00SW	Welding helmet 9100-Air witho welding filter), with self-adjusti QRS breathing tube (20.6" to 33.5") and storage bag.
35-1101-10SW	Welding helmet 9100-Air with welding filter 9100V (1.8"x3.7"), self-adjusting QRS breathing tu (20.6" to 33.5") and storage bas
35-1101-20SW	Welding helmet 9100-Air with welding filter 9100X (2.1"x4.2"), self-adjusting QRS breathing tu (20.6" to 33.5") and storage bas
35-1101-30iSW	Welding helmet 9100-Air with welding filter 9100XXi (2.8"x4.2"), self-adjusting QRS breathing tube (20.6" to 33.5") and storage bag.



3M™ Speedglas™ Welding Helmet 9100 FX-Air





art No	Description
S-1101-00SW	Welding helmet 9100 FX-Air without welding filter, with self- adjusting QRS breathing tube (20.6" to 33.5") and storage bag
3-1101-10SW	Welding helmet 9100 FX-Air with welding filter 9100V (1.8"x3.7"), self-adjusting QRS breathing tube (20.6" to 33.5") and storage bag.
5-1101-20SW	Welding helmet 9100 FX-Air welding filter 9100X (2.1"x4.2"), self-adjusting QRS breathing tube (20.6" to 33.5") and storage bag.
s-1101-30iSW	Welding helmet 9100 FX-Air welding filter 9100XXi (2.8"x4.2"), self-adjusting QRS breathing tube (20.6" to 33.5") and storage bag.



3M™ Speedglas™ Welding Helmet 9100MP Description

37-1101-00SW	Welding helmet 9100 MP without welding filter, with self- adjusting QRS breathing tube (20.6" to 33.5") and storage bag
37-1101-10SW	Welding helmet 9100 MP with welding filter 9100V (1.8"x3.7"), self-adjusting QRS breathing tube (20.6" to 33.5") and storage bag.
37-1101-20SW	Welding helmet 9100MP with welding filter 9100X (2.1"x4.2"), self-adjusting QRS breathing tube (20.6" to 33.5") and storage bag.
37-1101-30iSW	Welding helmet 9100MP with welding filter 9100XXi (2.8"x4.2"), self-adjusting QRS breathing tube (20.6" to 33.5") and storage bag.

## **3M<sup>™</sup> Adflo<sup>™</sup> Powered Air Respirator**



Respirator without headtop

– for use with 9100 Series Headtops

Part No Description

Part No

35-5401-01 Adflo respirator with SG-30W self-adjusting breathing tube, airflow indicator, prefilter, spark arrestor, HE particulate filter, battery, belt and charger.



## Respirator without headtop – for use with L-Series Headtops

Part No Description

34-5401-02SG Adflo respirator with

Adflo respirator with L-122SG breathing tube, airflow indicator, prefilter, spark arrestor, HE particulate filter, battery, belt and charger.



## Respirator without headtop – for use in High Altitude environments


Part No	Description

35-3499-01

Adflo HA respirator with self adjusting breathing tube QRS, breathing tube adapter, airflow indicator, prefilter, spark arrestor, HE particulate filter, battery, belt and charger.

## See a demo on how to replace your parts and maintain your welding respirator systems

#### Spare parts & accessories 3M™ Adflo™ Powered Air Respirator



Part No	Description	Part No	Description	Part No	Description
BPK-01	Backpack	15-0099-12	O-ring for breathing tube	35-0099-08	Charger for Li-ion battery
L-122SG	Breathing tube for L-series		assembly 15-0099-10.	35-0099-08N6	Docking station for chargers.
	headgear.		(not shown).	35-0099-14	Belt connection (not shown)
SG-15	Flame resistant breathing tube	15-0099-16	Belt, leather.	35-0699-9901	Nuisance odor filter
	cover (replaces 17-0099-54).	15-0099-20	Flow Indicator rubber adapter	35-0699-9901	Nuisance odor filter pad
SG-30W	Breathing tube, self-adjusting,		(not shown).	35-0699-9901	Nuisance odor filter pad, 10/c
	with QRS connection.	15-0099-21	Flow Indicator.	35-1099-01	PAPR assembly and filter cover
SG-40W	Breathing tube, heavy-duty, with	15-0099-9906	Prefilter, 6/case.	35-1099-07	Battery Li-ion
	QRS connection.	15-0099-9912	Prefilter, 12/case.	35-1099-81	PAPR filter cover
SG-50W*	Breathing tube, sound-	15-0299-9902	HE particulate filter, 2/case.	35-5401-01*	Adflo PAPR with SG-30W
	dampening, with QRS	15-0299-9906	HE particulate filter, 6/case.		self-adjusting breathing tube,
	connection.	15-0299-9936	HE particulate filter, 36/case.		airflow indicator, prefilter,
SG-90	Carry bag, black.	15-0499-9902	OV/AG cartridge, 2/case		spark arrestor, filter cover, HE
06-0500-65	Protective bag	15-0499-9906	OV/AG cartridge, 6/case		particulate filter, battery, belt
15-0009-9902	Spark arrestor, 2/c	15-1101-99	Battery NiMH		and charger.
15-0099-05	Airflow indicator	15-1101-99	Adflo service kit: HE particulate		
15-0099-06	Leather belt front extender		filters 2/c, prefilters 6/c, spark		
15-0099-08	Charger for NiMH battery		arrestor 2/case.		
15-0099-10	Breathing tube assembly	34-5401-02SG*	Adflo PAPR with L-122SG		
	(including gasket and o-ring)		breathing tube, airflow indicator,		
15-0099-11	Gasket for non-QRS breathing		prefilter, spark arrestor, filter		
	tubes (not shown).		cover, HE particulate filter,		
			battery, belt and charger		

<sup>\*</sup> The 3M™ Speedglas™ Breathing Tube SG-50W is required when used with 3M™ Adflo™ PAPR with HE filter and OV/AG cartridge and 3M™ Speedglas™ Welding Helmets 9100-Air or 9100 MP.

Always read and follow all User Instructions.

## 3M<sup>™</sup> Speedglas<sup>™</sup> Fresh-air III Supplied Air Regulators



## Vortex supplied air regulator V-100 Part No Description

V-100

Vortex cooling assembly, includes valve V-150, belt W-2963 and holder.



## Vortemp supplied air regulator V-200 Part No Description

V-200

Vortemp heating assembly, includes valve V-250, belt W-2963 and holder.



## Regulator with air regulating valve V-300 Part No Description


\_\_\_\_

V-300

3M™ Versaflo™ Air Regulating Valve Assembly.

	3M™ Supplied Air Hoses		3M™ Filter and Regulator Panels		
Available Supplied Air Hoses and Panels					
Part Numbers	W-9425-25 (25 ft). W-9435-50 (50 ft). W-9435-100 (100 ft).	W-2929-25 (25 ft). W-2929-50 (50 ft). W-2929-100 (100 ft).	W-2806 Filter and Regulator Panel, 50 cfm W-2808 CO Monitor Retrofit Kit.	256-02-00 Portable Filter and Regulator Panel, 50 cfm.	
Applications	3/8 in High Pressure Hose (25, 50, or 100 ft).		Helps to remove water, oil, particles, odors and vapors.	Removes limited amounts of carbon monoxide and other contaminants without using large desiccant drying towers.	

#### Spare parts & accessories for 3M™ Speedglas™ Fresh-air III Supplied Air Systems



Part No	Description	Part No	Description	Part No	Description
L-122SG	Breathing tube for L-series	W-3079	Manifold.	W-2929-100	High pressure air supply hose,
	headgear.	W-3094M	Filter housing assembly.		100 ft.
SG-15	Flame resistant breathing tube	W-3095	Filter housing base (part of	W-2963	Waist belt, cotton.
	cover (replaces 17-0099-54).		W-3094M).	W-9435-25	High pressure air supply hose,
SG-30W	Breathing tube, self-adjusting, with	W-3096	Air pressure regulator.		25 ft.
	QRS connection.	W-3098	Drain valve.	W-9435-50	High pressure air supply hose,
SG-40W	Breathing tube, heavy-duty, with	W-3099	Air pressure gauge.		50ft.
	QRS connection.	W-3182-2	Socket, 3/8 in MPT, 1/4 in body	W-9435-100	High pressure air supply hose,
SG-50W	Breathing tube, sound-dampening,		size, schrader, 2/case (not shown).		100 ft.
	with QRS connection.	W-3281-2	Socket, hansen S23 (3/8 in.	19-0099-63	Fresh-air III breathing tube
W-1449-2	Socket, 3/8 in. MPT, 1/4 in. body		Male NPT), 2/case (not shown).		V-Series.
	size, industrial interchange,	V-111	Vortex muffler kit (replacement	256-02-00	Portable compressed air filter an
	2/case.		muffler for the cooling assembly		regulator panel, 50 cfm,
W-1596	Pressure relief valve.		V-100).		4 outlets, with carbon monoxide
W-2119	Socket dust cap.	V-115	Vortex spare parts kit (for the		filtration and monitor.
W-2806	Compressed air filter and regulator		cooling assembly V-100).	256-02-01	Portable compressed air and
	panel.	V-150	Vortex cooling valve.		regulator panel, 100 cfm,
W-2808	CO monitor with retrofit kit	V-199	Adapter (for use with SG-30W and		8 outlets, with carbon monoxide
	(not shown).		SG-40W breathing tubes), 4/case.		monitor.
W-2811-10	Filter cartridge, 10/case.	V-211	Vortemp muffler kit (replacement	529-04-48	Calibration kit, large
W-2915M	Aluminum filter bowl.		muffler for the heating assembly		(not shown).
W-2916	Wing nut.		V-200).	529-04-49	Calibration kit, small
W-2920	Nut base.	V-215	Vortemp spare parts kit (for the		(not shown).
W-2921	Bowl gasket.		heating assembly V-200).	529-04-50	Adapter, 110-120 Volts AC
W-2923	Cartridge washer.	V-250	Vortemp heating valve.		(not shown).
W-2924	Air deflector.	W-2929-25	High pressure air supply hose,	529-05-20	Remote alarm and strobe audible
W-2925	Air deflector gasket.		25 ft.		(not shown).
W-3012	Coalescing filter assembly.	W-2929-50	High pressure air supply hose, 50 ft.		•
W-3013-4	High efficiency filter element for		J		

Always read and follow all User Instructions.

W-3012 (not shown), 4/case.

## 3M™ Speedglas™ Welding Helmet 9100-Air Systems







06-0000-30i

06-0000-20



06-0000-10





06-0000-30

Helmet with powered air systems - HE particulate filtration

Part No	Description		
35-1101-00SW	Without welding filter with		
	Adflo PAPR and HE filter.		
35-1101-10SW	With Speedglas welding		
	filter 9100V (1.8"x3.7" and		
	Adflo PAPR with HE filter.		
35-1101-20SW	With Speedglas welding		
	filter 9100X (2.1"x4.2") and		
	Adflo PAPR with HE filter.		
35-1101-30iSW	With Speedglas welding		
	filter 9100XXi (2.8"x4.2")		
	and Adflo PAPR with HE filt		


Helmet with supplied air systems - V-100 cooling valve

Part No	Description
25-5702-00SW	Without welding filter with Fresh-air III SAR, V-100 cooling valve (available in 2018).
25-5702-30iSW	With Speedglas welding filter 9100XXi (2.8"x4.2") and Fresh-air III SAR, V-100 cooling valve.

Alternative 3M™ Speedglas™ **Welding Filters** 

Description
Auto-darkening filter
9100V, variable shade
5, 8, 9–13 (1.8"x3.7").
Auto-darkening filter
9100X, variable shade
5, 8, 9-13 (2.1"x4.2").
Auto-darkening filter
9100XX, variable shade
5, 8, 9-13 (2.8"x4.2").
Auto-darkening filter
9100XXi variable shade
5, 8, 9-13 (2.8"x4.2").

#### Spare parts & accessories for 3M™ Speedglas™ Welding Helmet 9100-Air









04-0400-55

06-0000-30i

 $\bigcirc$ 

04-0320-00

06-0000-30i-KIT





06-0200-10

06-0200-20

06-0200-30





06-0000-10

06-0000-20

06-0000-30 06-0000-30i






06-0500-52



#### Maintenance tips for 3M™ Speedglas™ Welding Helmet 9100-Air



Adjust the air duct length to your personal preferences.



A face seal in good working order is essential at all times. Do you know how to replace it?



For additional protection against sparks or to cover for inside glare the extended head cover might be useful.

#### Part No Description Part No Description Part No Description 04-0320-00 06-0200-52B Part no 06-0200-52, 50/case Battery, 2/case. 06-0500-51 Extended coverage, crown. Welding filter 9100V. 06-0000-10 06-0200-53 06-0500-52 Outside protection plate high Extended coverage, ear and neck. Welding filter 9100X. 06-0000-20 temperature,10/case 06-0500-53 SideWindow cover plates, 06-0200-53B Part no 06-0200-53, 50/case 06-0000-30 Welding filter 9100XX. 2/case 06-0000-30i Welding filter 9100XXi 06-0200-54 Comfort sweatband, 3/case 06-0500-56 Magnification plate 1.5x. 06-000030iKIT Welding filter kit 9100XXi, 06-0200-54B Comfort sweatband, 12/case 06-0500-57 Magnification plate 2.0x. 06-0500-58 Magnification plate 2.5x. (filter and silver front) 06-0300-55 Silver front panel. 06-0200-10 Inside protection plate 9100V, Part no 06-0300-55, 5/case. 06-0300-55B 06-0500-59 Magnification plate 3.0x. 5/case 06-0300-55i Heat-reflecting front cover 06-0700-83 Full hood, black/grey 06-0200-10B Part no 06-0200-10, 25/case 9100XXi. 25-0099-28 06-0200-20 Inside protection plate 9100X, 06-0400-51 Headband incl assembled parts. 25-0099-35SW Welding helmet 9100-Air, without welding filter. 06-0400-51B Part no 06-0400-51, 5/case 5/case 06-0200-20B Part no 06-0200-20, 25/case 06-0400-52 25-0400-55 Air duct tube. Pivot mechanism headband. 06-0200-30 left and right. Inside protection plate Carry bag, black. 9100XX/9100XXi, 5/case 06-0400-52B Part no 06-0400-52, 5/case 06-0200-30B Part no 06-0200-30, 25/case 06-0400-53 Headband front part. 06-0400-53B Part no 06-0400-53, 5/case 06-0200-51 Outside protection plate standard, 10/case 06-0400-54 Headband back part. 06-0200-51B Part no 06-0400-54, 5/case Part no 06-0200-51, 50/case 06-0400-54B 06-0200-52 Outside protection plate scratch 06-0400-55 Battery holder 9100, 2/case resistant, 10/case 06-0400-55B Part no 06-0400-55, 10/case

1) Please use Part No 26-0099-35SW when new side windows are required.

## 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet 9100 FX-Air Systems







06-0000-30i





06-0000-10

06-0000-20 06-0000-30

#### Helmet with powered air systems - HE particulate filtration

Part No	Description
36-1101-00SW	Without welding filter
	with Adflo PAPR and HE
	filter.
36-1101-10SW	With Speedglas welding
	filter 9100V (1.8"x3.7") and
	Adflo PAPR with HE filter.
36-1101-20SW	With Speedglas welding
	filter 9100X (2.1"x4.2") and
	Adflo PAPR with HE filter.
36-1101-30iSW	With Speedglas welding
	filter 9100XXi (2.8"x4.2")
	and Adflo PAPR with HE
	filter.
36-1101-00SWHA	Without welding filter with Adflo
	High Altitude PAPR with HE filter.

#### **Helmet with** supplied air system

raitino	Description
26-5702-00SW	Without welding filter, with Fresh-air III SAR, V-100
	cooling valve.
26-5702-30iSW	With Speedglas welding filter 9100XXi (2.8"x 4.2") and
	Fresh-air III SAR, V-100 cooling valve. Available in 2018.

#### Alternative 3M™ Speedglas™ **Welding Filters**

Description
Auto-darkening filter 9100V, variable shade 5, 8, 9–13 (1.8"x3.7").
Auto-darkening filter 9100X, variable shade 5, 8, 9–13 (2.1"x4.2").
Auto-darkening filter 9100XX, variable shade 5, 8, 9–13 (2.8"x4.2").
Auto-darkening filter 9100XXi variable shade 5, 8, 9–13 (2.8"x4.2").

#### Maintenance tips for 3M™ Speedglas™ Welding Helmet 9100 FX-Air



It is important that the face seal is correctly mounted and fitted to provide the correct protection factor.




Is your clear visor not so clear anymore, after periods of frequent grinding? From our YouTube channel you will learn how to replace it.




If you need additional protection for your head, see how to assemble the head cover for additional protection against sparks here.

#### Spare parts & accessories for 3M™ Speedglas™ Welding Helmet 9100 FX-Air



#### 26-0099-35SW











06-0700-82

06-0500-52

Part No	Description	Part No	Description	Part No	Description
04-0320-00	Battery, 2/case.	06-0200-53B	Outer protection plate heat	06-0500-58	Magnification plate 2.5x.
06-0000-10	Welding filter 9100V.		resistant, 50/case.	06-0500-59	Magnification plate 3.0x.
06-0000-20	Welding filter 9100X.	06-0200-54	Comfort sweatband, 3/case	06-0700-51	Wide-view clear grinding visor,
06-0000-30	Welding filter 9100XX.	06-0200-54B	Comfort sweatband (bulk),		standard, 5/case.
06-0000-30i	Welding filter 9100XXi.		12/case	06-0700-54	Wide-view clear grinding visor,
06-0200-10	Inside protection plate 9100V,	06-0400-51	Headband incl assembled parts.		anti-fog, 5/case.
	5/case	06-0400-51B	Part no 06-0400-51 (bulk),	06-0700-63	Front panel, chrome.
06-0200-10B	Part no 06-0200-10 (bulk),		5/case	06-0700-64	Wide-view clear grinding visor
	25/case	06-0400-52	Pivot mechanism headband,		frame, black
06-0200-20	Inside protection plate 9100X,		left and right.	06-0700-73	SideWindow cover plates,
	5/case	06-0400-52B	Part no 06-0400-52 (bulk),		2/case
06-0200-20B	Part no 06-0200-20 (bulk),		5/case	06-0700-82	Extended head cover, head and
	25/case	06-0400-53	Headband front part.		neck.
06-0200-30	Inner cover plate for 9100XX/	06-0400-53B	Part no 06-0400-53 (bulk),	06-0700-83	Full hood, black/grey.
	9100XXi filters, 5/case. Plate		5/case	06-0700-85	Air diffuser
	marking 117×77.	06-0400-54	Headband back part.	26-0099-28	Face seal
06-0200-51	Outer protection plate,	06-0400-54B	Part no 06-0400-54 (bulk),	26-0099-35SW	Welding helmet 9100 FX-Air
	10/case.		5/case		without welding filter, with
06-0200-51B	Outer protection plate,	06-0400-55	Battery holder 9100, 2/case		headband.
	50/case.	06-0400-55B	Part no 06-0400-55 (bulk),	26-0400-55	Duct assembly.
06-0200-52	Outer protection plate scratch		10/case.	SG-90	Product storage bag.
	resistant, 10/case.	06-0500-52	Extended coverage, ear and		
06-0200-52B	Outer protection plate scratch		neck.		
	resistant, 50/case.	06-0500-56	Magnification plate 1.5x.		
06-0200-53	Outer protection plate heat resistant, 10/case.	06-0500-57	Magnification plate 2.0x.		

## 3M™ Speedglas™ Welding Helmet 9100 MP Systems



#### Helmet with powered air systems - HE particulate filtration

The particulate intration			
Part No	Description		
37-1101-00SW	Without welding filter with Adflo PAPR and HE filter.		
37-1101-10SW	With Speedglas welding filte 9100V (1.8"x3.7") and Adflo PAPR with HE filter.		
37-1101-20SW	With Speedglas welding filte 9100X (2.1"x4.2") and Adflo PAPR with HE filter.		
37-1101-30iSW	With Speedglas welding filte 9100XXi (2.8"x4.2") and Adflo PAPR with HE filter.		
37-1101-00SWH	A Without welding filter with Adflo High Altitude PAPR with HE filter.		



#### Helmet with supplied air systems Part No Description 37-5702-00SWSR Without welding filter with Fresh-air III SAR, V-100 cooling valve and Shrader fitting. 37-5702-00SW Without welding filter, with Fresh-air III SAR, V-100 cooling valve. 37-5702-30iSW With Speedglas welding filter 9100XXi (2.8"x 4.2") and Fresh-air III SAR, V-100 cooling valve. Available in 2018.



06-0000-30i








06-0000-20

#### Alternative 3M™ Speedglas™ **Welding Filters**

Part No	Description
06-0000-10	Auto-darkening filter 9100V, variable shade 5, 8, 9–13 (1.8"x3.7").
06-0000-20	Auto-darkening filter 9100X, variable shade 5, 8, 9–13 (2.1"x4.2").
06-0000-30	Auto-darkening filter 9100XX, variable shade 5, 8, 9–13 (2.8"x4.2").
06-0000-30i	Auto-darkening filter 9100XXi variable shade 5, 8, 9–13 (2.8"x4.2").

#### Spare parts & accessories for 3M™ Speedglas™ Welding Helmets 9100 MP







2 2

04-0400-55



00

04-0320-00

27-0099-35SW









06-0200-53




06-0000-30

06-0000-30i



06-0200-20

06-0200-30



06-0500-56 06-0500-57

06-0500-58

06-0500-59

### Maintenance tips for 3M™ Speedglas™ Welding Helmet 9100 MP



Need to re-fresh the head protection on your 9100MP? See how to remove the hard hat.



See how to install the heatreflecting, silver-coated helmet cover.



Need higher attenuation for your hearing protection, or is it just time to replace the old ones?

#### Part No Description Part No Part No Description Description M-350 Versaflo replacement head 06-0200-52B Outer protection plate scratch 06-0700-64 Wide-view clear grinding visor resistant, 50/case. frame, black M-957 Versaflo forehead comfort 06-0200-53 Outer protection plate heat 06-0700-73 SideWindow cover plates, resistant, 10/case. pad/sweat pad, 10/case. 2/case. M-985 06-0200-53B 27-0099-28 3M™ Peltor™ Earmuff Outer protection plate heat Face seal Welding helmet 9100 MP with Assembly Kit resistant, 50/case. 27-0099-35SW SG-90 Carry bag, black. 06-0202-10 Starter kit 9100V (for 9100 hard hat, without welding filter. 04-0320-00 MP), incl 5 outside protection 27-0099-52 Battery, 2/case. Pivot kit Welding filter 9100V. 06-0000-10 27-0099-53 plates, 2 inside protection Flip-up mechanism 06-0000-20 Welding filter 9100X. 27-0099-63 Inner shield plates, and 1 sweat pad Welding filter 9100XX. 06-0202-20 06-0000-30 Starter kit 9100X (for 9100 27-0099-68 Outer shield 06-0000-30i Welding filter 9100XXi. MP), incl 5 outside protection 27-0099-72 Hard hat incl pivot kit 06-0200-10 Inside protection plate 9100V, plates, 2 inside protection 27-0099-84 Radiant heat hard hat cover for 5/case plates, and 1 sweat pad 9100 MP helmet. 06-0200-10B Part no 06-0200-10 (bulk), 06-0202-30 Starter kit 9100XX (for 9100 27-0099-85 Throat and neck coverage. 25/case MP), incl 5 outside protection Not shown 06-0200-20 27-0099-87 Inside protection plate 9100X, plates, 2 inside protection Complete neck coverage for plates, and 1 sweat pad 9100MP 06-0200-20B Part no 06-0200-20 (bulk), 06-0400-54 Headband back part. 06-0400-54B Part no 06-0400-54 (bulk), 25/case Inner cover plate for 9100XX/ 06-0200-30 06-0400-55 Battery holder 9100, 2/case 9100XXi filters, 5/case. Plate marking 117×77. 06-0400-55B Part no 06-0400-55 (bulk), 06-0200-51 Outer protection plate, 10/case. 06-0700-51 10/case. Wide-view clear grinding visor, 06-0200-51B Outer protection plate, standard, 5/case 06-0700-54 Wide-view clear grinding visor, 50/case. 06-0200-52 Outer protection plate scratch anti-fog, 5/case. resistant, 10/case. 06-0700-63 Front panel, chrome.


## 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet L-Series SG



Headgear with shroud L-905 SG

Part No	Description
34-0905-SGV	Helmet L-905SG wideview faceshield with Speedglas welding filter 9100V and Adflo PAPR with HE filter.
34-0905-SGX	Helmet L-905SG wideview faceshield with Speedglas welding filter 9100X and Adflo PAPR with HE filter.
34-0905-SGXX	Helmet L-905SG wideview faceshield with Speedglas welding filter 9100XX and Adflo PAPR with HE filter.

Spare parts see page 93.



## **3M**<sup>™</sup> Protective Visor for respiratory protection




#### Spare parts


Part No	Description
07-0024-02	Sweatband, fleece, 2/case
16-0099-27	Brow guard
16-0099-28	Face seal
16-0099-29	Faceseal and headband assembly with air duct.
16-0099-30	Headcover, FR cotton (not shown).
16-0099-32	Clear window with fasteners and
	face seal, without brow guard.
16-0099-35	ClearVisor polycarbonate
16-0300-9905	Clear window strip off shielding film, 5/case







Spare parts & accessories for 3M™ Speedglas™ Headgear L-Series SG



04-0320-00 2 2 04-0400-55

06-0200-52

06-0200-53

06-0000-20 06-0200-20 06-0000-30 06-0200-30 06-0000-30i


06-0500-56 06-0500-57 06-0500-58 06-0500-59

Part No	Description	Part No	Description	Part No	Description
L-153SG	Welding helmet kit	L-905SG-F	Helmet with welding helmet	06-0200-52	Outer protection plate scratch
L-154SG	Silver front panel		and wideview faceshield.		resistant, 10/case.
L-199SG	Breathing tube cover, high temperature.	04-0320-00 06-0000-10	Battery, 2/case. Welding filter 9100V.	06-0200-52B	Outer protection plate scratch resistant, 50/case.
L-223-2	Outer shroud standard.	06-0000-20	Welding filter 9100X.	06-0200-53	Outer protection plate heat
L-225-2	Outer shroud, flame retardant.	06-0000-30	Welding filter 9100XX.		resistant, 10/case.
L-226-2	Inner shroud	06-0000-30i	Welding filter 9100XXi.	06-0200-53B	Outer protection plate heat
L-227	Outer shroud, flame retardant,	06-0200-10	Inside protection plate 9100V,		resistant, 50/case.
	leather		5/case	06-0500-56	Magnification plate 1.5x.
L-228-2	Outer shroud, nylon	06-0200-10B	Part no 06-0200-10 (bulk),	06-0500-57	Magnification plate 2.0x.
L-705SG	Hard hat with welding helmet		25/case	06-0500-58	Magnification plate 2.5x.
	and wideview faceshield, without welding filter.	06-0200-20	Inside protection plate 9100X, 5/case	06-0500-59	Magnification plate 3.0x.
L-705SG-F	Hard hat with welding helmet and wideview faceshield	06-0200-20B	Part no 06-0200-20 (bulk), 25/case		
L-901SG	Helmet with wideview faceshield	06-0200-30	Inner cover plate for 9100XX/ 9100XXi filters, 5/case.		
L-905SG	Helmet with welding helmet	06-0200-51	Outer protection plate, 10/case.		
	and wideview faceshield, without welding filter.	06-0200-51B	Outer protection plate, 50/case.		

## 3M<sup>™</sup> Speedglas<sup>™</sup> Welding Helmet 9000 HWR for respiratory protection



#### Spare parts & accessories



Part No	Description	Part No	Description	Part No	Description
02-0024-00	Sweatband, cotton fleece with	04-0280-00	Inner cover plate (2.1"x 4.1"),	04-0460-00	FlexView kit.
	padding.		5/case. Plate marking 42 02 10.	06-0500-56	Magnifying lens 1.5.
02-0024-01	Sweatband, leather.	04-0280-01	Inner cover plate (2.1" x4.1"),	06-0500-57	Magnifying lens 2.0.
02-0690-00	Neck protection.		+1 Shade, 5/case.	06-0500-58	Magnifying lens 2.5.
04-0067-00	Assembly parts for headband.	04-0280-02	Inner cover plate (2.1" x4.1"),	06-0500-59	Magnifying lens 3.0.
04-0212-02NO	Front cover.		+2 Shade, 5/case.	06-0700-83	Hood.
04-0216-00	Heat-reflecting front cover	04-0290-00	Inner cover plate (1.7" x 3.6"),	07-0024-02	Sweatband, fleece, 2/case.
	FlexView, silver.		5/case.	14-0099-28	Face seal 9000 HWR.
04-0260-00	Protective visor plate FlexView,		Plate marking 42 02 00.	14-0099-29	Headband assembly 9000 HWR,
	10/case.	04-0290-01	Inner cover plate (1.7" x3.6"),		with air duct.
04-0270-01	Outer protection plate, standard,		+1 Shade, 5/case.	15-1699-29	Headband assembly FlexView
	10/case. Plate marking 42 01 50.	04-0290-02	Inner cover plate (1.7" x3.6"),		HWR, with air duct.
04-0270-03	Outer protection plate, scratch		+2 Shade, 5/case.	15-1699-28	Face seal FlexView HWR.
	resistant, 10/case. Plate marking	04-0320-00	Battery CR 2032 Lithium 3V,	16-0099-30	Head protection.
	42 01 00.		2/case.	18-0099-68	Ear and neck protection in leather.
04-0270-04	Outer protection plate, heat	04-0360-00	Holder for welding filter (FlexView).		
	resistant, 10/case.	04-0361-00	Middle helmet FlexView, black.		
	Plate marking 42 01 71.	04-0380-00	Battery cover, 2/case.		

### 3M™ Hard Hat H-700

The 3M™ Speedglas™ Quick Release (QR) Rail allows you to attach a Speedglas welding helmet to many of the industry's most popular hard hats. 3M offers a complete QR welding helmet system including the

white, unvented 3M<sup>™</sup> Hard Hat H-701. The hard hat is available in 6 colors when you buy it separately, see below.

Internal slots for accessory earmuffs.

Ventilated headband and ratchet suspension for improved comfort.

For Quick Release (QR) welding helmets we offer the unvented hard hat model (04-0023-02) for protection of sparks and radiation.

Certified to ANSI Z89.1-2009. Very low temperature (-30 C) Molten metal splash (MM) Electrical insulation (440 Vac)

Short brim and compact design for increased user mobility and visibility.



H-702R





H-706R





H-703R



H-704R





Always read and follow all User Instructions.

## 3M<sup>™</sup> Versaflo<sup>™</sup> M-Series Headtops









M-407


Spare parts & accessories


















Part No	Description
M-960	Pivot kit.
M-972	Flame resistant headtop cover.
M-976	Head, neck and shoulder cover.
SG-15	Flame resistant breathing tube cover (replaces 17-0099-54).
SG-30W	Breathing tube, self-adjusting, with QRS connection.
SG-40W	Breathing tube, heavy-duty, with QRS connection.
SG-50W	Breathing tube, sound-dampening, with QRS connection.
M-985	3M™ Peltor™ Earmuff Assembly Kit







## **Product index**

Part No	Page
100003	78
101121	78
101185	78
126000	78
165005	78
166000	78
167410	78
847720	96
857720	96
02-0024-00	74–75, 77, 79, 94, 96
02-0024-01	74–75, 77, 79, 94
02-0690-00	74–75, 77, 79, 94
04-0000-21NC	74
04-0023-02	69, 71, 74, 95
04-0023-021	71, 73, 77
04-0067-00	94
04-0112-00NC	74, 79
04-0212-02NC	74, 79, 94
04-0216-00	79, 94
04-0260-00	79, 94
04-0270-01	67, 74, 79, 94
04-0270-03	67, 74, 79, 94
04-0270-04	67, 74, 79, 94
04-0280-00	67, 74, 79, 94
04-0280-01	67, 74, 79, 94
04-0280-02	67, 74, 79, 94
04-0290-00	67, 75, 77–79, 94
04-0290-01	77, 79, 94
04-0290-02	77, 79, 94
04-0320-00	69, 71, 73–75, 77–79, 87, 89, 91, 93–94
04-0360-00	79, 94
04-0361-00	79, 94
04-0380-00	74, 79, 94
04-0400-55	69, 71, 73, 87, 89, 91, 93
04-0460-00	79, 94
04-0550-00	79
05-0000-41	75
05-0013-00	75
05-0013-41	75
05-0250-00	67, 75
05-0250-01	67, 75
05-0370-00	75, 77–78
05-0655-00	74–75, 77, 79
05-0660-00	74–75, 77, 79
05-0680-00	75
	, ,

Part No	Page
05-0695-00	75
06-0000-10	68-73, 86-91, 93
06-0000-20	68-73, 86-91, 93
06-0000-30	68-73, 86-91, 93
06-0000-30i	68-73, 86-91, 93
06-000030iKIT	87
06-0000-30i-KIT	68-69, 73, 87
06-0000-P11	71
06-0014-00NR	29, 69
06-0014-00QR	73, 77
06-0100-10QR	72
06-0100-10SW	68
06-0100-20QR	72
06-0100-20SW	68
06-0100-30iSW	68
06-0100-30QR	72
06-0100-30SW	68
06-0114-00QR	73,77
06-0116-00QR	73,77
06-0118-00QR	72–73
06-0119-00QR	72–73
06-0200-10	67, 69, 71, 73, 87, 89, 91, 93
06-0200-10B	87, 89, 91, 93
06-0200-20	67, 69, 71, 73, 87, 89, 91, 93
06-0200-20B	87, 89, 91, 93
06-0200-30	67, 69, 71, 73, 87, 89, 91, 93
06-0200-30B	87
06-0200-51	67, 69, 71, 73, 87, 89, 91, 93
06-0200-51B	69, 71, 73, 87, 89, 91, 93
06-0200-52	67, 69, 71, 73, 87, 89, 91, 93
06-0200-52B	69, 71, 73, 87, 89, 91, 93
06-0200-53	67, 69, 71, 73, 87, 89, 91, 93
06-0200-53B	69, 71, 73, 87, 89, 91, 93
06-0200-54	69, 71, 87, 89
06-0200-54B	87, 89
06-0202-10	91
06-0202-20	91
06-0202-30	91
06-0300-51	68-69
06-0300-51SW	68-69
06-0300-52	69
06-0300-52QR	73
06-0300-52SW	69
06-0300-54QR	72-73
06-0300-55	69, 73, 87

## **Product index**

Part No	Page
06-0300-55i	69, 73, 87
06-0400-51	69, 71, 87, 89
06-0400-51B	87, 89
06-0400-52	69, 71, 87, 89
06-0400-52B	87, 89
06-0400-53	69, 71, 87, 89
06-0400-53B	87, 89
06-0400-54	69, 71, 87, 89, 91
06-0400-54B	87, 89, 91
06-0400-55	87, 89, 91
06-0400-55B	87, 89, 91
06-0500-51	69, 87
06-0500-52	69, 71, 87, 89
06-0500-53	87
06-0500-56	69, 71, 73–75, 77, 79, 87, 89, 91, 93–94
06-0500-57	69, 71, 73–75, 77, 79, 87, 89, 91, 93–94
06-0500-58	69, 71, 73–75, 77, 79, 87, 89, 91, 93–94
06-0500-59	69, 71, 73–75, 77, 79, 87, 89, 91, 93–94
06-0500-65	83
06-0600-00SW	70–71
06-0600-10SW	70
06-0600-20SW	70
06-0600-30SW	70
06-0614-00NR	70–71
06-0700-51	89, 91
06-0700-54	71, 89, 91
06-0700-63	71, 89, 91
06-0700-64	71, 89, 91
06-0700-72SW	71
06-0700-73	71, 89, 91
06-0700-81	71, 89
06-0700-82	71, 89
06-0700-83	69, 71, 74–75, 77, 79, 87, 89, 94
06-0700-85	89
07-0001-10	76–77
07-0001-11	76-77
07-0001-31	76–77
07-0012-00BL	76-77
07-0012-31BL	76
07-0012-31BLQR	76
07-0012-31BZ	76
07-0012-31SR	76
07-0012-31TB	76
07-0012-31TW	76

Part No	Page
07-0024-02	74–75, 77, 79, 92, 94
07-0112-00BLQR	77
07-0114-00BLQR	76–77
07-0200-51	67, 77
07-0200-52	67, 77
07-0200-53	67, 77
07-0212-00SV	77
07-0680-00	77
14-0099-28	94
14-0099-29	94
15-0009-9902	83
15-0099-05	83
15-0099-06	83
15-0099-08	83
15-0099-10	83
15-0099-11	83
15-0099-12	83
15-0099-16	83
15-0099-20	83
15-0099-21	83
15-0099-9906	83
15-0099-9912	83
15-0299-9902	83
15-0299-9906	83
15-0299-9936	83
15-0499-9902	83
15-0499-9906	83
15-1101-99	83
15-1699-28	94
15-1699-29	94
16-0099-27	92
16-0099-28	92
16-0099-29	92
16-0099-30	74, 77, 79, 92, 94
16-0099-32	92
16-0099-35	92
16-0300-9905	92
18-0099-68	73–75, 77–79, 94
19-0099-63	85
25-0099-28	87
25-0099-35SW	87
25-0400-55	87
25-5702-00SW	86
25-5702-30iSW	86
256-02-00	84–85

. . . .

## **Product index**

Part No	Page	
256-02-01	85	
26-0099-28	89	
26-0099-35SW	89	
26-0400-55	89	
26-5702-00SW	88	
26-5702-30iSW	88	
27-0099-28	91	
27-0099-35SW	91	
27-0099-52	91	
27-0099-53	91	
27-0099-63	91	
27-0099-68	91	
27-0099-72	91	
27-0099-84	91	
27-0099-85	91	
27-0099-87	91	
34-0905-SGV	92	
34-0905-SGX	92	
34-0905-SGXX	92	
34-5401-02SG	82–83	
35-0099-08	83	
35-0099-08N6	80, 83	
35-0099-14	83	
35-0699-9901	83	
35-1099-01	83	
35-1099-07	83	
35-1099-81	83	
35-1101-00SW	81, 86	
35-1101-10SW	81, 86	
35-1101-20SW	81, 86	
35-1101-30iSW	81, 86	
35-3499-01	82	
35-5401-01	82–83	
35-5401-01*	82–83	
36-1101-00SW	81, 88	
36-1101-00SWHA	88	
36-1101-10SW	81, 88	
36-1101-20SW	81, 88	
36-1101-30iSW	81, 88	
37-1101-00SW	81, 90	
37-1101-00SWHA	90	
37-1101-10SW	81, 90	
37-1101-20SW	81, 90	
37-1101-30iSW	81, 90	
37-5702-00SWSR	90	


Part No	Page
529-04-48	85
529-04-49	85
529-04-50	85
529-05-20	85
BPK-01	83
BT-20	96
BT-30	96
BT-40	96
L-122SG	82–83, 85
L-153SG	93
L-154SG	93
L-199SG	93
L-223-2	93
L-225-2	93
L-226-2	93
L-227	93
L-228-2	93
L-705SG	93
L-705SG-F	93
L-901SG	93
L-905SG	92–93
L-905SG-F	93
M-116	96
M-150	96
M-154	96
M-207	80,96
M-307	80,96
M-316	96
M-350	91, 96
M-354	96
M-407	80,96
M-919	96
M-920	96
M-921	96
M-925	96
M-927	96
M-928	96
M-937	96
M-953	96
M-956	96
M-957	91
M-958	91, 96
M-960	96
M-972	96
M-976	96

## **Product index**

Part No	Page
M-985	91, 96
SG-15	83, 85, 96
SG-30W	83, 85, 96
SG-40W	83, 85, 96
SG-50W	83, 85, 96
SG-90	83, 87, 89, 91
V-100	80, 84-86, 88, 90
V-111	85
V-115	85
W-1449-2	85
V-150	84–85
W-1596	85
V-199	85
V-200	80, 84–85
V-211	85
W-2119	85
V-215	85
V-250	84-85
W-2806	84-85
W-2808	84-85
W-2811-10	85
W-2915M	85
W-2916	85
W-2920	85
W-2921	85
W-2923	85
W-2924	85
W-2925	85
W-2929-100	84-85
W-2929-25	84-85
W-2929-50	84-85
W-2963	84-85
V-300	80, 84, 90
W-3012	85
W-3013-4	85
W-3079	85
W-3094M	85
W-3095	85
W-3096	85
W-3098	85
W-3099	85
W-3182-2	85
W-3281-2	85
W-9425-25	84
W-9435-100	84-85

Part No	Page
W-9435-25	85
W-9435-50	84–85
X1P5E	73
X2P5E	73
X3P5E	73
X4P5E	73
X5P5E	73

# 3M Welding Center of Excellence



35

More than 35 years ago we turned the world of welding on its head by introducing the autodarkening welding filter.



The Welding Lab in Gagnef has currently 25 employees and our business goal is that 3M should become the No 1 supplier of welding PPE to help improve productivity and customers' profitability.

**12** 

International Design Awards since 1996




8

3M Program Awards:


Circle of Technical Excellence & Innovation x3 Golden Step Award x3 Ace Award x3

## 3M Welding Lab Gagnef—Expert Areas





## **3M Occupational Health and Environmental Safety Division** Products and Services for Worker Safety





Respirators and hearing protection products are Officially Licensed Products of NASCAR®



# 3 V Job Solutions Work

We believe that health and safety is first and foremost about safeguarding worker welfare. A secure, safe working environment is paramount in any business. But we also believe that improving worker protection, comfort, durability and productivity is a more ambitious goal; one we firmly believe in.

At 3M, we don't take safety for granted. The health and welfare of your workforce depends on it. So, by working in association with skilled safety practitioners, partners and customers, our people are committed to ensuring that we help you create an environment that protects your workforce—effectively, efficiently and economically.

## Comfort and safety, right from the start.

For decades, 3M has been an innovator in worker health and safety. In 1972, we introduced the first NIOSH-approved disposable filtering facepiece respirator and launched the first disposable earplug.

40 years and thousands of patents later, 3M now offers an extensive family of Personal Protective Equipment (PPE). In addition to bringing new innovations to the market, we are constantly enhancing products with new technology and materials. 3M has remained at the forefront of worker safety.

Trust your PPE to a company that has the support and services you've needed for decades past and can rely on for years to come.

## Better.

Products that help you become more efficient.

## Faster.

Solutions that are easy to use.

Now that's Smarter.

