

IMPORTANT SAFETY INSTRUCTIONS

READ AND UNDERSTAND ALL INSTRUCTIONS. When using electric appli-AWARNING ances, basic precautions should always be followed, including the following:

•Before using, read this operator's manual, your battery pack and charger operator's manual, and all labels on the battery pack, charger and light. Learn your light's applications and limitations as well as potential hazards associated with this type of tool.

•Read and understand all the instructions before using the appliance.

•To reduce the risk of injury, close supervision is necessary when an appliance is used near children.

•Store idle light out of reach of children. Warm lights can become hazardous in the hands of children.

Store indoors. Do not expose to rain.


•Batteries must be recharged only with the charger specified by the manufacturer. A charger that may be suitable for one type of battery may create a risk of fire when used with another battery.

•Use light only with specifically designated battery pack. Use of any other batteries may create a risk of fire.

•When battery pack is not in use, keep it away from metal objects like: paper clips, coins, keys, nails, screws, or other small metal objects that can make a connection from one terminal to another. Shorting the battery terminals together may cause sparks, burns, or a fire.

 Maintain labels and nameplates. These carry important information. If unreadable or missing, contact a MILWAUKEE service facility for a free replacement.

SAVE THESE INSTRUCTIONS FUNCTIONAL DESCRIPTION



Direct Current



Pinch Hazard - Keep hands out of pinch zone

SPECIFICATIONS	
Cat. No Ingress Protection Light Output	
Ingress Protection	IP54
Light Output	
High	
Low	
Mounting Carrier Extension	/0" 70"
Battery Type	M12™
Charger Type	M12™
Charger Type DC Input Volts	
Max DC Input Amps Recommended Ambient Operating Temperature	0.9
Recommended Ambient Operating Temperature	0°F to 125°F

ASSEMBLY

Recharge only with the charger specified for the battery. For specific charging instructions. read the operator's manual supplied with your charger and battery.

Inserting/Removing the Battery

To **remove** the battery, push in the release buttons and pull the battery pack away from the tool. Always remove battery pack before changing or removing accessories.

To insert the battery, slide the pack into the body of the tool. Make sure it latches securely into place.

OPERATION

To reduce the risk of injury, do not look directly into the light when the light is on.

To turn **on** the light, press the Power button ①. Press the **MODE** button to cycle through High and Low settings. To turn **off** the light, press the Power button ① again.

Hanging the Light

The light bar can be used on its own, using the light bar hook to hang by a surface, or with the carrier to mount inside the hood of a car.

To mount the light to the hood of a car:

- 1. Place the mounting carrier on the hood of the car using the carrier hooks. Extend the hooks if necessary to ensure fit. Make sure the carrier is fully seated on the hood. WARNING! Pinch hazard - Keep hands out of pinch zone.
- 2. Adjust the light bar as necessary by rotating it to the desired position and sliding it left or right along the mounting carrier.

MAINTENANCE

To reduce the risk of injury, always unplug the charger and remove the battery pack from AWARNING the charger or tool before performing any maintenance. Never disassemble the tool, batterv pack or charger. Contact a MILWAUKEE service facility for ALL repairs.

Maintain Light

Keep your light, battery pack and charger in good repair by adopting a regular maintenance program. If the light does not work properly, return the light to a MILWAUKEE service facility for repairs.



AWARNING To reduce the risk of personal injury and damage, never immerse your tool, battery pack or charger in liquid or allow a liquid to flow inside them.

Cleaning

Keep tool handles clean, dry and free of oil or grease. Use only mild soap and a damp cloth to clean the tool, battery pack and charger since certain cleaning agents and solvents are harmful to plastics and other insulated parts. Some of these include gasoline, turpentine, lacquer thinner, paint thinner, chlorinated cleaning solvents, ammonia and household detergents containing ammonia. Never use flammable or combustible solvents around tools.