

INSTRUCTIONS FOR USE

GB

Examination before use

Before use check the gloves for punctures by blowing them up.

In case of any doubts regarding the gloves' protection, do not use these gloves.

Gloves becoming wet during use or after washing should be dried carefully at a temperature not exceeding 60°C.

Do not exceed the working voltage.

Avoid contact with oil, grease, white spirit or strong acids.

Cleaning

Clean the gloves in lukewarm soapy water.

Do not use wire brushes, sandpaper or other sharp objects.

Dry at room temperature, if possible, but not exceeding 60°C and powder them with talc.

If there are still spots of tar or paint on the gloves, clean immediately with a suitable solvent (use only a small amount and wash at once, as direct above).

Do not use petrol, paraffin or white spirits.

Storage/Transport

Store and transport the gloves in original packaging only.

Make sure that the gloves are not bent, folded or stored besides any sources of heat.







Do not expose them to direct sunlight, electrical light and do not store them near ozone-producing devices.

Store the gloves unfolded in dry condition at a temperature between 10°C and 21°C.

Disposal

If unused, the gloves can be disposed of with normal household waste.

If contaminated with chemicals, they are to be disposed of with the chemical manufacturers' instructions.



 **Beta**

Mod. 1995 MQ/G



GB

INSTRUCTIONS FOR USE