## **Applications**

- Masonry expansion wall joints
- Precast panel wall joints
- Pavement/Floor Joints
- Drive-It/Stucco

## **Assembly**

- 1. Locate the main frame.
- 2. Select the desired insertion wheek size. Insert shaft into main frame.
- 3. Insert Vibration Resistant thumb screw.
- 4. Adjust insertion wheel to desired depth.

Tighten vibration resistant screw until secure contact is made with flat on shaft.

Accomodates a standard threaded broom handle when desired.

Head of thumb screw can be used to start backer rod and to pitch off backer rod at end of insertion.





