

# Brite-Nite<sup>™</sup> 1,000 Lumen Area Worklight<sup>™</sup>



## User's Manual

We are constantly improving our products so specifications are subject to change without notice.




## Brite-Nite™ 1,000 Lumen Area Worklight™ by Wagan Tech®

Thank you for purchasing the Brite-Nite™ 1,000 Lumen Area Worklight™ by Wagan Tech®. With normal care and proper treatment, it will provide years of reliable service. Please read all operating instructions carefully before use.

### FEATURES

- 120 bright SMT LEDs
- 3 brightness levels
- Rechargeable Li-ion battery
- Light bar rotates 180°
- Strong magnets on each end for mounting
- Two 360° fold-away swivel hooks
- Charging cable with DC and AC adapters included



## SPECIFICATIONS

Lumens	High— 1,000 lm Medium— 400 lm Low— 200 lm
Run Time	High— 1 hr Medium— 2 hr Low— 4 hr
Battery	3.7V 2200 mAh Li-ion
Beam Distance	82 ft (25 m)
Charge Time	4 hr
Charge Input	5V, 1A

## CAUTION

- Never point the light beam directly into the eyes of another person or animal.
- This product is not a toy: Do not allow children to play with this item.
- Do not store in direct sunlight or near a heat source.
- Use for intended purposes only.
- Do not submerge in water.
- Lens gets hot after prolonged use. Avoid heat sensitive surfaces.
- This product contains strong magnets that may cause interference with pacemakers and other implanted medical devices when placed within a close proximity. Keep this product at least 6 inches from your chest if you have a pacemaker.

## OPERATION

1. Locate power switch
2. Click 1X for low  
Click 2X for medium  
Click 3X for high  
Click 4X to turn off

## CHARGING THE INTERNAL BATTERY

Please charge before initial use. In order to prolong the life of the battery, be sure to fully recharge the unit every 3 to 6 months, even if the unit has not been used.

1. Only use charging cable provided with the device.
2. The charging port is located on the handle with the power switch. Rotate the black portion of the handle to reveal the charging port (see diagram on page 1).
3. Insert the included charging plug into the charging port.
4. Plug the other end of the cable into a USB power port such as a USB wall charger, USB car charger or power bank.
5. The charge indicator LED will illuminate red while charging and will turn green when fully charged (about 4 hours).

## SUGGESTED USES

